

globalpayments T650P Global Payments Terminal



globalpayments T650C Global Payments Terminal User Guide

[Home](#) » [globalpayments](#) » globalpayments T650C Global Payments Terminal User Guide 

Contents

- [1 globalpayments T650C Global Payments Terminal](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Get started](#)
- [5 Network communication](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

globalpayments

globalpayments T650C Global Payments Terminal



Product Specifications

- **Model:** T650C / T650P
- **Power Source:** T650C – DC power connector; T650P – USB charging
- **Connectivity:** T650C – Wi-Fi and Ethernet; T650P – Wi-Fi and 4G wireless
- **Manager Password:** 7-12 characters or digits

Product Usage Instructions

Terminal ON/OFF

Countertop–T650C: Connect the dedicated DC power connector for power supply.

Wireless–T650P: Charge the terminal using the provided power cable. Press and hold the power button to turn the device on/off.

Manager Password

Contact Global Payments Customer Care Centre at 1-[888-682-3309](tel:888-682-3309) to set up a manager password consisting of 7-12 characters or digits.

Network Communication

- **Wi-Fi Set-Up:** Access available networks, select the desired Wi-Fi network, enter a password, and connect.
For Ethernet set-up (T650C), insert the Ethernet cable into the device.
- **4G Set-Up:** If you have a 4G configuration, the terminal comes with a pre-installed SIM card for immediate use.

Performing a Sale Transaction

1. Tap [SALE] on the screen.
2. Enter the transaction amount and confirm.

- 3. The cardholder completes payment following on-screen prompts.
- 4. The transaction is complete.

Additional Resources

Visit the Global Payments Help Centre at help.globalpay.com for more support materials or scan the QR code for assistance.

Frequently Asked Questions (FAQ)



- Q: How can I charge the T650P terminal?
A: Use the provided power cable by inserting the USB end into the terminal and connecting the other end to a power supply.
- Q: What should I do if I forget my manager password?
A: Contact Global Payments Customer Care Centre at 1-[888-682-3309](tel:8886823309) for assistance in resetting your manager password.


Get started




Welcome to the Global Payments Terminal Quick Start Guide! It's your go-to resource for quickly and easily setting up and using your new payments terminal. This guide covers everything from the initial setup to processing payments, ensuring you have all the essential information at your fingertips. We'll also provide you with helpful links to additional resources to maximize the potential of your new payment solution. Let's get started!

Terminal ON/OFF

The terminal power configuration differs across devices; view the table below to see the power connectivity method for your device(s):

Countertop—T650C	Wireless—T650P
<p>The T650C features a dedicated DC power connector for easy and convenient power supply.</p> 	<p>The T650P comes pre charged, but we advise you to charge the terminal to ensure it maintains a battery life above 15% for seamless transaction processing. Inside the box, you will find the power cable. To charge the device, insert the USB port into the T650P and connect the other end to the power supply.</p> 

- Power On: Press and hold the power button [] to turn on the device.

- Power Off: Press and hold the power button [] to wake the device up. After it is turned on, press and hold the power button [] until the “User Menu” displays on the screen. Tap [ Power off] to turn off the device.

Manager password

To set up your personalized manager password, kindly reach out to Global Payments Customer Care Centre at 1-[888-682-3309](tel:888-682-3309). Please note that the password should consist of 7-12 characters or digits.

Network communication

Device name	Countertop—T650C	Wireless—T650P
Available connectivity mode	Wi-Fi and Ethernet	Wi-Fi and 4G wireless


Network configuration differs across devices; view the table below to see the available connectivity method for your device(s):

To set up your device connectivity, follow the steps based on the communication mode configuration that you ordered.

For a Wi-Fi set-up

1. Swipe down from the top of the home screen. When you see the status bar, swipe down again.
2. Tap the Wi-Fi icon to toggle “Wi-Fi On”
3. Tap the arrow at the bottom of the Wi-Fi icon to display available networks
4. Tap the SSID name of the Wi-Fi network that you want to connect to from the list.
5. Enter the Wi-Fi password, and then tap [CONNECT].

For an ethernet set-up (Countertop—T650C only)



1. Insert the Ethernet cable into the T650C device.
2. Connect the other end of the cable to the ETH port, as illustrated on the right.

For a 4G set-up (Wireless—T650P only)

If you have selected a 4G configuration for your terminal, rest assured that it will arrive with a pre-installed and pre-programmed network SIM card, fully prepared for immediate use.

Performing a sale transaction

1. Tap the [SALE] transaction icon on the Payments app home screen.
2. Key in the transaction amount and tap [✓].
3. The cardholder taps/inserts/swipes their payment method and follows the prompts on the screen for each card entry.
4. Transaction complete

Additional resources



- Visit the Global Payments Help Centre at help.globalpay.com or scan the QR code on the side for additional support materials for your device(s).
- Should you have any questions or require additional instructions, please contact the Global Payments Customer Care Centre at 1-[888-682-3309](tel:888-682-3309).

© 2023 Global Payments Inc. All Rights Reserved.
SM-232614-v1.0

Documents / Resources



[globalpayments T650C Global Payments Terminal](#) [pdf] User Guide
T650C Global Payments Terminal, T650C, Global Payments Terminal, Payments Terminal

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.