

globe 50027 Smart WiFi Water Sensor Instruction Manual


Home » globe » globe 50027 Smart WiFi Water Sensor Instruction Manual



Contents

- 1 globe 50027 Smart WiFi Water Sensor Instruction Manual
- **2 SPECIFICATIONS**
- 3 WHAT'S IN THE BOX?
- **4 PRODUCT INFORMATION**
- **5 HOW TO POWER THE SENSOR**
- **6 MOUNTING INSTRUCTIONS**
- **7 BATTERY HANDLING AND USAGE**
- **8 BATTERY REPLACEMENT**
- **9 LIMITED WARRANTY**
- 10 Documents / Resources
- 11 Related Posts


globe 50027 Smart WiFi Water Sensor Instruction Manual



Check out the Installation video on our website: globe-electric.com/smart



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. READ ALL INSTRUCTIONS BEFORE USE.



• Do not immerse or expose the main body in/to water or other liquids.

• This product is not intended for use by children and contains small parts that may pose a choking hazard to children under the age of three Keep the product out of the reach of children and pets.

SPECIFICATIONS

• Required battery. Ix CR2-3V


• Standby current: 13 μA

• Working current TI5 mA-120 mA


Wireless type: 2.4 GHzWireless range: 45 m

• Wireless Protocol: IEEE 802.11b/g/n

WHAT'S IN THE BOX?



PRODUCT INFORMATION



HOW TO POWER THE SENSOR

- Remove the holder from the main body. Twist the top half of the sensor counterclockwise. Once the casing is off, remove the small plastic tab on the battery terminal. The battery will be connected and the sensor will automatically be in pairing mode.
- If not in pairing mode press and hold the power/reset button for 5 seconds until flashing rapidly.

MOUNTING INSTRUCTIONS

- When you select your mounting location, make sure the surface area is clean.
- During the mounting process, ensure the metal contacts on the probe are facing downwards.

There are 2 options for mounting:

Option 1:

You can simply place the water sensor on a flat surface without mounting the holder.

Option 2:

Remove the holder from the main body. Select your location and mount the holder using the included screw and wall anchor. Once installed, insert the main body and plug in the probe.

WARNING:

Keep batteries away from children and pets.

- Follow the battery manufacturer's safety and usage instructions.
- Insert the battery observing the proper polarity (+/-) as indicated inside the battery compartment.

CAUTION:

Failure to properly align the battery polarity can cause personal injury and/or property damage.

- Remove a spent or discharged battery from the product. Remove the battery when not using the product for an extended period.
- Never throw batteries into a fire. Do not expose batteries to fire or other heat sources.

DISPOSAL OF USED BATTERIES:

Battery may contain hazardous substances which could endanger the environment and human health. Used batteries shall not be treated as municipal waste, but left at the appropriate collection point for recycling. For more information about collection and recycling of used batteries, please contact your local municipality or waste disposal service.

- Use type CR2-3V battery.
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Danger of explosion if battery is incorrectly replaced.
- Batteries should be recycled or disposed of as per state and local guidelines.

BATTERY REPLACEMENT

- 1. Remove the holder from the main body.
- 2. Twist the top half of the sensor in the counterclockwise rotation.
- 3. Remove the spent battery and place Ix CR2-3V battery into the battery compartment, correctly observing the polarity indications (+/-)
- 4. Replace the top half of the sensor by rotating it clockwise.

LIMITED WARRANTY

This device is warranted for I year from the date of purchase. If it fails before that time, we will replace it. Send Globe Electric the sensor, proof of purchase and register receipt along with your complete name and address. See caution text for proper use. This warranty is void if this product is misused in any way. This replacement is the sole remedy available and liability for incidental or consequential damage is expressly excluded.

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

CAUTION:

This device is intended for indoor use or in weather protected fixtures. Lithium Battery: 3.0V A size. Do not recharge, crush, disassemble, heat above 85°C, incinerate, or expose the main body to water. Fire explosion, and severe burn hazard may ensue. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20 cm between the radiator & your body.

User Manual Notice for Licence-Exempt Radio Apparatus

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3 (B).

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Since 1932, Globe has taken pride in offering products of the highest quality, and a level of service unparalleled in the industry. Should you encounter any difficulties, have any questions or simply wish to offer us your valuable feedback, you may contact us in the following ways:

Toll Free Telephone: 1-888-543-1388 (North America Only) / Toll Free

Fax: 1-800-668-4562 (North America only)

E-Mail: info@globe-electric.com/ Mail: Globe Electric Customer

Service Department 150 Oneida, Montreal, Quebec, Canada H9R IA8 Please visit our website to discover other quality Globe products: http://www.globe-electric.com

FCC RESPONSIBLE PARTY

Globe Electric 1-888-353-1388 15301 Shoemaker Ave Norwalk, CA 90650 www.globe-electric.com

Read More About This Manual & Download PDF:

Documents / Resources



globe 50027 Smart WiFi Water Sensor [pdf] Instruction Manual 50027, Smart WiFi Water Sensor, 50027 Smart WiFi Water Sensor

Manuals+, home privacy