




# globe 50279 Smart Wi-Fi Universal Remote User Guide

[Home](#) » [globe](#) » globe 50279 Smart Wi-Fi Universal Remote User Guide 



## Globe

50279 Smart Wi-Fi Universal Remote  
User Guide



**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE READ ALL INSTRUCTIONS BEFORE USE**



**WARNING** – To reduce the risk of fire, electric shock, or serious personal injury:

- Do not immerse the product in water or other liquids.
- This product is not intended for use by children and contains small parts that may pose a choking hazard to children under the age of three. Keep the product out of the reach of children and pets.


## Contents

- 1 SPECIFICATIONS
- 2 WHAT'S IN THE BOX
- 3 PRODUCT INFORMATION
- 4 MOUNTING INSTRUCTIONS
- 5 LIMITED WARRANTY
- 6 WARNING:
- 7 RF Exposure
- 8 User Manual Notice for Licence-Exempt Radio Apparatus
- 9 Radiation Exposure Statement:
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts


## SPECIFICATIONS

- Standby current:  $\leq 0.8\text{A}$
- Working current: 1A
- Wireless type: 2.4 GHz
- Wireless range: Circular radius 8m ( 26.2 ft)
- Wireless Protocol: IEEE 802.11b/g/n

## WHAT'S IN THE BOX




smart universal  
remote



USB cable  
0.7m (2.30 ft)


## PRODUCT INFORMATION



## HOW TO POWER THE UNIVERSAL REMOTE

- Take your universal remote and the included micro USB cable. Insert cable underneath the remote and plug it into a USB adapter (not included).
- Once connected, the universal remotes LED (located at the front) will be flashing rapidly
- If the remote is not flashing rapidly. Press and hold the reset button located underneath for 5 seconds. Repeat process if not successful.

To pair the universal remote see the quick start guide or follow the how-to guide within the Globe Suite app.



## MOUNTING INSTRUCTIONS

- You can simply place the universal remote on any flat surface.

- Ensure that the remote is within range of the products you wish to control. The circular radius of 8m (26.2ft)
- This item can be used with an extension cord if needed.

## **LIMITED WARRANTY**

This device is warranted for 1 year from the date of purchase. If it fails before that time, we will replace it. Send Globe Electric the sensor, proof of purchase, and register receipt along with your complete name and address. See caution text for proper use. This warranty is void if this product is misused in any way. This replacement is the sole remedy available and liability for incidental or consequential damage is expressly excluded.

## **FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT**

### **CAUTION:**

This device is intended for indoor use. Do not use where directly exposed to water. Do not recharge, crush, disassemble, heat above 85 °C, incinerate, or expose content to water. Fire explosion and severe burn hazards may ensue. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this the device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

### **WARNING:**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

## **RF Exposure**

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with a minimum distance of 20cm between the radiator & your body.

## **User Manual Notice for Licence-Exempt Radio Apparatus**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3 (B)

### **Radiation Exposure Statement:**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Since 1932, Globe has taken pride in offering products of the highest quality, and a level of service unparalleled in the industry.

Should you encounter any difficulties, have any questions or simply wish to offer us your valuable feedback, you may contact us in the following ways:

Toll-Free Telephone: 1-888-543-1388 (North America Only) / Toll-Free Fax: 1-800-668-4562 (North America Only)

E-Mail: [info@globe-electric.com](mailto:info@globe-electric.com) / Mail: Globe Electric Customer Service Department

150 Oneida, Montreal, Quebec, Canada H9R 1A8 Please visit our website to discover other quality Globe products: <http://www.globe-electric.com>

#### FCC RESPONSIBLE PARTY PARTIE RESPONSABLE FCC

Globe Electric


1-888-353-1388

15301 Shoemaker Ave

Norwalk, CA 90650

[www.globe-electric.com](http://www.globe-electric.com)

## Documents / Resources

	<p><a href="#">globe 50279 Smart Wi-Fi Universal Remote</a> [pdf] User Guide GE50279, 2AQUQGE50279, 50279 Smart Wi-Fi Universal Remote, 50279, Smart Wi-Fi Universal Remote</p>
--	---

## References

- [Electric | The Largest Consumer Energy & Renewables Platform](#)