Home » GO RHINO » GO RHINO RB-Series Running Board Drop Steps Instruction Manual



# **GO RHINO RB-Series Running Board Drop Steps Instruction** Manual

#### Contents

- 1 GO RHINO RB-Series Running Board Drop Steps
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 PRODUCT SAFETY & LEGAL DISCLAIMER**
- **5 INSTALLATION INSTRUCTIONS**
- 6 Documents / Resources
- 7 Related Posts

## **GO RHINO RB-Series Running Board Drop Steps**

#### **Product Information**

- Product Description: RB Drop Step attachment for RB10 Running Board
- Product Safety & Legal Disclaimer: Please visit <u>www.gorhino.com</u> for more information.
- · Manufacturer: Go Rhino
- Address: 589 W. Apollo St., Brea, CA 92821
- Contact: 888-427-4466

## **Product Usage Instructions**

#### Installation Instructions:

- Before installing the product, read the installation instruction manual from front to back.
- Refer to the provided installation video or visit <a href="http://www.gorhino.com/Installation-Videos">http://www.gorhino.com/Installation-Videos</a> for visual guidance.
- Estimated time for installation: 30 minutes
- If you need installation service, contact the authorized distributor or call toll-free 1-888-427-4466 to find an authorized installation service company.

#### **Tools Needed for Installation:**

• 8MM SEMS Bolt

## **Installation Steps:**

Note: The following instructions are for attaching the RB Drop Step to the RB10 Running Board on the driver side front or rear door position.

- 1. Attach the Auxiliary Bracket to the U-Bracket using (1) 8MM SEMS Bolt. Do not tighten the screw. (Refer to Figure 1)
- 2. Determine the desired location of the driver side RB Drop Step on the RB10 Running Board. Position (1) U-Bracket toward the front of the vehicle and the Auxiliary Bracket and U-Bracket assembly toward the rear of the vehicle in the opening on the underside of the RB10 Running Board. (Refer to Figure 2)
- 3. Attach the driver side RB Drop Step to the RB10 Running Board using the U-Brackets and (3) 8MM SEMS Bolt. Tighten all screws securing the RB Drop Step, U-Brackets, and Auxiliary Bracket to the RB10 Running Board. Repeat steps for the passenger side. (Refer to Figure 3)

**Note**: The above instructions are specific to attaching the RB Drop Step to the RB10 Running Board on a Jeep Wrangler 4-door driver side rear door position.

#### PART NO.

- 69420000T
- 69420000PC

#### PRODUCT DESCRIPTION:

· Straight RB Drop Steps

## **PRODUCT SAFETY & LEGAL DISCLAIMER**

- IMPORTANT READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING, FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY.
- Review the product package and contents prior to beginning the installation. Take care when opening the
  packaging and removing items. If a return is needed you will want to return the product in its original packaging
  if possible.
- This instruction guide is provided as a GENERAL installation guide, some vehicles vary dimensionally and may require additional steps.
- Test fit the product on the vehicle prior to any third party modifications and or finishing. The manufacturer and/or distributors do not accept responsibility for third party charges, labor and or third part replacement modifications. Some modifications may void the factory warranty.
- Exercise due-diligence when installing this product. The manufacturer and distributors of this product do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product. Careless installation and operation can result in serious injury or equipment damage.
- This product is for general off-road use. All liability for installation and use rests with the owner/operator.
- INSTALLER: Once installation is complete, please return this guide along with other documentation included in this product back to the consumer for future reference. The manufacturer/distributors of this product do not guarantee this particular version will be available at a later date.

© 2016 Go Rhino Products. All rights reserved www.gorhino.com 589 W. Apollo St., Brea, CA 92821 P: 888 427 4466

## **INSTALLATION INSTRUCTIONS**

#### **INJURY HAZARD**

- Please complete a shop and tool inspection prior to beginning the installation.
- Always make sure you have a clean, dry and well lit work area.
- Always remove jewelry, loose fitting clothing and wear protective gloves and eye protection.
- Always use extreme caution when jacking or raising a vehicle for work. Set the emergency brake and use tire/wheel blocks and jack stands. Refer to the vehicle manufacturer hand book. Utilize the vehicle manufacturers designated lifting points.
- Always use appropriate and adequate care in lifting parts during disassembly and installation. Seek help in lifting heavy or large items into place. Utilize jacks and or lifting devices when available.
- Always insure products are secure during disassembly and installation.
- Always wear eye protection and take steps to protect any exposed skin during the installations. Drilling, cutting
  and grinding plastic and metal may create flying particles that can cause injury.
- Always use extreme caution when drilling, cutting and or grinding on a vehicle. Thoroughly inspect the area to be drilled, on both sides of material, prior to modification and relocate any objects that may become damaged.
- Always assemble and tighten all fasteners per the installation instructions.
- Always route electrical cables carefully. Avoid moving parts, parts that may become hot and vrough or sharp edges.
- Always insulate and protect all exposed wiring and electrical connections.

### **MAINTENANCE AND CARE**

- Always perform regular inspections and maintenance on mounts and related fasteners.
- · Periodically check and tighten all fasteners.
- Stripped, fractured, or bent fasteners must be replaced.
- After washing the vehicle make sure to fully dry all surfaces.
- In areas with cold temperatures make sure to wash the product often to remove harmful materials used on road ways.
- Never use abrasive cleaners or polish compounds. Clean with a gentle soap and water. If you use wax use a non abrasive automotive wax such as pure carnauba wax.

#### **WARNING**

- Some products have been designed to work together with factory rear sensor systems, factory forward facing sensor systems and factory air bags.
- Installation of some of these products may alter the factory sensor system performance.
- Factory sensors may read shackles or hooks protruding from the fairlead and or tow hooks.
- All sensor testing is completed by Go Rhino Products and or third party testing labs on modified vehicles.
- Sensor sensitivity, factory sensor housing, orientation, and operating conditions are all variables that will influence functionality of the sensors.
- Installation of some product may effect the factory air bag systems.
- · Some products allow the use of third party products such as winches, shackles, hooks, etc. Follow the

respective manufacturers operating instructions for use with our products.

- Make sure to fully understand the product, it's intended use and operation prior to use.
- Above all... be safe!

## **Documents / Resources**



GO RHINO RB-Series Running Board Drop Steps [pdf] Instruction Manual

RB-Series Running Board Drop Steps, RB-Series, Running Board Drop Steps, Board Drop Steps, Drop Steps, Steps

Manuals+,