



Godox RC-A6II Remote Control Instruction Manual

[Home](#) » [Godox](#) » Godox RC-A6II Remote Control Instruction Manual 

Contents

- [1 Godox RC-A6II Remote Control](#)
- [2 Body](#)
 - [2.1 Declaration of Conformity](#)
- [3 Operation](#)
- [4 Technical Data](#)
- [5 FCC Statement](#)
- [6 Warranty](#)
 - [6.1 Applicable Products](#)
 - [6.2 Warranty Period](#)
 - [6.3 How to Get the Maintenance Service](#)
 - [6.4 Inapplicable Cases](#)
- [7 Maintenance and Service Support Information](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)




Godox RC-A6II Remote Control



Body

1. LCD Panel (Black in White)
2. CH/GR Button
3. SET Button
4. "+" Button
5. Battery Compartment
6. Power Switch
7. "-" Button
8. Battery Compartment Cover



Warning

This product is for commercial use. Operating frequency: 2412.99MHz – 2464.49MHz
Maximum Average EIRP Power: 5dBm

Declaration of Conformity

GODOX Photo Equipment Co.,Ltd. hereby declares that this Remote Control/RC-A6II is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link:

https://www.godox.com/DOC/Godox-RC-A6II_DOC.pdf.

The device complies with RF specifications when the device used at 0mm from your body.

Operation

1. Wireless Control

RC-A6II has control function, and can control multiple groups of LED lights. The remote has 32channels and

100 IDs to avoid interference. Please set the channels, groups and IDs of LED light to the same as those of RC-A6II remote control before usage.

2. Adjusting Channel/Group with the Remote Control

- Press the CH/GR button and the group icon blinks.
- Press the“-”“+”button to choose a group (A to F, 0 to 9).
- Press the CH/GR button twice and the channel icon blinks.
- Press the“-”“+”button to choose a channel (1 to 32).

3. Adjusting ID with the Remote Control

Double click the CH/GR button and press the“-”“+”button to choose ID from OFF or 0 to 99.

4. Adjusting Light Brightness with the Remote Control

Press the“-”“+”button to adjust the light brightness.

5. Adjusting Color Temperature with the Remote Control (The color temperature value of this LED light cannot be adjusted)

Press the SET button of the remote control and the color temperature icon blinks. Press the“-”“+”button to adjust the color temperature.

6. Remote control reset:

press down “-” and “+” button simultaneously to reset.

Note: The wireless signal can be received only when the controller of LED light is powered on.

Technical Data

Remote Control	RC-A6II
Power Supply	3.0V(AAA*2)(not include)
Wireless Frequency	2.4GHz
Distance (emptiness)	100m
Channel	32
Group	16 groups(A-F, 0-9)
Standby Time	Over one year
Operation Temperature	-10°C ~ 50°C
Dimension	120*38*15mm
Net Weight	30g

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note		

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day(purchase date) when the product is bought for the first time, And the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases:

1. The product or accessory has expired its warranty period;
2. Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing,

- improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc;
3. Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment;
 4. The original identifying information of product or accessory is modified, alternated, or removed;
 5. No valid warranty card;
 6. Breakage or damage caused by using illegally authorized, nonstandard or non-public released software;
 7. Breakage or damage caused by force majeure or accident;
 8. Breakage or damage that could not be attributed to the product itself.

Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.


Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Battery	12	Customer sends the product to designated site
	Circuit Board	3	Customer sends the product to designated site
	Electrical parts e.g.battery charger, etc.	12	Customer sends the product to designated site
Other Items	Flash tube, power cord, sync cable, modeling lamp,lamp body, lamp cover,lockingdevice, package, etc.	No	Without warranty

Godox After-sale Service
Call +86-755-29609320(8062)

Documents / Resources

	<p>Godox RC-A6II Remote Control [pdf] Instruction Manual 070, 2ABYN070, RC-A6II, Remote Control, RC-A6II Remote Control</p>
---	---