



49868 LED Tea Lights  
with Timer



## goobay 49868 LED Tea Lights with Timer User Manual

[Home](#) » [goobay](#) » goobay 49868 LED Tea Lights with Timer User Manual 

### Contents

- [1 goobay 49868 LED Tea Lights with Timer](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Specifications](#)
- [5 Safety Instructions](#)
- [6 Description and Function](#)
- [7 Operating](#)
- [8 Changing batteries](#)
- [9 Maintenance, Care, Storage and Transport](#)
- [10 Disposal Instructions](#)
- [11 Documents / Resources](#)
  - [11.1 References](#)
- [12 Related Posts](#)



**goobay 49868 LED Tea Lights with Timer**



## Product Information

### Specifications

- **Operating voltage (V):** 3.0
- **Numbers of LEDs:** 1 per candle
- **Light color:** Warm white
- **Color temperature (K):** 3000
- **Min. luminous duration (h):** 100 (with one set of batteries)
- **Color:** White
- **Protection level:** IP 20
- **Dimensions (mm):** 38 x 37
- **Weight (g):** 12 per candle
- **Battery Type:** CR2032 Lithium button cell, 3.0 V
- **Battery Quantity (pcs.):** 1 per candle

### Product Usage Instructions

#### Safety Instructions

Follow all safety instructions provided in the manual to prevent accidents and ensure safe usage of the product.

#### Description and Function

Use the product only in dry interior rooms as described in the manual. Do not use the device in ways other than specified.

#### Intended Use

Not attending to the regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

#### Operation

##### Starting Up

Remove the tab to initiate the candles.

##### Power On / Off

##### Manual:

1. To turn on: Slide the switch (1) to the 'ON' position.
2. To turn off: Slide the switch (1) to the 'OFF' position.

##### Timer:

1. Slide the switch (1) to the 'ON' position. The LED tea lights will automatically turn off after 6 hours and continue to cycle on and off daily at the same time.
2. To turn off the timer function, slide the switch (1) to the 'OFF' position.

#### Battery Replacement

If needed, replace the empty battery with a new one of the same or equivalent type. Refer to section 7.2 for disposal instructions.

## Maintenance, Care, Storage, and Transport

The products are maintenance-free and should be stored and transported with care to prevent damage.

## Frequently Asked Questions (FAQ)

### 1. Q: Can I use the LED tea lights outdoors?

A: No, the product is intended for indoor use only in dry interior rooms as specified in the manual.

### 2. Q: How long do the batteries last?

A: With one set of batteries, the minimum luminous duration is 100 hours per candle.

## Specifications

Operating voltage (V $\equiv$ )	3.0
Numbers of LEDs	1 per candle
Light colour	warm white
Colour temperature (K)	3000
Min. luminous duration (h)	100 (with one set of batteries)
Colour	white
Protection level	IP 20
Dimensions ( $\varnothing$ x l) [mm]	38 x 37
Weight (g)	12 per candle
<b>Battery</b>	
Type	CR2032 Lithium button cell, 3.0 V
Quantity (pcs.)	1 per candle

## Safety Instructions

### General

- Read the user manual completely and carefully before use.

The user manual is part of the product and contains important information for correct use.

- Keep this user manual.

The user manual must be available for uncertainties and passing the product.

- Check the scope of delivery for completeness and integrity.
- Use product, product parts and accessories only in perfect condition.

The LEDs of these tea lights can not be replaced.

- In case of questions, defects, mechanical damage, trouble and other problems, non-recoverable by the documentation, contact your dealer or producer.
- Do not modify product and accessories.

Not meant for children. The product is not a toy!

- Secure packaging, small parts and insulation against accidental use.
- Avoid stresses such as heat and cold, moisture and direct sunlight, vibration and mechanical pressure.
- Only place on a solid, non-slipping and fireproof surface.
- Do not cover the product.

### **Batteries**

The cells are replaceable.

- Never use batteries when they are dented, leaked or damaged.
- Remove leaked, deformed or corroded batteries from the product and dispose them by appropriate protectives.
- If a battery has leaked, avoid contact with skin, eyes and mucous membranes. If necessary, rinse affected areas with water and seek medical attention immediately.
- Do not deform, burn or disassemble the battery and never pierce it with a sharp object.

Extreme heat may cause explosion and/or leaking of corrosive liquid. Mechanical damage can result in gaseous substances which can be highly irritating, combustible or toxic.

- Do not short-circuit the battery or immerse it in liquids.

There is a risk of explosion, fire, heat, fumes or gas emission.

## **Description and Function**

### **Product**

Set of 4 LED tea lights for a safe lighting solution for many areas including homes and loggias, offices or schools.

- can be used in places where real tea lights are too dangerous or not allowed
- with timer function – 6 hours on/18 hours off

### **Scope of delivery**

Set of 4 LED tea lights with timer, 4x Li-button cell, user manual

### **Operating elements and product parts**

1. ON / TIMER / OFF switch
2. Battery compartment

## Intended Use



We do not permit using the device in other ways like described in chapter „Description and Function“ or „Safety Instructions“. Use the product only in dry interior rooms. Not attending to these regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

## Operating

### Commissioning

- Remove the contact protection from the battery compartment by carefully pulling out the tab.

### Switching ON and OFF Manual

1. Switching ON : Slide the switch (1) to the „ON“ position.
2. Switching OFF: Slide the switch (1) to the „OFF“ position.

### TIMER

1. Slide the switch (1) to the „ON“ position.

The LED tea lights switch off automatically after 6 hours and switch on again after another 18 hours. If the timer settings are not changed, the LED tea lights will turn on and off at the same time each day.

2. Slide the switch (1) to the „OFF“ position to switch off.

### Changing batteries

If necessary, replace the empty battery with a new one.

- Only use batteries of the same type listed in chapter „Specifications“.
- Change the battery as shown in Fig. a – d.



- Be sure to observe the correct polarity (+/-) when inserting them. Lithium batteries can explode if inserted

incorrectly.

- Place a new battery in the battery compartment with the positive terminal facing up.
- Dispose of the empty battery properly.

Please also read chapter 7.2 „Disposal instructions“.

## Maintenance, Care, Storage and Transport

The products are maintenance-free.

- Only use a dry and soft cloth for cleaning.
- Do not use detergents or chemicals.
- Store cool and dry.
- Remove batteries / rechargeable batteries when not in use.
- Store the product out the reach of children and in a dry and dust-protected ambience when not in use.
- Keep and use the original packaging for transport.

## Disposal Instructions

### Product



According to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can damage the health and pollute the environment. As a consumer, you are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the user manual, or at the packaging alludes to these terms. With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environmental protection.

**WEEE No:** 82898622

### Battery





(Rechargeable) batteries must not be disposed of with household waste.

Their components have to be supplied separately to the recycling or disposal, because toxic and dangerous ingredients can harm the environment if not disposed of sustainably. As a consumer, you are obliged to return them at the end of their service lives to the manufacturer, the sales outlet or established for this purpose, public collection points for free. Details regulates the respective country's law. The symbol on the product, the instruction manual and / or the packaging draws attention to those provisions. With this kind of material separation, recovery and disposal of waste (rechargeable) batteries you make an important contribution to protecting our environment.


D-34000-1998-0099

## Symbols used

For indoor use only	IEC 60417- 5957	
Direct current	IEC 60417- 5031	

Goobay®  
by Wentronic GmbH | Pillmannstraße 12  
38112 Braunschweig | Germany

Documents / Resources

	<a href="#">goobay 49868 LED Tea Lights with Timer</a> [pdf] User Manual 49868, 49868 LED Tea Lights with Timer, LED Tea Lights with Timer, Tea Lights with Timer, Lights with Timer, Timer
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.