





# **GRANDSTREAM HT801 V2 Analog Telephone Adapter Installation Guide**

Home » GRANDSTREAM » GRANDSTREAM HT801 V2 Analog Telephone Adapter Installation Guide 🏗



#### **Contents**

- 1 GRANDSTREAM HT801 V2 Analog Telephone **Adapter**
- 2 Specifications
- 3 FAQ
- **4 Product Usage Instructions**
- **5 PACKAGE CONTENT**
- 6 HT801 V2 PORTS and LED indicators
- **7 PRECAUTIONS**
- **8 EU Regulatory Information**
- 9 Documents / Resources
  - 9.1 References



**GRANDSTREAM HT801 V2 Analog Telephone Adapter** 



# **Specifications**

Power Input: 5VPorts: FXS, NET

• LED Indicators: Power, FXS, NET

• Power Adapter: 5V

Micro-USB Power Socket (5V)

#### **FAQ**

#### Q: Can HT801 V2 be used to contact emergency services?

A: No, Grandstream does not provide connections to emergency services via HT801 V2. Additional arrangements should be made to access emergency services.

## Q: How can I access the GNU GPL license terms?

A: The GNU GPL license terms are accessible through the Web user interface of the device or by contacting Grandstream Networks.

## **Product Usage Instructions**

#### 1. Power ON

Connect the 5V power adapter to the device and power socket. The Power LED should illuminate.

#### 2. FXS LED

This LED indicates the status of the FXS port. Ensure it is properly connected and functioning.

#### 3. NET LED:

The NET LED indicates the status of the NET port. Verify proper connection and activity.

#### 4. Reset:

To reset the device, locate the Reset button or option and follow the manufacturer's instructions.

# 5. Micro-USB Power Socket (5V):


Use the Micro-USB power socket with the provided 5V adapter to power the device.

# **PACKAGE CONTENT**


• HT801 V2



• Ethernet Cable




• 5V power adapter




· Quick Installation Guide



HT801 V2 PORTS and LED indicators





- 1. Power ON LED
- 2. FXS LED
- 3. NET LED
- 4. NET port
- 5. Reset
- 6. Micro-USB power socket (5V)
- 7. FXS port
- The HT801 V2 is not pre-configured to support or make emergency calls to any type of hospital, law enforcement agency, medical care unit ("Emergency Service(s)") or any other kind of Emergency Service. You must make additional arrangements to access Emergency Services. It is your responsibility to pur-chase SIP-compliant Internet telephone service, properly configure the HT801 V2 to use that service, and periodically test your configuration to confirm that it works as you expect. It is also your respon-sibility to purchase traditional wireless or landline telephone services to access Emergency Services.
- GRANDSTREAM DOES NOT PROVIDE CONNECTIONS TO EMERGENCY SERVICES VIA THE HT801 V2.
   NEITHER GRANDSTREAM NOR ITS OFFICES, EMPLOYEES OR AFFILIATES MAY BE HELD LIABLE FOR
  ANY CLAIM, DAMAGE, OR LOSS, AND YOU HEREBY WAIVE ANY AND ALL SUCH CLAIMS OR CAUSES
  OF ACTION ARISING FROM OR RELATING TO YOUR INABILITY TO USE THE HT801 V2 TO CONTACT
  EMERGENCY SERVICES, AND YOUR FAILURE TO MAKE ADDITIONAL ARRANGEMENTS TO ACCESS
  EMERGENCY SERVICES IN ACCORDANCE WITH THE IMMEDIATELY PRECEDING PARAGRAPH.
- The GNU GPL license terms are incorporated into the device firmware and can be accessed via the Web user interface of the device at my\_device\_ip/gpl\_license. It can also be accessed here: https://www.grandstream.com/legal/open-source-software
- To obtain a CD with GPL source code information please submit a written request to <a href="mailto:info@grandstream.com">info@grandstream.com</a>

#### **PRECAUTIONS**

- Please DO NOT power cycle the HT801 V2 during system boot up or firmware upgrade. You may corrupt firmware images and cause the unit to malfunction.
- Use only the power adapter included in the HT801 V2 package. Using an alternative non-qualified power adapter may possibly damage the unit.

# **EU Regulatory Information**

Hereby, [Grandstream Networks, Inc.] declares that the radio equipment type [HT801 V2] is in compliance with Directive 2014/30/EU&Directive 2001/95/EC.

The full text of the EU declaration of conformity is available at the following internet address: <a href="http://www.grandstream.com">http://www.grandstream.com</a>

#### **Grandstream Networks, Inc.**

126 Brookline Ave, 3rd Floor Boston, MA 02215. USA Tel:+1 (617) 566 – 9300 www.grandstream.com

#### **EU Agent:**

Picus Advisors Ltd Taivalmaki 9F1-02200 Espoo, FINLAND https://www.picus.fi

Note: For European Union only



For Certification, Warranty and RMA information, please visit <a href="www.grandstream.com">www.grandstream.com</a>

# **Documents / Resources**



GRANDSTREAM HT801 V2 Analog Telephone Adapter [pdf] Installation Guide HT801 V2 Analog Telephone Adapter, HT801 V2, Analog Telephone Adapter, Telephone Adapter, Adapter

#### References

- © Grandstream Networks Networking & Unified Communications
- U Home | Picus
- User Manual

# Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.