



# Gulikit NS26 Goku Wireless Controller Adapter Instructions

[Home](#) » [GuliKit](#) » Gulikit NS26 Goku Wireless Controller Adapter Instructions 

## Contents

- [1 Gulikit NS26 Goku Wireless Controller Adapter](#)
- [2 Product Information](#)
  - [2.1 Key Features:](#)
- [3 Product Usage Instructions](#)
  - [3.1 Getting Started](#)
  - [3.2 Basic Navigation](#)
  - [3.3 Wireless Connectivity](#)
  - [3.4 Battery Management](#)
  - [3.5 Application Usage](#)
- [4 Troubleshooting](#)
- [5 Use on Windows PC](#)
  - [5.1 Controller Button Mapping on PC](#)
- [6 Use on Xbox One, Xbox Series X, Xbox Series S consoles](#)
  - [6.1 Controller Button Mapping on Xbox](#)
- [7 Use on PS4 console:](#)
  - [7.1 Controller Button Mapping on PS4](#)
- [8 Use on Switch](#)
  - [8.1 Controller Button Mapping on Switch](#)
- [9 FCC Warning Statement](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)



**Gulikit NS26 Goku Wireless Controller Adapter**



## Product Information

The product is a versatile electronic device designed to simplify your daily tasks. It combines multiple functions to enhance productivity and convenience.

### Key Features:

- High-resolution touchscreen display
- Wireless connectivity options
- Long-lasting battery life
- Intuitive user interface
- Wide range of pre-installed applications

## Product Usage Instructions

### Getting Started

1. Unbox the product and remove all packaging materials.
2. Connect the device to a power source using the provided charger.
3. Press and hold the power button until the device powers on.

### Basic Navigation

1. Use your finger or the stylus to interact with the touchscreen display.
2. Tap on icons or menu items to open applications or access various features.
3. Swipe left or right to navigate between screens or menus.

## Wireless Connectivity

1. Go to the device settings to connect to a Wi-Fi network.
2. Enable Bluetooth in the settings menu to pair the device with compatible devices.

## Battery Management

1. Charge the device fully before initial use for optimal battery performance.
2. To conserve battery life, adjust the screen brightness and disable unnecessary background processes.

## Application Usage

1. Explore the pre-installed applications by tapping on their icons.
2. Install additional applications from the app store to expand the device's functionality.
3. Use the device's camera, messaging, and productivity apps to capture moments, communicate, and get work done.

## Troubleshooting

If you encounter any issues with the device, consult the troubleshooting section in the user manual or contact our customer support for assistance.


## Use on Windows PC

1. Plug GuliKit wireless controller adapter into USB A port on your computer.  
(It is better to use USB A port on back panel if it is desktop computer.)
2. Hold the pairing button to turn into pairing mode with flashing led.
3. Set GuliKit controller to "windows-X" mode, hold the pairing button to turn it into pairing mode with flowing led.


\* Ways of setting pairing mode on other controllers

The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.

**Note:**The adapter supports auto pairing to your controller on the PC next time even when you switch back from other consoles.




### Switch Pro controller pairing guide



Pairing button, Holding 2 seconds to have scrolling  
Led for pairing.


### Xbox controller pairing guide




Pairing button, Holding 2 seconds to have scrolling  
Led for pairing.


### PS4 controller pairing guide

Turn controller power off, hold Share and PS buttons to set into pairing mode with flashing led.




### Controller Button Mapping on PC





### Use on Xbox One, Xbox Series X, Xbox Series S consoles


1. Use a cable to connect your original Xbox controller to GuliKit adapter. (Micro USB to USB A cable for Xbox One controller, USB C to USB A cable for Xbox Series X/S controller.)(cable is not included.)
  2. Next plug the adapter into USB A port on your console.
- Note:** Do not reverse step 1 and step 2.
3. Hold the pairing button on adapter to turn into pairing mode with flashing led.
  4. Set GuliKit controller to "windows-X" mode,hold the pairing button to turn it into pairing mode with flowing led.
- \* Ways of setting pairing mode on other controllers The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.



**Note:**

- Do not unplug your original controller off the adapter, or your controller can not work.
- The adapter supports auto pairing to your controller on this console next time even when you switch back from other consoles.

**Controller Button Mapping on Xbox**




### Use on PS4 console:

1. Use a Micro USB to USB cable (not included) to connect your original PS4 controller Dualshock to GuliKit adapter.
  2. Next plug the adapter into USB A port on PS4 console.  
**Note:** Do not reverse step 1 and step 2.
  3. Hold the pairing button on adapter to turn into pairing mode with flashing led.
  4. Set GuliKit controller to "windows-X" mode, hold the pairing button to turn it into pairing mode with flowing led.
- \* Ways of setting pairing mode on other controllers. The adapter gets paired to controller when leds are steady





on. Then you are good to use the controller.



**Note:**


- Do not unplug your original controller off the adapter, or your controller can not work.
- The adapter supports auto pairing to your controller on this console next time even when you switch back from other consoles.

**Controller Button Mapping on PS4**



## Use on Switch


1. Plug GuliKit controller adapter into the USB port on Switch dock.
  2. Press and hold the pairing button on the adapter until you see flashing LED to get the adapter into pairing mode.
  3. Turn your controller into pairing mode and get paired to the adapter.
- \* Ways of setting pairing mode on other controllers. The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.



**Note:**

- Do not unplug your original controller off the adapter, or your controller can not work.
- The adapter supports auto pairing to your controller on this console next time even when you switch back from other consoles.

**Controller Button Mapping on Switch**



## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

**Operation is subject to the following two conditions:**

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### IC warning:

This device contains licence-exempt transmitters)/receiver(s) that comply with Innovation Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- this device may not cause interference and
- this device must accept any interference, including interference that may cause undesired operation of the device.


#### Radiation Exposure:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment; To maintain compliance with IC's F Exposure guidelines, This equipment should be. installed and operated with minimum distance of 5mm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

#### Documents / Resources



**GuliKit**



**GuliKit Goku Wireless Controller Adapter**  
Instructions

NS25



**Use on Windows PC:**

1. Plug GuliKit wireless controller adapter into USB A port on your computer. (It is better to use USB A port on back panel if it is desktop computer.)
2. Hold the pairing button to turn into pairing mode with flashing red.
3. Set GuliKit controller to "windows" mode hold the pairing button to turn it into pairing mode with flashing red.

**\* Ways of pairing/pairing mode on other controllers:**  
The adapter gets paired to controller when both are already on. Then you are good to use the controller.


**Note:** The adapter supports auto pairing to your controller on the PC first time even when you switch back from other consoles.

**Switch Pro controller pairing guide:**



Pairing button (holding 2 seconds to have something led to pairing)


**Xbox controller pairing guide:**




Pairing button (holding 2 seconds to have something led to pairing)


**PS4 controller pairing guide:**


Turn controller power off, hold Share and PS buttons to set reset pairing mode with flashing led.



**Controller Button Mapping on PC:**







**Use on Xbox One, Xbox Series X, Xbox Series S consoles:**

1. Use a cable to connect your original Xbox controller to GuliKit adapter.

(Micro USB to USB A cable for Xbox One controller, USB C to USB A cable for Xbox Series X/S)

- Xbox controller (cable is not included.)
1. Plug the adapter into USB port on your console.
  2. Hold the pairing button on adapter to turn into pairing mode with flashing led.
  3. Set Gulikit controller to "Windows X" mode, hold the pairing button to turn into pairing mode with flowing led.

\* Ways of setting pairing mode on other controllers

The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.

- Note:
1. Do not unplug your original controller off the adapter, or your controller can not work.
  2. The adapter supports auto pairing to your controller on the console next time even when you switch back from other consoles.

Controller Button Mapping on Xbox:



#### Use on PS4 console:

1. Use a Micro USB to USB-A cable (not included) to connect your original PS4 controller Dashboard to Gulikit adapter.
  2. Next plug the adapter into USB A port on PS4 console.
- Note: Do not reverse step 1 and step 2.
3. Hold the pairing button on adapter to turn into pairing mode with flashing led.
  4. Set Gulikit controller to "Windows X" mode, hold the pairing button to turn it into pairing mode with flowing led.

\* Ways of setting pairing mode on other controllers

The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.

- Note:
1. Do not unplug your original controller off the adapter, or your controller can not work.
  2. The adapter supports auto pairing to your controller on the console next time even when you switch back from other consoles.

Controller Button Mapping on PS4:



#### Use on Switch:

1. Plug Gulikit controller adapter into the USB port on Switch dock.
2. Press and hold the pairing button on the adapter until you see flashing LED to get the adapter into pairing mode.
3. Turn your Switcher into pairing mode and get paired to the adapter.

\* Ways of setting pairing mode on other controllers

The adapter gets paired to controller when leds are steady on. Then you are good to use the controller.

- Note:
1. Do not unplug your original controller off the adapter, or your controller can not work.
  2. The adapter supports auto pairing to your controller on the console next time even when you switch back from other consoles.

Controller Button Mapping on Switch:



© 2019 Gulikit. All rights reserved. Gulikit is a registered trademark of Gulikit. All other trademarks are the property of their respective owners.

## Gulikit NS26 Goku Wireless Controller Adapter [pdf] Instructions

2AQNP-NS26, 2AQNPNS26, NS26, NS26 Goku Wireless Controller Adapter, Goku Wireless C ontroller Adapter, Wireless Controller Adapter, Controller Adapter, Adapter