



HAGiBiS U3 Bluetooth Receiver User Manual

[Home](#) » [HAGiBiS](#) » HAGiBiS U3 Bluetooth Receiver User Manual 

HAGiBiS

User Manual
Bluetooth Receiver

Contents

- [1 Product Introduction](#)
- [2 Product specification](#)
- [3 Features](#)
- [4 Installation Guide](#)
- [5 Connection Guide](#)
- [6 Product Diagram](#)
- [7 FAQ](#)
- [8 Package Content](#)
- [9 FCC WARNING](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)

Product Introduction

This product is a Bluetooth receiver, power supply, and audio output as one. The shell is made of alloy material, it can provide Bluetooth function for speakers and cars without Bluetooth function, audio from mobile devices such as mobile phones and tablets can be transmitted to

Product specification

Name	Bluetooth receiver	BT Version	5.0
SN R	92dB	Frequency	20Hz – 22KHz
Power supply	5V/1A	range	lom
Temperature	-1050°C	Humidity	–.90%

Features

- Bluetooth 5.0 Version
- Active Noise Cancelling Chip
- High Sensitivity Microphone
- Creative small device

Installation Guide


1. Connect the USB power supply port of the product to the charger and power on automatically.
2. Connect the 3.5mm audio jack to your speaker or car via AUX port.

Connection Guide

1. The BT receiver will automatically enter pairing mode once power on.
2. Open the Bluetooth function on your mobile phone or tablet and click search.
3. Click HAGiBiS U3 once appear and enter “0000” if required.
4. The BT receiver will automatically re-connect next time once power is on.

Note: The pairing mode lasts only 3 minutes. After 3 minutes, the LED lights will enter the slow flash standby mode. If you need to enter the pairing mode, please restart the product after power failure.

Product Diagram



FAQ

Q. How much power is needed?

A: Please use a 5V/1A power supply. If the current is too high, the equipment may be damaged.

Q. Will there be an electric current sound?

A: This will happen to a few users. Current noise is usually caused by the power supply, and different vehicle noise will be different. If it occurs, it can be avoided by following settings.

1. Turn the car down and the mobile phone up.
2. Try to use the car with its own USB power supply or mobile power supply, do not use the cigarette lighter car charging, because the cigarette lighter is the engine power supply, the current is unstable.

Package Content

- BT receiver
- User Manual
- Warranty Card

Operation Demo Video and Artificial
Customer Service

Please scan below QR Code Service WeChat



<http://weixin.qq.com/r/Szm9pUXEyxi0rQH92xZ>

Email: support@hagibis.com

Website: <http://www.hagibis.com>

Hotline 400-820-6093 Working days from 9:00 AM to 6:00 PM

FCC WARNING


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, This equipment should be installed and operated with a minimum distance of 20cm the radiator your body: Use only the supplied antenna.

Documents / Resources



[HAGiBiS U3 Bluetooth Receiver](#) [pdf] User Manual

U3, 2AS3L-U3, 2AS3LU3, U3 Bluetooth Receiver, Bluetooth Receiver, Receiver