



HAGOOD RF Wireless Remote LED Controller Instructions

[Home](#) » [HAGOOD](#) » HAGOOD RF Wireless Remote LED Controller Instructions 



RF Wireless Remote LED Controller Instructions



RF Wireless Remote
LED Controller

Contents

- [1 Instructions](#)
- [2 Functions](#)
- [3 Installing](#)
- [4 Specification](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Instructions

- | | |
|---|---|
| <ul style="list-style-type: none">• Dimmer & Dynamic• 8 Dynamic Effects• 10-Level Dimmer• 256-Grade PWM• Speed Adjustable | <ul style="list-style-type: none">• Card Type Remote• Ultra Slim Design• Smooth Dimmer Effect• 1 to 1 Remote Paired• Auto Save Function |
|---|---|

1. Turn On/ Standby

Press this key to turn on the unit or switch to standby mode. The unit will turn on and restore to its previous status at powering the moment.

2. Lighting mode

Switch to lighting mode from dynamic mode.

3/8/9. Dimmer Adjust Shortcuts

Switch to 100%, 50%, or 25% brightness lighting mode.

4/6. Dynamic Mode Adjust

Switch to dynamic mode from lighting mode or switch between different dynamic modes.


5/7. Speed Adjust

Adjust the playing speed of dynamic modes. Press SPEED+ to increase speed and press SPEED- to decrease.

10/11. Brightness Adjust (Dimmer)

Adjust lighting mode brightness. Press BRIGHT+ to increase brightness and press BRIGHT- to decrease.

Functions



Installing

1. Power Supply This unit accepts DC12V to 24V power supply. The red cable should be connected to the positive and the black cable to the negative. Please select the proper power supply according to the LED application.
2. LED Output The red cable should be connected to an LED positive and the black cable to the negative. The peak output current is 6 A, please reduce the load if the main unit is overheating.

CAUTION! Do not short circuit the LED output, this may lead to permanent damage!



3. Remote Control! Please pull out the insulating part before using it. The RF wireless remote signal can pass through a barrier, so it's not necessary to aim at the main unit when operating. For proper receiving of the remote signal, do not install the main unit in closed metal parts. The remote battery is a 3V CR2025 type, please only replace it with the same type battery.

Specification

Dynamic mode	8 modes
Dynamic speed level	10 levels
Lighting brightness level	10 levels
PWM grade	256 grades
Smooth dimmer effect	Yes
Working voltage	DC12-24V
Output current	peak 6A
Remote control! mode	RF Wireless
Remote frequency	433.92MHz
Remote distance	> 3 am at an open area

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equip-ment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Documents / Resources

	HAGOOD RF Wireless Remote LED Controller [pdf] Instructions CRISETEK22A, 2A62R-CRISETEK22A, 2A62RCRISETEK22A, RF Wireless, Remote LED Co ntroller, RF, Wireless Remote LED Controller, RF Wireless Remote LED Controller
---	---

[Manuals+](#).