



HAISEN UFSRC UFS Sensor Remote Instruction Manual


[Home](#) » [HAISEN](#) » HAISEN UFSRC UFS Sensor Remote Instruction Manual 

HAISEN[®]

Contents

- [1 HAISEN UFSRC UFS Sensor Remote Instruction Manual](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)


HAISEN UFSRC UFS Sensor Remote Instruction Manual



Remote Brand: Haisen

Remote Model: HD03R

Remote Range (m): Distance of 15m (max)



Memory & Apply Mode

1. Press "ON/OFF button" to turn on the light or off.
2. To reset the parameters, Please follow the steps as below:
Step 1 – Press ON, to turn on the light if it was off at the start.
Step 2 – Press "Start" to the well-setting sensor.
Step 3 – Press the button of Detection range, Hold time, Stand-by dimming level, Stand-by period and Daylight threshold one after the other in sequence.
Step 4 – Press "Memory" to memorize the settings.
Note: The interval of each parameter setting shall be controlled within 30s
3. To programme other lights in the array that have similar sensors to the same programme.
Step 1 – Press "ON" to the second sensor
Step 2 – Press "Apply"

Isolated Setting Mode


1. Press "ON/OFF button" to turn on the light or off. Press "Auto Mode", the remote will activate settings that were saved last or remain at the factory default settings.
2. To reset the parameters, Please follow the steps as below:
Step 1 – Press ON, to turn on the light if it was off at the start.
Step 2 – Press any button of "Auto Mode", "Reset", "Test" and "Apply" to begin the sensor detection mode.
Step 3 – Press the button of Detection range, Hold time, Stand-by dimming level, Stand-by period and Daylight threshold one after the other in sequence.

Notes:

1. Settings will be saved automatically and remain until you press reset again.
2. Light will flicker when setting each parameter.

Read More About This Manual & Download PDF:

Documents / Resources



[HAISEN UFSRC UFS Sensor Remote](#) [pdf] Instruction Manual

UFSRC, HD03R, UFS Sensor Remote, UFSRC UFS Sensor Remote, Sensor Remote, Remote