Manuals+

HALO HAFH-RF Static Fixed Height Return Frame Instruction Manual

September 26, 2025

HAFH-RF Static Fixed Height Return Frame

"

Specifications:

- Product Name: Halo Static Return Frame
- Model Variants: HAFH-RF, HAFH-SF
- Components Included:
    - Table feet x1
    - Column x1
    - Bolt: M6x12 x2
    - Screw: ST4x20 x13
    - Side brackets x1
    - Rubber pad x10
    - Top frame-1 x1
    - Bolt: M6x10 x3
    - Centre bracket x1
    - Center rails x2
    - Top frame-2 x1
    - Hand bolts M6x10 x2
    - Allen Wrench(4mm) x1
    - Allen Wrench(5mm) x1
    - Cable tie x2

Product Usage Instructions:

Assembly Instructions:

Step 1: Loosen the pre-installed bolts and
adjust the length of the top frame to match the size of the table
top.

Step 2: Insert the Column into the top frame
and fix it with 4 screws M6x12.

Step 3: Place the table feet on the column,
align, and tighten the bolt.

Step 4: Place the side bracket on the top frame

and tighten the bolts.

Step 5: Connect the return frame to the single
workstation, fix it with 2 hand bolts, and fix the center brackets
with screws M6x10.

Step 6: Mount the tabletop and fix it with
screws ST4x20. Fix the center bracket with screws M6x10.

Cable Tray Installation:

Step 1: Fix the cable tray to the cable tray
arms with screws M6x10.

Step 2: Install the U brackets to the desk
frame with screws M8x10. Mount the cable tray to the desk frame and
fix it with screws M6x10.

Screen Panel Installation (Shush30 Privacy Screen):

Step 1: Insert the tapped plates to the screen
panel.

Step 2: Install the screen brackets to the
Shush30 Extrusion with screws M5x6.

Step 3: Fix the screen brackets to the desk
frame with screws M6x10.

Eco Panel Screen Panel Installation:

Step 1: Install the screen brackets on the
cable tray arm with screws M6x10.

Step 2: Place the EPS panel on the screen

brackets and secure using double-ended bolts M5*32mm through the holes created in the Eco Panel Screen.

Frequently Asked Questions (FAQ):

Q: How many components are included in the Halo Static Return Frame?

A: The Halo Static Return Frame includes various components such as table feet, columns, bolts, screws, side brackets, rubber pads, top frames, hand bolts, Allen wrenches, and cable ties.

Q: How do I install the cable tray on the desk frame?

A: To install the cable tray, first fix it to the cable tray arms using provided screws M6x10. Then, attach U brackets to the desk frame with screws M8x10 and mount the cable tray, securing it with screws M6x10.

Q: What is required for installing the Eco Panel Screen?

A: Installing the Eco Panel Screen requires screen brackets, double-ended bolts, a drill bit (not included), and a suitable Allen key for tightening.

"`

[View Fullscreen](#)

Halo Static Return Frame Instruction Manual

Halo Static Fixed Height Return Frame (HAFH-RF)

Halo Static Single Sided Fixed Height Workstation Frame (HAFH-SF)

1

Component parts

NO. Component Name

PCS

NO. Component Name

PCS

1

Table feet

1

9

Centre bracket

1

2

Column

1

10 Center rails

2

3

Bolt: M6x12

2

11 Top frame-2

1

4

Screw:ST4x20

13

12 Hand bolts M6x10

2

5

Side brackets

1

13 Allen Wrench(4mm)

1

6

Rubber pad

10

14 Allen Wrench(5mm)

1

7

Top frame-1

1

15 Cable tie

2

8

Bolt: M6x10

3

2

Assembly Instructions

Step 1 Loosen the pre-installed bolts and Adjust the length of the top frame to match the size of the table top.

Step 2 Inset the Column to the top frame,fix column with 4pcs screws M6x12 like.

3

Step 3

Place the table feet on the column and rotate it and make it align, then tighten the pre-installed bolt.

Step 4 Place the side bracket on the top frame and tighten the bolts.

4

Step 5 Connect the return frame to the single workstation and fixed with 2 hand bolts. Fix the centre brackets with 2pcs screws M6x10.

Step 6 Mount the tabletop and fix it with24 pcs screws ST4x20; Fix the centre bracket with 2 pcs screws M6x10

5

Cable tray installation Step 1 – Fix the cable tray(B2-SSCT) to the cable tray arms(HP-SSARM) with 8 pcs M6x10 screws.

Step 2 – Install the U brackets to the desk frame with 4 pcs M8x10 screws. – Mount the cable tray to the desk frame and fix it with 6 pcs M6x10 screws

6

Screen panel installation (Shush30 Privacy Screen) Step 1 – Insert the tapped plates to the screen panel (plates can be found in B2-SBRAC carton)

Step 2 – Install the screen brackets (B2-SBRAC)to the Shush30 Extrusion with 8 pcs

M5x6 screws.

7

Step 3 – Fix the screen brackets (B2-SBRAC) to the desk frame with 10 pcs M6x10 screws.

8

EPS (900mm H Eco Panel) Screen panel installation Step 1 – Install the screen brackets(B2-SBRAC) on the cable tray arm (B2-SSARM)with 10 PCS M6x10 Screws The brackets direction as photos display.

Step 2 – Place the EPS panel on the screen brackets Using a 6mm drill bit (not included), drill out holes in Eco Panel Screen in line with back to back screen bracket holes (Note: Carbide Drill Bits Work Best For PET panel) – Place 8 x Double Ended Bolts M5* 32mm – 6mm through The screen bracket (B2-SBRAC) holes and the holes you have created in the Eco Panel Screen. Tighten double ended bolt with Allen key.

9

Documents / Resources

	[HALO HAFH-RF Static Fixed Height Return Frame](#) [[pdf](#)] Instruction Manual HAFH-RF, HAFH-RF Static Fixed Height Return Frame, Static Fixed Height Return Frame, Fixed Height Return Frame, Height Return Frame

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz **Search**