



## hama 00182502 Bluetooth Keyboard with Bag Instruction Manual

[Home](#) » [Hama](#) » hama 00182502 Bluetooth Keyboard with Bag Instruction Manual 

### Contents


- 1 hama 00182502 Bluetooth Keyboard with Bag
- 2 Operating Instructions
  - 2.1 Controls and Displays
- 3 Package Contents
- 4 Safety Notes
- 5 System requirements
- 6 Getting Started
- 7 Operation
  - 7.1 Bluetooth® pairing
  - 7.2 Multimedia keys
- 8 Care and Maintenance
- 9 Warranty Disclaimer
- 10 Service and Support
- 11 Technical Data
- 12 Recycling Information
- 13 Declaration of Conformity
- 14 Documents / Resources
- 15 Related Posts

# ***hama***

**hama 00182502 Bluetooth Keyboard with Bag**



## Operating Instructions



### Controls and Displays

#### A: Indicator and control panel

1. Connect button
2. OFF/ON switch
3. Caps Lock status LED
4. Bluetooth ® status LED
5. Charge indicator status LED
6. Power status LED

#### B Charging unit

7. Micro-USB socket

Thank you for choosing Hama product. Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner. If you sell the device, please pass these operating instructions on to the new owner.

## Package Contents

- 'KEY4ALL X3100' Bluetooth ® keyboard with tablet case
- Micro-USB charging cable
- These operating instructions

## Safety Notes

- The product is intended for private, non-commercial use only.
- Protect the product from dirt, moisture and overheating, and only use it in a dry environment.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not use the product in moist environments and avoid splashes.
- Do not drop the product and do not expose it to any major shocks
- Never apply force when using the product or during installation.
- Since the battery is integrated and cannot be removed, you will need to dispose of the product as a whole. Do this in compliance with the legal requirements.
- Dispose of packaging material immediately according to locally applicable regulations.
- Do not modify the product in any way. Doing so voids the warranty.
- Do not throw the battery or the product into fire.
- Do not tamper with or damage/heat/disassemble the batteries/rechargeable batteries.

## System requirements

The Bluetooth ® keyboard is suitable for use with all iOS, Android and Windows tablet PCs. Check whether the latest software version is installed and, if necessary, perform a software update.

### Note

- To ensure that the keyboard functions properly, check that the right keyboard layout (QWERTZ, QWERTY etc.) is set in your device settings.
- Note that support for certain key functions may vary depending on your device.
- If some keys on the Bluetooth keyboard do not work properly on your device for software reasons, you can run them via the virtual keyboard.
- Please refer to the operating instructions for the device you are using.

## Getting Started

### Warning

- Only use suitable charging devices or USB connections for charging.
- As a rule, do not charge devices or USB connections that are defective and do not try to repair them yourself.
- Do not overcharge the product or allow the battery to completely discharge.
- Avoid storing, charging or using the device in extreme temperatures and extremely low atmospheric pressure (for example, at high altitudes).
- When stored over a long period of time, batteries should be charged regularly (at least every three months).

- Only charge the batteries at temperatures between 10°C -40°C.
- The USB cable included in the box is only suitable to charge this product. It's not suitable for data transfer or charging of other USB devices.
- Charge the battery of the Bluetooth® keyboard fully before using it for the first time.
- Begin charging the Bluetooth® keyboard by connecting the included Micro-USB charging cable to the Micro-USB socket of the keyboard(7) and to the USB connection of a PC/notebook.
- Alternatively, you can charge the Bluetooth® keyboard using a suitable USB charger. Please refer to the operating instructions for the USB charger used.
- The charge indicator status LED (5) will be lit red during active charging. If the battery is fully charged, the charge indicator status LED (5) will go out.
- If the battery capacity is low, the power status LED (6) will begin to flash blue during operation. In this case, charge the battery of the Bluetooth® keyboard as described above.

### **Note –Stand function**

- For optimal handling, fasten your device in the tablet case and use the integrated stand function.
- To do this, fold back the flap of the tablet case and attach it using the magnet (C).
- Carefully fasten your tablet PC to the holder using the rubber straps. Choose the appropriate straps for holding your tablet PC securely in place.
- To remove the tablet PC, carefully pull off each of the straps from the corners of your tablet PC.

### **Operation**

- The functions described in this section are only available for Bluetooth®-capable terminal devices.
- Note that the maximum range for Bluetooth® is 10 metres without obstacles such as walls, people, etc.

### **Bluetooth® pairing**

- Make sure that your Bluetooth®-capable terminal device is on and Bluetooth® is activated.
- Make sure that your Bluetooth®-capable terminal device is visible for other Bluetooth® devices.
- For more information, please refer to the operating instructions of your terminal device.
- Slide the OFF/ON switch (2) to the ON position to switch on the Bluetooth® keyboard. The power status LED (6) lights up.
- Press and hold the Connect button (1) until the Bluetooth® status LED (4) begins to continually flash blue. The keyboard is searching for a Bluetooth® connection.
- Open the Bluetooth® settings on your terminal device and wait until Hama KEY4ALL X3100 appears in the list of Bluetooth® devices found.
- Select Hama KEY4ALL X3100 and enter the numeric code specified on your device using the Bluetooth® keyboard. Press the Enter key to confirm and wait until the keyboard is shown as connected in the Bluetooth® settings on your terminal device. The Bluetooth® status LED (4) goes out.
- You can now use the Bluetooth® keyboard.

### **Automatic Bluetooth® connection (after successful pairing)**

- Make sure that your Bluetooth®-capable terminal device is on and Bluetooth® is activated.
- Make sure that your Bluetooth®-capable terminal device is visible for other Bluetooth® devices.
- For more information, please refer to the operating instructions of your terminal device.
- Slide the OFF/ON switch (2) to the ON position to switch on the Bluetooth® keyboard. The power status LED (6) lights up.
- Press and hold the Connect button (1) until the Bluetooth® status LED (4) begins to continually flash blue. The keyboard is searching for a Bluetooth® connection.
- Open the Bluetooth® settings on your terminal device and wait until Hama KEY4ALL X3100 appears in the list of Bluetooth® devices found.
- Select Hama KEY4ALL X3100.
- You can now use the Bluetooth® keyboard.














### **Note –Connection impaired**

After the devices have been paired once, the connection is then established automatically. If the Bluetooth® connection is not established automatically, check the following:

- Check the Bluetooth® settings of your terminal device to see whether Hama KEY4ALL X3100 is connected. If not, repeat the steps listed under 6.1 Bluetooth® pairing.
- Check whether obstacles are impairing the range. If so, move the devices closer together.

### **Multimedia keys**

The multimedia keys give you direct access to various applications and functions. The functions marked in blue on the keyboard are activated by pressing the Fn key and the key in question.

Key symbol	Function
	Android: Start screen, iOS: Start screen, Windows: Microsoft Edge (Internet)
	Search
	Select all
	Copy
	Insert
	Cut
	Previous track
	Start / Pause
Key symbol	Function
	Next track
	Decrease volume
	Increase volume
	Android: Back, iOS: N/A, Windows: N/A
	Lock
<b>Delete</b>	Delete

### Standby and switch off

- If you do not use the keyboard for longer than 10 minutes, it will automatically switch to standby mode
- Press any button to reactivate the keyboard.
- Slide the OFF/ON switch (2) to the OFF position to switch off the Bluetooth ® keyboard.

### Care and Maintenance

- Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning agents.
- Make sure that water does not get into the product.

## Warranty Disclaimer

Hama GmbH & Co. KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

## Service and Support

Please contact Hama Product Consulting if you have any questions about this product. Hotline: +49 9091 502-0 (German/English) Further support information can be found here: [www.hama.com](http://www.hama.com)

## Technical Data

Bluetooth® version	3.0
Range	max. 10 m
Dimensions (L xWx H)	26.0 x 20.5 x 1.8 cm
Number of keys	64
Current consumption	5V 230 mA
Battery type	3.7 V Li-Po
Typ. capacity	185 mAh / 0.68 Wh
Operating systems	Android, iOS, Windows

## Recycling Information

### Note on environmental protection:

After the implementation of the European Directive 2012/19/EU and 2006/66/EU in the national legal system, the following applies: Electric and electronic devices, as well as batteries, must not be disposed of with household waste. Consumers are obliged by law to return electrical and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined



by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices/Batteries, you are making an important contribution to protecting our environment.


## Declaration of Conformity

Hereby,Hama GmbH &CoKG declares that the radio equipment type [00182502] is in compliance with Directive 2014/53/EU.The full text of the EU declaration of conformity is available at the following internet address:

[www.hama.com](http://www.hama.com)

-> 00182502 -> Downloads.

## Documents / Resources

	<p><a href="#">hama 00182502 Bluetooth Keyboard with Bag</a> [pdf] Instruction Manual</p> <p>00182502, Bluetooth Keyboard with Bag</p>
---	--

Manuals+.