




hama 00186399 Clock Instruction Manual

[Home](#) » [Hama](#) » hama 00186399 Clock Instruction Manual 



00 186399
Wall Clock “Vintage Color”
Wanduhr



Operating Instructions

Contents

- [1 Explanation of Warning Symbols and Notes](#)
- [2 Package Contents](#)
- [3 Safety Notes](#)
- [4 Getting Started](#)
- [5 Installation](#)
- [6 Operation](#)
- [7 Care and Maintenance](#)
- [8 Warranty Disclaimer](#)
- [9 Technical Data](#)
- [10 Recycling Information](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

Explanation of Warning Symbols and Notes



Warning

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



Note

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.

Package Contents

- 1 Wall clock
- 1 AA battery
- These operating instructions

Safety Notes

- Protect the product from dirt, moisture, and overheating, and only use it in a dry environment.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not drop the product and do not expose it to any major shocks.
- Do not modify the product in any way. Doing so voids the warranty.
- Keep the packaging material out of the reach of children due to the risk of suffocation.
- Dispose of packaging material immediately according to locally applicable regulations.
- The product is intended for private, non-commercial use only.
- Use the product for its intended purpose only.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Do not operate the product outside the power limits given in the specifications.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Keep this product, as all electrical products, out of the reach of children!
- Use the item only in moderate climatic conditions.



Warning Batteries

- When inserting batteries, note the correct polarity (+ and – markings) and insert the batteries accordingly. Failure to do so could result in the batteries leaking or exploding.
- Only use batteries (or rechargeable batteries) that match the specified type.
- Before you insert the batteries, clean the battery contacts and the polar contacts.
- Do not allow children to change batteries without supervision.
- Do not mix old and new batteries or batteries of a different type or make.
- Remove the batteries from products that are not being used for an extended period (unless these are being kept ready for an emergency).
- Do not short-circuit batteries.
- Do not charge batteries.
- Do not throw batteries in a fire.
- Keep batteries out of the reach of children.
- Never open, damage or swallow batteries or allow them to enter the environment. They can contain toxic, environmentally harmful heavy metals.
- Immediately remove and dispose of dead batteries from the product.
- Avoid storing, charging or using batteries in extreme temperatures.

Getting Started

1. Inserting the battery

Remove the safety film if necessary as well as the contact breaker and insert the batteries with the correct polarity. The clock is ready for operation.

2. Replacing the battery

- Remove and dispose of any used batteries. Insert the new battery (AA).
- Ensure that the polarity of the battery corresponds to the symbols in the battery compartment.

Installation

You can mount the wall clock on a wall using the opening on the back.



Warning Mounting Note

- Before mounting the clock, ensure that the chosen wall is suitable for the weight to be mounted, and make sure that there are no electrical wires, water, gas or other lines at the installation site on the wall.
- Purchase special fastening materials from specialised dealers.
- Do not mount the product above locations where persons might linger.

Operation

- Once the battery has been inserted properly, the clock will automatically start running.

- Use the setting wheel on the back of the clock to set the time.

Care and Maintenance

Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning agents. Make sure that water does not get into the product.

Warranty Disclaimer

Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

Technical Data



Wall clock

Power supply	1.5 V 1xAAbattery
--------------	----------------------

Recycling Information

Note on environmental protection:



After the implementation of the European Directive 2012/19/EU and 2006/66/EU in the national legal system, the following applies: Electric and electronic devices as well as batteries must not be disposed of with household waste. Consumers are obliged by law to return electrical and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilising old devices/Batteries, you are making an important contribution to protecting our environment.

hama®

Hama GmbH & Co KG
86652 Monheim / Germany
Service & Support



www.hama.com




+49 9091 502-0 DG



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

00186399 / 10.20



hama
THE POWER OF DESIGN

Wall Clock
Energy Class

00186399

hama 00186399 Clock [pdf] Instruction Manual
00186399, Clock