



## **hama 00223498 LED Night Light with Socket 2 USB Outputs Motion and Light Sensor Instruction Manual**

[Home](#) » [Hama](#) » hama 00223498 LED Night Light with Socket 2 USB Outputs Motion and Light Sensor Instruction Manual 

# ***hama***

**LED Night Light with Socket 2  
USB Outputs Motion and Light Sensor  
Instruction Manual**



## Contents

- [1 Operating instruction](#)
- [2 Package Contents](#)
- [3 Safety Notes](#)
- [4 Operation](#)
- [5 Care and Maintenance](#)
- [6 Technical specifications](#)
- [7 Warranty Disclaimer](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

## Operating instruction

Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference.

### Explanation of Warning Symbols and Notes



#### **Risk of electric shock**

This symbol indicates product parts energized with a dangerous voltage of sufficient magnitude to constitute a risk of electric shock.



#### **Warning**

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



#### **Note**

This symbol is used to indicate additional information or important notes.

## Package Contents

- 1 Night Light
- These operating instructions

## Safety Notes

- The product is intended for private, noncommercial use only.
- Protect the product from dirt, moisture and overheating and use it in dry rooms only.
- Do not drop the product and do not expose it to any major shocks.
- Do not operate the product outside the power limits given in the specifications.
- Do not modify the device in any way. Doing so voids the warranty.
- Do not continue to operate the device if it becomes visibly damaged.
- Use the product for its intended purpose only.
- Keep this product, as all electrical products, out of the reach of children!
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Lay all cables so that they do not pose a tripping hazard.
- Do not bend or crush the cable.
- Always pull directly on the plug when disconnecting the cable, never on the cable itself.
- Dispose of packaging material immediately according to locally applicable regulations.

- The product is intended for indoor use only.
- Use the item only in moderate climatic conditions.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not use the product in moist environments and avoid splashes.
- Never connect multiple units of this product in a series.
- The product may only be operated with the type of power supply network described on the nameplate.
- This product is not suitable for lighting rooms in domestic households.



#### **Risk of electric shock**

- Do not open the device or continue to operate it if it becomes damaged.
- Do not use the product if the AC adapter, adapter cable, or power cable is damaged.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.



#### **Note**

- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced!

### **Operation**

- The night light has a brightness and motion sensor. When motion in the dark is detected, the night light automatically switches on. Conversely, the night light switches off when it gets light.
- After activation, the night light is lit for about 30 seconds.



#### **Warning – Connecting terminal devices**

- Before connecting a terminal device, check whether the power output of the charger can supply sufficient power for the device.
- Please refer to the instructions in the operating manual of your terminal device.



#### **Warning**

- Only connect the product to a socket that has been approved for the device. The socket must be installed close to the product and easily accessible.



#### **Warning**

- When using a multi-socket power strip, make sure that the sum power draw of all the connected devices does not exceed its maximum throughput rating.
- If you will not be using the product for a long period of time, disconnect it from mains power.

Unless the operating instructions for the devices you want to charge explicitly inform you otherwise, proceed as follows:

- Connect your terminal device to a USB charging socket using a suitable USB cable.
- Connect the charger to a properly installed and easily accessible power socket.
- Charging progress is displayed on your terminal device.
- Disconnect the terminal device from the charger if you want to interrupt charging or if the terminal device is fully charged.
- Then disconnect the charger from the mains.
- When charging batteries built into a device, pay attention to the maximum charging time for the batteries.

## Care and Maintenance

Only use dry, soft cloths for cleaning.



### Note

Disconnect the device from the power supply before cleaning or if it will not be used for a long period of time.

## Technical specifications

### Specifications in accordance with Regulation (EU) 2019/1782

Manufacturer's name or trademark, commercial registration number, and address	Hama, HRA
Model identifier	00223498
Input voltage	230 V
input AC frequency	50 Hz
Output voltage / Output current / Output power	5.0 V DC/ 2.
Efficiency at low load (10 %)	80.4 %
Efficiency at low load (10 %)	75.7 %
No-load power consumption	0.09 W

## Warranty Disclaimer

Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

# ***hama***

Hama GmbH & Co KG  
86652 Monheim / Germany  
**Service & Support**  
[www.hama.com](http://www.hama.com)  
+49 9091 502-0



Raccolta Carta

**Manuals+,**