



HANSEN PHP18DJT Wireless Microphone User Manual

[Home](#) » [HANSEN](#) » HANSEN PHP18DJT Wireless Microphone User Manual 

HANSEN

WIRELESS
MICROPHONE
PHP18DJT



USER MANUAL

Product Name Speaker with wireless microphone
Model: PHP18DJT
Power: 1.5V*2 AA

Frequency Range:407.5MHz-607.7MHz
Channel 3

How to Use

Install the two batteries into the battery slot and cover the back shell. Push the switch up to turn on the microphone, the indicator light is on.
Turned on the speaker, the microphone, and the speaker are automatically connected and can be used normally.
After using the microphone, push down the switch to turn it off.


Caution

- 1. If you don't use the microphone for a long time, you need to remove the batteries.
- 2. Keep the microphone away from the fire.
- 3. Do not immerse the microphone in water.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources

	HANSEN PHP18DJT Wireless Microphone [pdf] User Manual PHP18DJT, 2AQ8HPPHP18DJT, PHP18DJT, Wireless Microphone
---	--