



HAVIT Lightning HV3276T-BLK-12V Virsma Step Light Instruction Manual



[Home](#) » [HAVIT LIGHTNING](#) » HAVIT Lightning HV3276T-BLK-12V Virsma Step Light Instruction Manual 



Virsma Step Light Installation
Instruction Manual



| Product Specifications | | |
|------------------------|----------------------------------|-----------------|
| Model No. | HV3276T-BLK-12V | HV3276T-WHT-12V |
| Name | Virisma | |
| Material | Aluminum | |
| Colour | Black | White |
| IP Rating | IP54 | |
| Input Voltage | 12v DC | |
| Lamp Base | Built-in LED | |
| Lamp Wattage | 1x 4w | |
| Colour Temp | TRI Colour – 3000k, 4000k, 5500k | |
| Lumens | 110lm, 115lm, 120lm | |
| CRI | > 80 | |
| Wiring | Parallel | |
| Dimmable | No | |
| Warranty | 2 Years Replacement* | |

| Dimensions | Mounting Base Diagram |
|---|--|
|  |  |

Contents

[1 Important Safety Issues:](#)

[2 Steps for Installation:](#)

[3 Documents / Resources](#)

[3.1 References](#)

[4 Related Posts](#)

Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Do not exceed maximum wattage restrictions for globes: 240V GU10 = 35w / 12V MR16 = 20w
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of the voltage required and cannot be installed more than 25m from LED Driver, if not within this allowance warranty will be voided.
- Aluminum and 304SS fittings must not be installed within 2km of any saltwater environments.
- When installing copper fittings, gloves must be worn to avoid any oils transferring to the fitting.
- All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on the fitting. (Warranty does not cover Tea Staining)
- All o-rings and seals must be in place correctly to maintain the warranty.
- These instructions may be updated at any time due to product improvements, Please visit the website for the most current installation instructions.

Steps for Installation:

1. Make sure that the electrical circuit is free of voltage (master switch off)
2. Loosen Allen screws on side of the fitting and remove the face and set it aside.
3. Install the base plate to the wall in the desired location
4. Use an appropriate 12v DC LED Driver – DO NOT CONNECT LIGHT FITTING DIRECTLY TO 240V
5. Connect the cable – If more than one fitting is installed, wiring must be done in parallel.
6. Fitting is preset to 3000k, to change the slide switch to desired color temperature
7. Reattach face to base plate making sure Allen screws are tight to avoid water penetration
8. Apply silicon around the edge of the fitting to prevent any water from getting inside to electrical connections.
9. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Additional Information



HV3276T-BLK-12V

<https://havit.com.au/collections/all/products/hv3276t-wht-virsma-white-square-led-step-lights>





HV3276T-WHT-12V

<https://havit.com.au/collections/all/products/hv3276t-wht-virsma-white-square-led-step-lights-1>

Virisma Step Light Installation Instructions

Product Specifications

| | | |
|---------------|----------------------------------|------------------|
| Model No. | HV3276T-BLK-240V | HV3276T-WHT-240V |
| Name | Virisma | |
| Material | Aluminium | |
| Colour | Black | White |
| IP Rating | IP54 | |
| Input Voltage | 240v AC | |
| Lamp Base | Built in LED | |
| Lamp Wattage | 1x 4w | |
| Colour Temp | TRI Colour – 3000k, 4000k, 5500k | |
| Lumens | 110lm, 115lm, 120lm | |
| CRI | > 80 | |
| Wiring | Parallel | |
| Dimmable | No | |
| Warranty | 2 Years Replacement* | |

| Dimensions | Mounting Base Diagram |
|---|---|
|  |  |

Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of the voltage required, if not within this allowance warranty will be voided.
- Aluminum and 304SS fittings must not be installed within 2km of any saltwater environments.
- When installing copper fittings, gloves must be worn to avoid any oils transferring to the fitting.
- All 316 & 304 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on the fitting. (Warranty does not cover Tea Staining)
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check the online installation form for the most current version.

Steps for Installation:

1. Make sure that the electrical circuit is free of voltage (master switch off)

2. Loosen Allen screws on side of the fitting and remove the face and set it aside.
3. Install base plate to the wall in the desired location
4. Connect the cable – use wire with earth; connect the earth first, then live and neutral wire
5. Fitting is preset to 3000k, to change the slide switch to desired color temperature.
6. Reattach face to base plate making sure Allen screws are tight to avoid water penetration
7. Apply silicon around the edge of the fitting to prevent any water from getting inside to electrical connections.
8. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Warranty Terms & Conditions*



<https://havit.com.au/pages/warranty-terms-and-conditions>

Additional Information



HV3276T-BLK-240V

<https://havit.com.au/collections/all/products/hv3276t-wht-virsma-white-square-led-step-lights>



HV3276T-WHT-240V


<https://havit.com.au/collections/all/products/hv3276t-wht-virsma-white-square-led-step-lights-1>

Contact Details:

143 Beauchamp Road
Matraville NSW 2036
Australia

Tel: 02 9381 8300
Fax: 02 9666 8881
Email: sales@havit.com.au
Web: www.havit.com.au

Documents / Resources



[HAVIT Lightning HV3276T-BLK-12V Virsma Step Light](#) [pdf] Instruction Manual
HV3276T-BLK-12V, HV3276T-WHT-12V, HV3276T-BLK-12V Virsma Step Light, HV3276T-BLK-12V, Virsma Step Light, Step Light, Light

References

-  [Havit Lighting](#)

Manuals+.