




homematic IP HmIP-PS-2 Pluggable Switch Instruction Manual

[Home](#) » [Homematic IP](#) » homematic IP HmIP-PS-2 Pluggable Switch Instruction Manual 

homematic HmIP-PS-2 Pluggable Switch Instruction Manual



**Pluggable Switch
HmIP-PS-2**
Installation and operating manual 

Contents

- 1 Package contents
- 2 Hinweise zur Anleitung
- 3 Hazard information
- 4 Function and device overview
- 5 General system information
- 6 Start-up
- 7 Operation
- 8 Behaviour after power recovery
- 9 Troubleshooting
- 10 Restore factory settings
- 11 Maintenance and cleaning
- 12 General information about radio operation
- 13 Disposal
- 14 Technical specifications
- 15 Documents / Resources
 - 15.1 References

Package contents

1x Home Matic IP Pluggable Switch
1x Operating manual

Hinweise zur Anleitung

Please read this manual carefully before beginning operation with your Homematic IP components. Keep the manual so you can refer to it at a later date if you need to. If you hand over the device to other persons for use, please hand over the operating manual as well.

Symbols used:



Attention!

This indicates a hazard.



Note.

This section contains important additional information!

Hazard information



We do not assume any liability for damage to property or personal injury caused by improper use or the failure to observe the hazard information. In such cases, any claim under warranty is extinguished! For consequential damages, we assume no liability!



Do not open the device. It does not contain any parts that can be maintained by the user. There is a risk of electric shock if the device is opened. In the event of an error, please have the device checked by an expert. Do not use the device if there are signs of damage to the housing, control elements or connecting sockets, for example, or if it demonstrates a malfunction. If you have any doubts, have the device checked by an expert.



For safety and licensing reasons (CE), unauthorized change and/or modification of the device is not permitted.



The device may only be operated indoors and must be protected from the effects of moisture, vibrations, solar or other methods of heat radiation, cold and mechanical loads.



The device is not a toy; do not allow children to play with it. Do not leave packaging material lying around, plastic films/bags, pieces of polystyrene etc., can be dangerous in the hands of a child.



Please take the technical data (in particular the maximum permissible switching capacity of the relay and the type of load to be connected) into account before connecting a load! All load data relates to ohmic loads! Do not exceed the capacity specified for the device. Exceeding this capacity could lead to the destruction of the device, to a fire or to an electrical accident.



The device may only be connected to an easily accessible power socket outlet. In case of danger, disconnect the device from the power socket outlet.



Only use the device with properly installed wall outlets with earth contacts and not with multiple socket outlets or extension cables.



Do not connect devices to the pluggable switch which could cause fire or other types of damage in unattended operation (e.g. irons).



Remove the plug of the connected device from the switch, whenever you make changes or modifications to the device.



Always lay cables in such a way that they do not become a risk to people and domestic animals.



The device has not been designed to support safety disconnection. The load is not isolated from the mains. Voltage-free only when the plug is pulled out!



Before cleaning the device, unplug it from the socket outlet. Use a dry linen cloth to clean the device. If the device is particularly dirty, you can slightly dampen the cloth to clean it. Do not use any detergents containing solvents for cleaning purposes. Make sure that no moisture will ingress into the housing.



Using the device for any purpose other than that described in this operating manual does not fall within the scope of intended use and shall invalidate any warranty or liability. This also applies to any conversion or modification work. The device is intended for private use only.



Do not connect multiple pluggable switches into one another.



Devices with electronic power supply units (e.g. TV or high voltage LED light sources) are not ohmic loads. They can generate inrush currents with more than 100 A. Switching such kind of loads may lead to premature wear of the actuator.



The device may only be operated within residential buildings.

Function and device overview


With the Homematic IP Pluggable Switch you can comfortably switch on and off connected loads via the Homematic IP app or directly from the device.

The pluggable switch is connected quickly and without any tools. Simply plug in the device to a socket and it is immediately ready for use. Thanks to the compact design, the pluggable switch does not block the surrounding sockets.

Geräteübersicht:

(A) System button (pairing, switching connected loads on and off, LED)

(B) Pluggable switch





General system information

This device is part of the Homematic IP smart home system and works with the Homematic IP radio protocol. All devices of the system can be configured comfortably and individually with the Homematic IP smartphone app. Alternatively, you can operate the Homematic IP devices via the Central Control Unit CCU3 or in connection with various partner solutions. The available functions provided by the system in combination with other components are described in the Homematic IP User Guide. All current technical documents and updates are provided at www.homematic-ip.com.


Start-up

6.1 Installation and pairing


-  Please read this entire section before starting the pairing procedure.
-  First set up your Homematic IP Access Point via the Homematic IP app to enable operation of other Homematic IP devices within your system. For further information, please refer to the operating manual of the Access Point.


To integrate the pluggable switch into your system and enable it to communicate with other Homematic IP devices, you must pair the device to your Homematic IP Access Point first. To pair the pluggable switch, please proceed as follows:

- Open the Homematic IP app on your smartphone.
- Select the menu item “Pair device”.
- Plug in the switch into the desired socket.



- Pairing mode remains activated for 3 minutes.

 You can manually start the pairing mode for another 3 minutes by pressing the system button (A) shortly.




- Your device will automatically appear in the Homematic IP app.
- To confirm, please enter the last four digits of the device number (SGTIN) in your app or scan the QR code. Therefore, please see the sticker supplied or attached to the device.
- Please wait until pairing is completed.
- If pairing was successful, the LED (A) lights up green.
- If the LED lights up red, please try again.
- Select the desired solution for your device.
- In the app, give the device a name and allocate it to a room.

After pairing, loads such as electric heaters can be easily connected to the pluggable switch. Connected loads can

then be switched on and off.

Operation

After pairing and installing have been performed, simple operations are available directly on the device. Press the system button (A) shortly to switch on and off connected loads.

 Improper usage or a defective installation (e.g. low-quality or defective plugs or sockets) can lead to overheating of the pluggable switch. The integrated temperature control automatically switches off the load. The device is protected against overheating and secure operation is ensured. As soon as the temperature reaches a non-critical value, you can switch on the pluggable switch again. Always observe the permitted ambient temperature of the device and, if necessary, have the installation checked for possible error sources by an expert.

Behaviour after power recovery

After the device has been inserted to a socket or after power recovery the pluggable switch performs a self-test/restart (approx. 2 seconds). The device LED (A) flashes orange and green briefly (LED test display). The LED will flash if an

error is detected during this test (see „9.4 Error codes and flashing sequences“ on page 20). This is repeated continuously and the device does not perform its function. If the test is completed without errors, the device transmits a wireless telegram containing its status information.

Troubleshooting

9.1 Command not confirmed


If at least one receiver does not confirm a command, the device LED (A) lights up red at the end of the failed transmission process. The failed transmission may be caused by radio interference (see „12 General information about radio operation“ on page 21). This may be caused by the following:

- Receiver cannot be reached.
- Receiver is unable to execute the command (load failure, mechanical blockade, etc.).
- Receiver is defective.

9.2 Duty Cycle

The duty cycle is a legally regulated limit of the transmission time of devices in the 868 MHz range. The aim of this regulation is to safeguard the operation of all devices working in the 868 MHz range. In the 868 MHz frequency range we use, the maximum transmission time of any device is 1% of an hour (i.e. 36 seconds in an hour). Devices must cease transmission when they reach the 1% limit until this time restriction comes to an end. Homematic IP devices are designed and produced with 100% conformity to this regulation. During normal operation, the duty cycle is not usually reached. However, repeated and radio-intensive pairing processes mean that it may be reached in isolated instances during start-up or initial installation of a system. If the duty cycle is exceeded, this is indicated by one long lighting of the device LED (A), and may manifest itself in the device temporarily working incorrectly. The device starts working correctly again after a short period (max. 1 hour).

9.3 Automatic disconnection in case of overload

 If the device is overloaded with load currents greater than 13 A or with loads with more than 3 kW power, after a short delay time, this leads to the device's automatic disconnection. The safety disconnection is reported with an error message via the app or WebUI.

To be able to use the device again, you must remove the overload and unplug the device once from the socket then plug it back in again. Alternatively, you can wait 30 minutes after removing the overload (“restart lock”). The device can then be switched on again. The device is not automatically switched on after the restart lock has expired.

9.4 Error codes and flashing sequences

Flashing code	Meaning	Solution
Short orange flashing	Radio transmission/att- emptying to transmit	Please wait, until trans-mission has been confirmed.
1x long green lighting	Transmission confirmed	You can continue operation.
1x long red lighting	Transmission failed	Please try again (see „9.1 Command not confirmed” on page 19).
Short orange flashing (every 10 seconds)	Pairing mode active numbers of the device	Please enter the last four number to confirm (see „6.1 Installation and pairing” on page 17).
1x long red lighting	Duty cycle exceeded or transmission failed	Please try again (see „9.1 Command not confirmed” on page 19) or (see „9.2 Duty Cycle” on page 19).
6x long red flashing	Device defective	Please see your app for error message or contact your retailer.
1x orange and 1 x green lighting (after plugging into a socket)	Test display	Once the test display has stopped, you can continue.

Restore factory settings

The factory settings of the device can be restored. If you do this, you will lose all your settings. To restore the factory settings of the pluggable switch, please proceed as follows:

- Unplug the device from the socket (→ see figure).
- Plug in the device into the socket again while pressing and holding down the system button (A) for 4s at the same time, until the LED (A) will quickly start flashing orange (see figure).
- Release the system button again.
- Press and hold down the system button again for 4s, until the status LED lights up green.
- Release the system button to finish the procedure.
- The device will perform a restart.

Maintenance and cleaning



The product does not require you to carry out any maintenance. Enlist the help of an expert to carry out any repairs.

Clean the product using a soft, lint free cloth that is clean and dry. You may dampen the cloth a little with lukewarm water in order to remove more stubborn marks. Do not use any detergents containing solvents, as they could corrode the plastic housing and label.

General information about radio operation

Radio transmission is performed on a non-exclusive transmission path, which means that there is a possibility of interference occurring. Interference can also be caused by switching operations, electrical motors or defective electrical devices.



The range of transmission within buildings can differ greatly from that available in the open air. Besides the transmitting power and the reception characteristics of the receiver, environmental factors such as humidity in the vicinity have an important role to play, as do on-site structural/screening conditions.

Hereby, eQ-3 AG, Mai burger Str. 29, 26789 Leer/Germany declares that the radio equipment type Homematic IP HmIP-PS-2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.homematic-ip.com

Disposal

Instructions for disposal



This symbol means that the device must not be disposed of as household waste, general waste, or in a yellow bin or a yellow sack. For the protection of health and the environment, you must take the product and all electronic parts included in the scope of delivery to a municipal collection point for old electrical and electronic equipment to ensure their correct disposal. Distributors of electrical and electronic equipment must also take back obsolete equipment free of charge. By disposing of it separately, you are making a valuable contribution to the reuse, recycling and other methods of recovery of old devices. Please also remember that you, the end user, are responsible for deleting personal data on any old electrical and electronic equipment before disposing of it.








Information about conformity

The CE mark is a free trademark that is intended exclusively for the authorities and does not imply any assurance of properties.

For technical support, please contact your retailer.

Technical specifications

Device short description:	HmIP-PS-2
Supply voltage:	230 V/50 Hz
Current consumption:	13 A max.
Standby power consumption:	< 0.2 W
Max. switching capacity:	3 kW
Kind of load:	ohmic load
Life expectancy relay/ switching cycle:	40000 (13 A, ohmic load)
Relay:	NO contact, 1-pole, μ contact
Switch type:	independently mounted switch
Operating mode:	S1
Withstand voltage:	2500 V
Protection class:	I
Method of operation:	Type 1
Degree of protection:	IP20
Ambient temperature:	-10 to +35 °C
Degree of pollution:	2
Dimensions (W x H x D):	70 x 70 x 39 mm (not incl. mains plug)
Weight:	154 g
Radio frequency band:	868.0-868.6 MHz 869.4-869.65 MHz
Maximum radiated power:	10 dBm
Receiver category:	SRD category 2
Typ. open area RF range:	400 m
Duty cycle:	< 1 % per h/< 10 % per h

Load type		Relay
Ohmic load		13 A
Incandescent lamp load		1500 W
Self-ballasted lamps (LED/compact fluorescent lamp)		200 W
HV halogen lamps		1500 W
Electronic transformers for NV halogen lamps		1500 W
Iron core transformers for NV halogen lamps		1500 W
Fluorescent lamps (uncompensated)		1500 W
Fluorescent lamps (parallel compensated)		1500 W
Electric radiators and other electric heating systems (ohmic load)		8 A (200.000 switching cycles)
Motor load		2,2 A

Subject to technical changes.

Kostenloser Download der

Homematic IP App!

Free download of the

Homematic IP app!



homematic

Manufacturer's authorised representative:


eQ-3 AG

Mai burger Straße 29

26789 Leer / GERMANY

www.eQ-3.de

Documents / Resources

	<p>homematic IP HmIP-PS-2 Pluggable Switch [pdf] Instruction Manual HmIP-PS-2 Pluggable Switch, HmIP-PS-2, Pluggable Switch, Switch</p>
---	---

References

- [IP Home page | Homematic IP](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.