



HOMEZIE S14 String Light User Manual

[Home](#) » [HOMEZIE](#) » HOMEZIE S14 String Light User Manual 

Contents

- 1 HOMEZIE S14 String Light
- 2 INCLUDED IN THE PACKAGING
- 3 SPECIFICATIONS
- 4 DIMMER CONTROL
- 5 INSTALLATION INSTRUCTIONS
- 6 REMOTE CONTROL
- 7 DISPOSAL INSTRUCTIONS
- 8 MAINTENANCE AND USAGE
- 9 FCC DECLARATION FOR DIMMER CONTROL
- 10 Frequently Asked Questions (FAQ):
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts



HOMEZIE S14 String Light



INCLUDED IN THE PACKAGING

- 1x String light with S14 LED bulbs
- Spare bulb(s)
- 1x User manual

Thank you for purchasing the Homezie String Light. This manual contains essential information for the installation, use, and maintenance of your string light. Please read the manual carefully before starting. Keep the manual for future reference.

SPECIFICATIONS


- Power per bulb 0.7 W
- Waterproof rating IP65
- Input voltage 220V ~ 240V, 50/60Hz
- Lamp type S14 LED
- Socket type 2 pin

DIMMER CONTROL

- Waterproof rating IP65
- Maximum power 200 W
- Input voltage 220V~240V,50/60Hz
- Control distance 10 meter

INSTALLATION INSTRUCTIONS



1. Install the string light in the desired location.
- 2.



If you have purchased a dimmer: Follow step 3.


If you have not connected a dimmer:

Step 2. Plug the power cord into the outlet. The lights will turn on. Follow step 3 if you have also purchased a dim kit. Refer to the dim kit manual for use.



3. Connect the dim kit to the string light. Then plug the power cord into the outlet. Insert 2 AAA batteries into the remote control. You can now use the remote control to operate the string light.

REMOTE CONTROL



Tip: Press and hold + / - to increase or decrease the brightness.

WARNINGS

1. RISK OF ELECTRIC SHOCK IF BULBS ARE BROKEN OR MISSING. DO NOT USE.
2. Do not connect the string light to power while it is still in the packaging.
3. Do not remove or install bulbs while the string light is connected to power.
4. Ensure all bulb sockets are fitted with a bulb.
5. Replace defective bulbs immediately with bulbs of the same type as supplied or specified by the manufacturer.
6. Do not repair, disassemble, or modify the product without approval.
7. Keep bulbs away from heat sources.
8. Do not connect parts of this string light with parts of a string light from another manufacturer.
9. Connections should only be made using the supplied connectors. Open ends must be sealed before use.
10. The bulbs are made of plastic; handle with care when hanging.
11. The dim kit works only with AC 220V.
12. Before using the remote control for the first time, ensure the battery is correctly installed.
13. Disconnect the string light from the power supply before installing the bulbs.
14. Do not turn on the lights if the socket is damaged.
15. Do not overload sockets or string lights. The maximum operating power is 200W.
16. Keep the bulbs out of the reach of children.
17. Ensure the bulbs remain dry and clean.
18. Do not hang objects on the lights, as additional weight may break the string and pose a fire hazard.
19. Although our lights are equipped with safety features, we do not recommend leaving the lights unattended or continuously turned on.

20. Unplug the lights when not in use. Turn off the power before installing the string light.

DISPOSAL INSTRUCTIONS



Disposal of Electrical and Electronic Equipment (WEEE)

This symbol means that the product must not be disposed of with household waste. Instead, recycle it at an authorised WEEE collection point. Proper disposal helps protect the environment and recover valuable materials. Contact your local authorities for recycling information.

MAINTENANCE AND USAGE

1. Inspect the string light regularly

Before each use, check the cord, bulbs, and plug for any damage, such as cracks, loose connections, or broken bulbs. Do not use the string light if visible damage is present.

2. Clean the string light carefully

Turn off the string light and unplug it from the power outlet before cleaning. Use a dry or slightly damp cloth to remove dust and dirt. Do not use harsh cleaning agents or water, as this may damage the electrical components.

3. Use the string light only as recommended

Do not use the string light in damp environments and follow all instructions provided in the manual.

4. Avoid overloading

Ensure the string light is connected to a power source that provides the correct voltage and current. Overloading may cause short circuits or damage to the cord. Avoid using overloaded extension cords or adapters.

5. Replace defective bulbs immediately

Replace defective bulbs only with bulbs of the same type and wattage. This prevents overheating and damage to the string light.

6. Store the string light properly

Store the string light in a dry and cool place when not in use.

Prevent the cord from tangling or being subjected to tension by neatly rolling it up and protecting it from heavy objects.

FCC DECLARATION FOR DIMMER CONTROL

Use is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note:

The dimmer control has been tested and complies with the limits for a Class B digital device, as specified in Part

15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, it may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.



Imported by:

info@homezie.co

Frequently Asked Questions (FAQ):

- **Q: How many spare bulbs are included?**

A: The packaging includes spare bulb(s) along with the string light and user manual.


- **Q: Can I use a different type of bulb in the string light?**

A: It is recommended to replace defective bulbs with the same type as provided or as specified by the manufacturer for safety and performance reasons.

- **Q: What should I do if the string light malfunctions?**

A: If you encounter any issues with the string light, refer to the user manual for troubleshooting steps. If problems persist, contact customer support for assistance.

Documents / Resources

	HOMEZIE S14 String Light [pdf] User Manual ASS14, S14 String Light, S14, String Light, Light
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.