




Honeywell 2 Speed Oscillating Table Fan Instruction Manual

[Home](#) » [Honeywell](#) » Honeywell 2 Speed Oscillating Table Fan Instruction Manual 

Honeywell 2 Speed Oscillating Table Fan



HT-109E
28W




Fig. 1



Fig. 2




Fig. 3

IMPORTANT SAFETY INSTRUCTIONS

1. Please read all instructions before using this fan.
2. Only use this fan as described in this manual. Other non-recommended use may cause fire, electric shock, or injury.
3. Only connect the fan to a single-phase power socket with the current as stated on its type plate.
4. Connect power after the fan has been fully assembled. Unplug from outlet when moving fan from one location to another, before putting on or taking off parts, and before cleaning. Disconnect the fan when not in use. Do not tug at the power cord to disconnect the plug.
5. Supervision is needed when the fan is used anywhere near children. This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely.

6. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent, or a similarly qualified person in order to avoid a hazard.
7. Unwind the power cord completely. An incompletely unwound power cord can lead to overheating and cause a fire. Do not touch the power cord with wet hands. Position the power cord so that nobody can trip over it and where the socket can be reached easily.
8. Do not use an infinitely variable speed controller. This can lead to overheating, fire, electric shock, or faults in the appliance.
9. Do not operate the fan without the protective front and rear grilles in position. Do not touch the rotating fan blades with any part of the body. This can cause personal injury and damage.
10. Never insert fingers, pencils, or any other object through the grille when the fan is running.
11. Do not operate the fan if it is damaged or might be defective, or if it is not working properly. Remove the power plug from the socket.
12. Do not use the fan anywhere near easily inflammable gases or substances such as solvents, lacquers, glues, etc.
13. The fan is only designed for private use in indoor rooms and is not intended for outdoor or for commercial use. Do not use the fan anywhere near a bathtub, a shower or a swimming pool, or anywhere else where water could splash.
14. Do not plunge the fan into water or any other liquids and do not pour water or any other liquids over the fan.
15. Place the fan on a firm, even, dry surface. Be sure the fan is on a stable surface when operating to avoid overturning. Make sure the fan is standing securely so that it cannot tip over or fall down. Maintain a safe distance of at least 50 cm from other objects.
16. Clean the fan regularly by following the cleaning instructions.

Contents

[1 COMPONENTS](#)

[2 ASSEMBLY INSTRUCTIONS](#)

[3 OPERATING INSTRUCTIONS](#)

[4 CLEANING AND STORAGE](#)

[4.1 Storage](#)

[5 Documents / Resources](#)

[6 Related Posts](#)

COMPONENTS

1. Front Grille
2. Spinner
3. Blades
4. Plastic Nut
5. Rear Grille
6. Motor Shaft
7. Speed Knob
8. Oscillating Clutch Knob
9. Motor Housing
10. Tilt Adjustment Knob

11. Power Supply Cord with Plug

12. Base

ASSEMBLY INSTRUCTIONS

Assembly of Blade and Guards

1. Unscrew the spinner clockwise and the nut counter-clockwise to separate them (Steps 1, 2, and 3 – Fig. 1).
2. Set the rearguard in the proper position with handle up.
3. Screw on plastic nut tightly to attach rear grille.
4. Discard plastic sleeve on the motor shaft. Install the blade onto the shaft until it reaches the retaining pin (Steps 4, and 5 – Fig. 2).
5. Screw spinner onto motor shaft counterclockwise to blade.
6. Press the front grille onto the rear grille until the front grille is properly fitted, fix both grilles with rim and use a screwdriver to tighten the locking screw.
7. Secure both grilles firmly by tightening the fan grille locking screws and nuts (Fig. 3).

OPERATING INSTRUCTIONS

Speed Knob

The speed of the fan is controlled by rotating the speed knob. The number on the knob will indicate which of the two speeds is in effect:

0 = Off; 1 = Low; 2 = High.

Oscillation

To make the fan oscillate, press down on the oscillating control knob located on the top of the motor housing. To stop oscillation, pull up on the knob.

Tilt Adjusting

To adjust the airflow upward or downward, loosen the screw, gently push the grilles (1,5) to the desired position and retighten the screw.

CLEANING AND STORAGE

Cleaning

1. Unplug the fan from the electricity supply.
2. Only use a soft cloth to gently wipe the fan clean.
3. DO NOT immerse the fan in water and never allow water to drip into the motor housing.
4. DO NOT use petrol, paint thinner, or other chemicals to clean the fan.
5. Dismantling for cleaning the fan is not recommended. Use a vacuum cleaner with a brush attachment to clean the grilles, followed by a soft damp cloth.

Storage

For storage, clean the fan carefully as instructed and store your fan in a cool dry place.

**Disposal:**

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

CONDITION OF PURCHASE

As a condition of purchase the purchaser assumes responsibility for the correct use and care of this KAZ product according to these user instructions.

WARNING: IF PROBLEMS ARISE WITH THIS KAZ PRODUCT, PLEASE OBSERVE THE INSTRUCTIONS IN THE WARRANTY CONDITIONS. DO NOT ATTEMPT TO OPEN OR REPAIR THE KAZ PRODUCT YOURSELF, AS THIS COULD LEAD TO TERMINATION OF THE WARRANTY AND CAUSE DAMAGE TO PERSONS AND PROPERTY.

Technical modifications reserved.

KAZ Europe SA,
Place Chauderon 18 (9th floor)
CH – 1003 Lausanne
Switzerland
Tel. +41 21 644 01 10
www.kaz-europe.com

Honeywell

The Honeywell trademark is used by Kaz, Inc. under license from Honeywell Intellectual Properties, Inc.

www.kaz-europe.com

HT-109E-OM//0//2007-01-09 31IM109E190

1/9/07 4:44:44 PM

Documents / Resources

[Honeywell 2 Speed Oscillating Table Fan](#) [pdf] Instruction Manual
2 Speed Oscillating Table Fan, HT-109E, 28W