



# Honeywell CS92A Wi-Fi Evohome Controller Instructions

[Home](#) » [Honeywell](#) » Honeywell CS92A Wi-Fi Evohome Controller Instructions 

## Contents

- [1 Honeywell CS92A Wi-Fi Evohome Controller](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Wireless connectivity Guide](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

# Honeywell

**Honeywell CS92A Wi-Fi Evohome Controller**



## Product Information

The CS92A is a transceiver used in conjunction with a master controller to establish a wireless connection for remote control operations. It is designed and manufactured by Automatikkentret, located at Strandvejen 42 Saksild 8300 Odder. For further information, you can visit their website [www.automatikkentret.dk](http://www.automatikkentret.dk) or contact them via email at [info@automatikkentret.dk](mailto:info@automatikkentret.dk). The CS92A transceiver is equipped with a green light indicator and a red light indicator.

## Product Usage Instructions

1. Put the CS92A into binding mode by pressing and holding the button for 5 seconds.
2. Observe the green light coming on and the red light flashing once every second.
3. For optimal signal reception, mount the transceiver in a location where there are no metal objects in a direct line between it and the master controller.

## Wireless connectivity Guide

### Wi-Fi evohome Controller (ATC928G3000)

Wireless Cylinder Thermostat (CS92)

To bind a Wireless Cylinder Thermostat (CS92) to a Wi-Fi evohome Controller (ATC928G3000) to control a hot water cylinder ...

### On the evohome Controller

- Press and hold O SETTINGS for 5 seconds

- Press the green tick Pd
- Press SYSTEM DEVICES
- Press STORED HOT WATER
- Press ENABLED
- Press HOT WATER SENSOR BINDING


On the Wireless Cylinder Thermostat G Press and hold the button for 5 seconds. The green light should come on and the red light should flash

- Press the button again

You should receive a SUCCESS message on the evohome Controller and the LED on the Wireless Cylinder Thermostat should stop blinking and turn OFF. If not, go back and re-bind.

Put CS92A into binding mode by pressing and holding the button for 5 seconds, until the green light comes on and the red light flashes once every second. For best signal reception, the transceiver should be mounted in a location where there are no metal objects in a direct line between it and the master controller.

## Documents / Resources

	<p><a href="#">Honeywell CS92A Wi-Fi Evohome Controller</a> [pdf] Instructions  CS92A Wi-Fi Evohome Controller, CS92A, Wi-Fi Evohome Controller, Evohome Controller, Controller</p>
---	---