Manuals+ — User Manuals Simplified.

Honeywell Flex Alert App User Guide

Contents

Honeywell

Honeywell Flex Alert App

Product Information

Flex Alert Quick-Start Guide

- Volume Down
- Volume Up

SET-UP INSTRUCTIONS

- Click this link to set up in the app or go to: **hwll.co/FlexAlertProvision**
- For additional questions, see our FAQ sheet at: **hwll.co/FlexAlertFAQ**

WI-FI NETWORK INFORMATION

MULTI-FUNCTION POWER BUTTON

- Power/Replay
- username and password (PEAP-MSCHAPv2)

WARNINGS
Only power the device using the provided 5 VDC AC/DC Adapter. Device contains battery. DO NOT leave device in a high temperature environment or subject it to low air pressure. Explosion or leakage of flammable liquid or gas could occur.

Contact Information

- Email: **USDDSALES@HONEYWELL.COM**
- Facebook: **FACEBOOK.COM/STATIONALERTING**
- Phone: 1-877-551-USDD
- Website: **STATIONALERTING.COM**

Specifications

- **Power Source:** 5 VDC AC/DC Adapter
- **Network Compatibility:** WI-FI
- **Security Protocol**: PEAP-MSCHAPv2

Setting up the Device

1. Download the app or visit hwll.co/FlexAlertProvision.
2. Follow the on-screen instructions to set up the device.

Powering On and Off
To power on the device, press the Power/Replay button. To power off, press and hold the same button until the device shuts down.

Adjusting Volume
To decrease the volume, press the Volume Down button. To increase the volume, press the Volume Up button.

Important Reminders

- Always use the provided 5 VDC AC/DC Adapter to power the device.
- Avoid exposing the device to high temperatures or low air pressure to prevent potential hazards.

FAQ

- **Can I use a different power adapter to charge the device?**

  It is recommended to only use the provided 5 VDC AC/DCB Adapter to power the device for safety and optimal performance.
- **How do I connect the device to a Wi-Fi network?**

  Follow the instructions in the app or visit hwll.co/FlexAlertProvision for detailed steps on connecting to a Wi-Fi network.
- **What should I do if the device gets exposed to extreme temperatures?**

  Remove the device from the high-temperature environment immediately and allow it to cool down before further use. Contact customer support if needed.

PRODUCT OVERVIEW

Volume Down

Volume Up

Power / Replay

SET-UP INSTRUCTIONS

- Click this link to set up in the app or go to: hwll.co/FlexAlertProvision
- For additional questions, see our FAQ sheet at: hwll.co/FlexAlertFAQ

WI-FI NETWORK INFORMATION

Supported Configurations:

- 2.4GHz networks
- Networks that don't require a password
- WPA2 Personal networks
- WPA2 Enterprise networks that require a username and password (PEAP-MSCHAPV2)

Unsupported Configurations:

- 5GHz Networks
- Networks that require a certificate and key to connect

MULTI-FUNCTION POWER BUTTON

- **Turn On –** Press the multi-function button once
- **Turn Off –** Press and hold the multi-function until the lights turn off (approximately 5 seconds)
- **Bluetooth Pairing Mode** – Press and hold the multi-function until you see rotating blue light (approximately 15 seconds)
- **Replay Alert** – While the device is on, press the multifunction button once.
  (Note: Flex Alert does not replay alerts that have been delivered before the device was most recently turned on.)

WARNINGS

- Only power the device using the provided 5 VDC AC/DC Adapter.
- Device contains battery. DO NOT leave device in a high temperature environment or subject it to low air pressure. Explosion or leakage of flammable liquid or gas could occur.

ABOUT COMPANY

- **USDDSALES@HONEYWELL.COM**
- **FACEBOOK.COM/STATIONALERTING**
- 1-877-551-USDD
- **STATIONALERTING.COM**

Documents / Resources

Honeywell Flex Alert App [pdf] User Guide
Flex Alert App, Flex, Alert App, App

References

- ⊕ **hwll.co/FlexAlertFAQ**
- ⊕ **hwll.co/FlexAlertProvision**
- **H** **Station Alerting | US Digital Designs | Honeywell Building Technologies**
- **User Manual**