

HOTACK
HOTACK L013 LED
Portable Game
Projector



HOTACK L013 LED Portable Game Projector User Manual

[Home](#) » [Hotack](#) » HOTACK L013 LED Portable Game Projector User Manual 

Contents

- [1 HOTACK L013 LED Portable Game Projector](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Safety Instructions](#)
- [5 Overview](#)
- [6 Cleaning Method](#)
- [7 FCC STATEMENT](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

HOTACK

HOTACK L013 LED Portable Game Projector



Specifications

- Weight: 157g
- Dimensions: 76x130mm

Product Information

The L013 is a compact and portable projector designed for home entertainment and presentations. It features various connectivity options, including HDMI and USB inputs, as well as Bluetooth capabilities. The projector supports media playback from external devices like U disks and offers settings for display, Bluetooth, system configurations, and more.

Safety Instructions

1. Do not expose the device to rain or moisture.
2. Avoid placing the device on soft surfaces that can pose a fire hazard.
3. Avoid areas with excessive dust, dirt, or strong magnetic fields.
4. Ensure proper ventilation to prevent overheating.
5. Keep the device away from direct sunlight, extreme temperatures, and overexposure to moisture.
6. Avoid confined spaces and provide adequate ventilation around the device.
7. Monitor heat buildup during extended use and allow the device to cool down when necessary.
8. Handle the device with care, avoid touching the lens, and supervise children's usage.
9. Use only manufacturer-specified attachments and accessories.
10. Avoid extreme vibration to prevent damage to internal components.

Product Usage Instructions

Getting Started

1. Plug the power cable into the projector.
2. Press the power button to turn on the projector.
3. Connect the projector to an HDMI port-supported device using an HDMI cable.

4. To turn off the projector, press the power button.

Cleaning Method

1. Prepare cleaning tools.
2. Use tweezers to pry off the bottom cover for access to the internal components.
3. Clean the projector using a cotton swab for delicate areas.
4. Reinstall the bottom cover after cleaning is complete.

Display Setting

Access the display settings by navigating to Setting – Display. Adjust image mode, color temperature, keystone correction, aspect ratio, and zoom level as needed.

Bluetooth Setting

To configure Bluetooth settings, go to Setting – Bluetooth. Turn on Bluetooth, search for devices, and pair with the desired device for connectivity.

Media Playback

In the homepage menu under Media, access media files such as movies, music, photos, and text from a U disk connected to the projector.

Wired Screen Sharing

In the homepage menu under Wired Screen, utilize the feature to share screens from Android and iOS devices by following the interface instructions.

Troubleshooting Tips

1. **Blurry Image:** Adjust keystone correction settings in Display or use Auto Keystone Correction. Press the focus button on the remote control for clarity.
2. **Mounting Hole:** The projector supports mounting on standard camera tripods and 1/4 inch screw projector tripod stands through its dual-use design with a single mounting hole.

FAQ

- **Q: How can I improve image clarity on the projector?**
 - A: Adjust keystone correction settings and use the focus button on the remote control for best clarity.

L013 User Manual

Safety Instructions


Read all instructions before you use this device. Do not make any changes or create settings that are not described in this manual. If physical damage, loss of data or damage is caused by failure to follow instructions, the warranty does not apply.

1. To reduce the risk of fire or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this device.
2. Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire


hazard.

3. Do not place this device in areas susceptible to excessive dust and dirt or near any appliance generating a strong magnetic field.
4. To prevent overheating, do not block or clog the ventilation holes.
5. Never place this device in a confined space. Always leave enough space around this device for ventilation.
6. Protect this device from overexposure to direct sunlight, heat, large temperature fluctuations and moisture. Avoid extreme temperatures.
7. When this device is running for a long period of time, the surface may become hot. Shut it down immediately and unplug the charger. Resume operation after this device has cooled down.
8. Always handle this device with care. Avoid touching the lens. Do not allow children to handle the device without supervision.
9. Use attachments or accessories specified by the manufacturer only.
10. Avoid extreme vibration as it may damage the internal components.


Package List




Projector × 1



Remote Control × 1
(Batteries are not included)




Power Cable × 1



HDMI Cable × 1




Projector User Manual × 1



Clean Tool × 1

Overview



Tips

1. Blurry Image


Go to Setting – Display – Keystone Correction – Turn on the Auto Keystone Correction or enter Manual Keystone to adjust the image.

Press the focus button on remote control to get the best clarity.

2. Mounting Hole


Adopting a single mounting hole dual-use design, the projector is compatible with the standard camera tripod and 1/4 inch screw projector tripod stand.

Remote Control




Getting Started


1. Plug the power cable to the projector.
2. Press power button to turn on the projector.



3. Connect projector to HDMI port support device.



4. Press the power button to turn off the projector.




Tips


Make sure the projector is horizontal to the projector screen.

Cleaning Method


1. Get cleaning tools ready.




2. Use tweezers to pry off the bottom cover.



3. Clean the projector by the cotton swab.




4. Reinstall the bottom cover after cleaning.




Display Setting

Setting – Display > Set image mode, color temperature, keystone correction, aspect ratio, zoom level.




System Setting

Setting – System > Set the OSD language, projection mode, homepage color, factory setting reset, software upgrade, auto sleep, OSD timer, video delay, version information.




Bluetooth Setting

Setting – Bluetooth > Turn on Bluetooth. Select search and pair the device that you want to connect to.



Wired Screen


Homepage – Wired Screen > Support Android and iOS device to share screen according to the interface tips.



Android Connect by Cables


1. Confirm to open HCCast in the pop-up window of your phone.
2. It can automatically be wired to the same screen.

Attention:
Avoid Frequent Plugging & Unplugging for a stable connection.
Certain Android models require selecting 'Transfer File' for screen mirroring.



iOS Connect by Cables

Connect your iPhone to the projector via the original iPhone charging cable. (Cable has a USB port and Lightning port)




Android device scanning

1. Scan the left QR code.
2. In the pop-up window of your phone, select View and Install App.

Please insert iOS and Android devices


Media

Homepage – Media > Enter the media to read the movie/music/photo/text from your U disk.



HDMI

Homepage – HDMI > Enter the HDMI signal source to display the video.



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ISED Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.


The digital apparatus complies with Canadian CAN ICES-3

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian Information on RF exposure and compliance.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

Documents / Resources

	HOTACK L013 LED Portable Game Projector [pdf] User Manual L013, L013 LED Portable Game Projector, LED Portable Game Projector, Portable Game Projector, Game Projector, Projector
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.