




HOTONE MIDI Foot Controller Pedal Bluetooth Ampero Control 4 Button Instructions

[Home](#) » [HOTONE](#) » HOTONE MIDI Foot Controller Pedal Bluetooth Ampero Control 4 Button Instructions 

HOTONE








www.hotoneaudio.com

Contents

- [1 Screen Display](#)
- [2 Getting Started](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Screen Display

Bluetooth	MIDI	Bank
 <p>Bluetooth not connected</p>	 <p>This indicates a PC message (PC 16) has been sent</p>	
 <p>Bluetooth connected</p>	 <p>This indicates a CC message (C 112) has been sent</p>	 <p>This indicates unit bank change (bank 00 to bank 01)</p>

The Bluetooth indicator (the dot shown above) will flash when Amparo Control is in Bluetooth Pair Mode (hold FS 2+3).

Getting Started

1. Turn on the Bluetooth switch on your mobile device, then turn on your Amparo Control and launch the app.
2. Login to your account (optional).
3. Press and hold FS 2+3 on your Amparo Control to enable Bluetooth Pair Mode. A dot will flash on the bottom right corner of the screen of your unit to indicate pairing status.
4. When your Amparo Control appears listed on the startup page, select and tap the “Connect To The Selected Device” button on the screen. If the search failed, you can retry searching by manually tapping the “Search Again” button.

Notes:

1. You can enter offline mode if no device is found.
2. Amparo Control can only be edited by one device at a time. To use other devices, tap the “Settings” icon on the lower right corner of the screen, find “Connection Status” and enter, then tap “Disconnect”. Connect another device when finished.
3. The default device name is Amparo Control. You can customize your device name if needed.




Thank you for purchasing a Hotone product. Scan the QR code for the full manual and app download links.



www.hotoneaudio.com/support

We recommend you update the latest firmware/software for the best possible experience.



FCC regulation warning (for USA)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna transmitter. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

FCC ID:2AHJSEC-4
157g
273*124mm

HOTONE

www.hotoneaudio.com

Documents / Resources

	HOTONE MIDI Foot Controller Pedal Bluetooth Ampero Control 4 Button [pdf] Instructions EC-4, EC4, 2AHJSEC-4, 2AHJSEC4, MIDI Foot Controller Pedal Bluetooth Ampero Control 4 Button, MIDI, Foot Controller Pedal Bluetooth Ampero Control 4 Button
---	---