

hp KB60 Bluetooth Keyboard Instructions

Home » HP » hp KB60 Bluetooth Keyboard Instructions



Contents

1 KB60 Bluetooth Keyboard

2 Documents / Resources

2.1 References

KB60 Bluetooth Keyboard



PRINTER: Replace this box with Printed- In (PI) Statement(s) as per spec.

NOTE: This box is simply a placeholder. PI Statement(s) do not have to fit inside the box but should be placed in

this area.

Color Side 1: BLACK Color Side 2: BLACK


Flat size: 31.5 x 27.5 in. (800.1 x 698.5 mm) Finished size: 5.25 x 5.5 in (133.35 x 139.7 mm)

Fold 1:




Fold 2: 5-panel accordion











Connect the keyboard to one computer using the receiver and up to two computers via Bluetooth®. To program the keyboard keys or set up your keyboard and mouse to easily switch between computers, use the software. If the software does not download automatically, on your computer, open Microsoft Store. Search for HP Accessory Center, and then download the app.

The keyboard offers limited support for macOS® and Chrome™ devices. To manually change the keyboard operating system, hold down the following keys for more than 3 seconds:

Windows®: FN +1macOS: FN + 2Chrome: FN + 3

Components description

1. Programmable keys

To change the default functions, use HP Accessory Center.

2. Receiver key and light

Press and hold for 2 s to pair the keyboard using the receiver.

Slowly blinking white (180 s): The receiver is in pairing mode.

Solid white (5 s): The keyboard is connected to the receiver.

3. Bluetooth keys and lights

Press to select the first or second Bluetooth channel. Press and hold for less than 2 s to air the keyboard using Bluetooth. Press and hold for more than 2 s to reinitiate pairing mode if previously paired.

Solid white (5 s): The keyboard connection or reconnection was successful.

Slowly blinking white (180 s): The Bluetooth channel is selected, and the keyboard is in pairing mode.

Two white blinks and a pause (180 s): The keyboard is connecting to a previously paired device.

4. Power light

Solid white (5 s): The keyboard is on.

Slowly blinking amber: The keyboard needs to be charged.

5. Copilot in Windows (supported devices only)

Feature availability and functionality varies by market, see aka.ms/WindowsAlFeatures.

The Copilot feature is limited to specific up-to-date versions of Windows.

6. Receiver light

Slowly blinking white (180 s): The receiver is in pairing mode.

Solid white (5 s): The keyboard is connected to the receiver.

NOTE: Turn off the keyboard when not in use.



RMN: TPA-A001K, TPA-P002D

© Copyright 2024 HP Development Company, L.P.

macOS is a trademark of Apple Inc., registered in the U.S. and other countries and regions. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Chrome is a trademark of Google LLC. Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: October 2024



Documents / Resources



hp KB60 Bluetooth Keyboard [pdf] Instructions
KB60, KB60 Bluetooth Keyboard, Bluetooth Keyboard, Keyboard

References

- © Redirection Tools
- O Al Tools and Features in Windows 11 | Microsoft Windows
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.