

**HUMMER  
H212 CPU Multi  
Socket Intel**



## HUMMER H212 CPU Multi Socket Intel Instruction Manual

[Home](#) » [HUMMER](#) » HUMMER H212 CPU Multi Socket Intel Instruction Manual 

### Contents

- [1 HUMMER H212 CPU Multi Socket Intel](#)
- [2 Warranty](#)
- [3 Components description](#)
- [4 Second fan assembly](#)
- [5 Intel LGA17DD installation](#)
- [6 Intel LGA2066/2011 installation](#)
- [7 AMD installation](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

# HUMMER

HUMMER H212 CPU Multi Socket Intel



### Notice


Please read this user manual carefully before installation to get the cooler the best performance by optimized installation. NOX Xtreme is not responsible for any damage to the product or injury caused by incorrect installation or user's carelessness. The cooler may cause an interference with a few motherboards and if you face an interference between the Hummer cooler and your motherboard, please stop installing the cooler. Be sure to be careful not to hurt yourself with the sharp fins while installing and disassembling the cooler. Do not move the cooler around after the installation to prevent CPU damage. Please, do not use the cooler for any other usage apart from the original purpose.

### Warranty

For your warranty claims, please contact Nox Xtreme overseas distribution partners in your country. Find the distribution partner list at [www.nox-xtreme.com](http://www.nox-xtreme.com)


- **Warranty:** 2 years from purchasing date. (Depending on the laws of each country,)
- **URL:** [www.nox-xtreme.com](http://www.nox-xtreme.com)
- **E-mail:** [support@nox-xtreme.com](mailto:support@nox-xtreme.com)

### Components description




1. Bracket mounting screws
2. LGA15X mounting bracket
3. LGA2011/66 mounting bracket
4. AMD mounting bracket
5. LGA115X backplate
6. Thermal grease
7. Fan clip

## Second fan assembly




1. Place the hook for the fan on the cooler.
2. Apply pressure to pass the wire through the fan.
3. Insert the end of the hook into the holes of the fan.


## Intel LGA17DD installation



1.




2.




3.

1. Install the Intel bracket onto the cooler. Stick the backplate onto the back
2. Apply a thin thermal grease layer to the CPU surface. of the motherboard.
3. Put the heatsink onto the CPU. tightening the bracket screws into the backplate to secure the heatsink firmly.

### Intel LGA2066/2011 installation




1.




2.

1. Apply a thin thermal grease layer to the CPU surface.
2. Put the heatsink onto the CPU, tightening the bracket screws into the mounting nuts on the MB.


**NOTE:** Please refer to the bracket/backplate illustration to choose the correct mounting position.




## AMD installation



1.




2.



3.

1. Remove the original AMD plastic retention tray, but keep the backplate.
2. Apply a thin thermal grease layer to the CPU surface.
3. Put the heatsink onto the CPU, tightening the bracket screws into the backplate to secure the heatsink firmly.

## Documents / Resources



[HUMMER H212 CPU Multi Socket Intel](#) [pdf] Instruction Manual

H212 CPU Multi Socket Intel, H212, CPU Multi Socket Intel, Multi Socket Intel, Socket Intel, Intel

## References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.