

HyperX Cloud II Core Wireless Gaming Headset User Guide

Home » HYPERX » HyperX Cloud II Core Wireless Gaming Headset User Guide 🖺



Quick Start Guide


Contents

- 1 Overview
- 2 Setting up with PC
- 3 Status LED
- 4 Power button
- 5 Documents /

Resources


5.1 References

Overview




- A Status LED
- **B** Power button
- **C** Mic mute /mic monitoring button
- **D** Volume wheel
- **E** USB-C charge port
- **F** Microphone port
- **G** Detachable microphone
- **H** USB adapter
- I Wireless pairing pin hole
- J Wireless status LED
- K USB-C charge cable


Usage



Setting up with PC


Right click speaker icon > Select Open Sound settings > Select Sound control panel






Playback Device

Set Default Device to "HyperX Cloud II Core Wireless"



Recording Device

Set Default Device to "HyperX Cloud II Core Wireless"



Setting up with PlayStation 5

Go to the home page and select Settings > Sound **Microphone:**

• Input Device: USB Headset "HyperX Cloud II Core Wireless"

Audio Output:

- Output Device: USB Headset "HyperX Cloud II Core Wireless"
- Output to Headphones: All Audio

Status LED

STATUS	LED
Pairing	Flash green and red every 0.2s
Searching	Slow breathing green
Connected*	90% — 100% : Solid green for 5s
	10% — 90% : Blinking green for 5s
	< 10% : Blinking red for 5s

^{*}Battery level indication

Power button

- Power on/off Hold button for 3 seconds to power headset on/off
- Battery level status Press button to see the battery level status on the status LED
 - o The status LED will automatically turn off to conserve battery life

Scroll up and down to adjust volume level


Charging

It is recommended to fully charge your headset before first use.

STATUS LED	CHARGE STATUS
Solid green	Fully Charged
Breathing green	10% — 99%
Breathing red	< 10%

Mic mute / mic monitoring button

- Mic mute toggle Press button to turn the mic mute on/off
- Mic monitoring toggle Hold button for 3 seconds to toggle mic monitoring on/off



HyperX NGENUITY Software

Go to hyperx.gg/ingenuity to download the NGENUITY software. NGENUITY software features include:

- DTS Headphone
- · Adjustable EQ settings
- Adjustable auto shut-off behavior
- · Battery level indicator



Contact the HyperX support team or see the user manual at : hyperx.gg/support

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.

Overview

A - Status LED

B – Power button

C – Mic mute / mic monitoring button

D – Volume wheel

E – USB-C charge port

F – Microphone port

G - Detachable microphone

H - USB adapter

I - Wireless pairing pin hole

J - Wireless status LED

K - USB-C charge cable

Usage

1. Connect the wireless adapter to your device 2. Power on the headset

Setting up with PC

Right click speaker icon > Select Open Sound settings > Select Sound control panel

Playback Device

Set Default Device to "HyperX Cloud II Core Wireless"

Recording Device

Set Default Device to "HyperX Cloud II Core Wireless"

Setting up with PlayStation 5

Go to the home page and select Settings > Sound

Microphone

• Input Device: USB Headset "HyperX Cloud II Core Wireless"

Audio Output

• Output Device: USB Headset "HyperX Cloud II Core Wireless"

• Output to Headphones: All Audio

Status LED

STATUS	LED
Pairing	Flash green and red every 0.2s
Searching	Slow breathing green
Connected*	90% – 100%: Solid green for 5s
	10% – 90%: Blinking green for 5s
	< 10%: Blinking red for 5s

^{*}Battery level indication

Power button

- Power on/off Hold button for 3 seconds to power headset on/off
- Battery level status Press button to see the battery level status on the status LED
 - o The status LED will automatically turn off to conserve battery life

Mic mute / mic monitoring button

- Mic mute toggle Press button to turn the mic mute on/off
- Mic monitoring toggle Hold button for 3 seconds to toggle mic monitoring on/off

Volume wheel

Scroll up and down to adjust volume level

Charging

It is recommended to fully charge your headset before first use.

STATUS LED	STATUS LED
Solid green	Solid green
Breathing green	Breathing green
Breathing red	Breathing red

HyperX NGENUITY Software

Go to hyperx.gg/ingenuity to download the NGENUITY software. NGENUITY software features include:

- DTS Headphone
- Adjustable EQ settings
- · Adjustable auto shut-off behavior
- · Battery level indicator

Questions or Setup Issues?

Contact the HyperX support team or see the user manual at hyperx.gg/support

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.

Simplified Declaration of Conformity

Hereby, HP declares that the radio equipment is in compliance with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.hp.eu/certificates (search with Model Name) UK only: Hereby, HP declares that the radio equipment is in compliance with the relevant statutory requirements. The full text of the declaration of conformity is available at the following internet address: www.hp.eu/certificates (search with Model Name)

Battery/TX Power Info

Battery Information

Contains 3.7V, 1000mAh Li-ion Battery, 3.7Wh

Cannot be replaced by user

Frequency & TX Power Information

Frequency Bands: 2.4GHz (TX Power: <10dBm)

FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

users encouraged to try correct the interference by one or more of the following measures:

- 1. Reorient the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. FCC ID: B94-CL005, B94-CL005WA

Canada Notices

This Class B digital apparatus complies with Canadian ICES-003.

ISED Statement

This device contains license-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's license-exempt

RSS(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference,
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

India RoHS Statement

This product, as well as its related consumables and spares, complies with the reduction in hazardous substances provisions of the "India E-waste (Management and Handling) Rule 2016." It does not contain lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for where allowed pursuant to the exemptions set in Schedule 2 of the Rule.



©Copyright 2022 HyperX and the HyperX logo are registered trademarks or trademarks of HP Inc. in the U.S. and/or other countries.

All registered trademarks and trademarks are property of their respective owners.

Documents / Resources



HyperX Cloud II Core Wireless Gaming Headset [pdf] User Guide

44X0009B, Cloud II Core Wireless Gaming Headset, Cloud II Core, Wireless Gaming Headset, Cloud II, Core Wireless Gaming Headset, Gaming Headset, Headset

References

• MGENUITY – HyperX ROW

- W Support HyperX ROW
- OLaptop Computers, Desktops, Printers, Ink & Toner | HP® Official Site
- Negulations Certificates | HP® United Kingdom

Manuals+,