



iAuditor UMWLBW Temperature Monitoring System User Guide

[Home](#) » [iAuditor](#) » iAuditor UMWLBW Temperature Monitoring System User Guide 



Contents

- [1 USER GUIDE](#)
- [2 iAuditor Sensors](#)
 - [2.1 Self-Installation Guide](#)
 - [2.2 Online Setup](#)
 - [2.3 Compliance Statement](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

USER GUIDE

iAuditor Sensors

Say goodbye to manual temperature and humidity checks! With iAuditor Sensors you can monitor your assets in real-time 24/7, receive alerts when things go out of critical range, and record all of your data automatically.



Self-Installation Guide

Follow this guide to setup your iAuditor sensor <https://support.safetyculture.com/sensors/iauditor-sensor-self-installation-guide/>

Online Setup

To setup the sensor online head over to www.sfty.io/setup



2+ years battery life



Wide temperature range



Weatherproof casing



Long range connectivity



Easy-mount bracket



Readings every 10 minutes

Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operations of the device.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of

this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.


This equipment complies with the FCC and ISM radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and all persons' body during normal operation.

Warning: Any changed or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



www.safetyculture.com/monitoring

Documents / Resources



[iAuditor UMWLBW Temperature Monitoring System](#) [pdf] User Guide
DT1104-0100, DT11040100, 2AW4, U-DT1104-0100, 2AW4UDT11040100, UMWLBW, Temperature Monitoring System