

iBoard IB-188C Running Boards Nerf Bars Side Steps



iBoard IB-188C Running Boards Nerf Bars Side Steps Installation Guide

[Home](#) » [iBoard](#) » iBoard IB-188C Running Boards Nerf Bars Side Steps Installation Guide 

Contents

- [1 iBoard IB-188C Running Boards Nerf Bars Side Steps](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 PART LIST](#)
- [6 Mounting Bracket List](#)
- [7 Hardware Package](#)
- [8 Installation Instructions](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

iBoard[®]

iBoard IB-188C Running Boards Nerf Bars Side Steps



Specifications

- **Product Name:** Rocker Panel Mount
- **No drilling:** required
- **Part Number:** IB-188C&H

Product Usage Instructions

Step 1: Front Mounting Bracket Installation

- Start the installation under the passenger side of the vehicle. Locate the front factory running board mounting location along the inner side of the body.

Parts needed:

- (3) M8 Plastic Washers

Step 2: Plastic Washer Installation

- Slide (1) M8 Plastic Washer over each factory mounting stud in the body panel. The Plastic Washers are designed to prevent corrosion between the aluminium body panel and the steel mounting brackets.

Step 3: Passenger Front Mounting Bracket Installation

- Select the Passenger Front Mounting Bracket and attach it to the factory studs with the provided washers and nuts. Snug but do not fully tighten the hardware.

Parts needed

- (3) M8 Plastic Washers
- (3) M8 Large Flat Washers
- (3) M8X1.25 Nylon Lock Nuts

Step 4: Passenger Rear Mounting Bracket Installation

- Repeat Steps 1-3 to install the Passenger Rear Mounting Bracket.

Step 5: Passenger Center Mounting Installation

Move to the Passenger Side Center Mounting Location. Assemble the Passenger Center Bar Bracket and Passenger Center Mounting Bracket using provided hardware.

Parts needed

- (2) M8X1.25-25mm Hex Bolts
- (2) M8 Lock Washers
- (4) M8 Large Flat Washers
- (2) M8 Hex Nuts

FAQ

- **Q:** Is drilling required for installation?
- **A:** No, drilling is not required. The product is designed for rocker panel mount without drilling.
- **Q:** What is the recommended tightening torque for different fastener sizes?
- **A:** The recommended tightening torque is as follows:
 - 6mm – 6-7 ft-lbs
 - 8mm – 16-18 ft-lbs
 - 10mm – 31-32 ft-lbs
 - 12mm – 56-58 ft-lbs
 - 14mm – 92-94 ft-lbs

READ INSTRUCTIONS CAREFULLY BEFORE START ING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.



PART#: IB-188C&H

Fastener Size	Tightening Torque (ft-lbs)	Required
6mm	6-7	X
8mm	16-18	√
10mm	31-32	X
12mm	56-58	X
14mm	92-94	X

- ROCKER PANEL MOUNT
- NO DRILLING REQUIRED

PART LIST


Driver Side Step Bar



Front



Passenger Side Step Bar









Mounting Bracket List

Item	QTY	Description	Item	QTY	Description
1#	4	Mounting Brackets	3#	2	Driver/Passenger Center Bar Brackets
2#	2	Driver/Passenger Center Mounting Brackets			

Hardware Package





Hardware Package A (For Bracket Installation)

Item	Qty	Description	Item	Qty	Description
1#	12	M8 Plastic Washers	4#	4	M8X1.25-25mm Hex Bolts
2#	20	M8 Large Flat Washers	5#	4	M8 Lock Washers
3#	12	M8X1.25 Nylon Lock Nuts	6#	4	M8 Hex Nuts

 1# 2# 3# 4# 5# 6#

Hardware Package B (For Stainless Steel Step Bar Installation)


Item	Qty	Description	Item	Qty	Description
1#	12	M8X1.25-35mm Carriage Bolts	3#	12	M8 Nylon Lock Nuts
2#	12	M8 Large Flat Washers	4#	6	Sliders (Packed with Step Bars)

 1# 2# 3# 4#

Installation Instructions

STEP 1


- Start the installation under the passenger side of the vehicle. Locate the front factory running board mounting location along the inner side of the body, (Fig 1).



(Fig 1) Passenger Side Front Mounting Bracket Location

STEP 2

- Slide (1) M8 Plastic Washer over each factory mounting stud in the body panel, (Fig 2 & 3).
- **NOTE:** The Plastic Washers are designed to prevent corrosion between the aluminium body panel and the steel mounting brackets.



(Fig 2) M8 Plastic Washer





Fig 3) Thread Plastic Washers Onto 3 Mounting Studs
(Example Passenger Side Front Mounting Location)

STEP 3

- Select Passenger Front Mounting Bracket. Note: All (4) Front and Rear Mounting Brackets are universal.
- Attach the Mounting Bracket to the (3) factory studs with (3) M8 Large Flat Washers and (3) M8X1.25 Nylon Lock Nuts, (Fig 4). Snug but do not fully tighten the hardware.





STEP 4

- Repeat Steps 1—3 to install the Passenger Rear Mounting Bracket.


STEP 5

- Move to the Passenger Side Center Mounting Location, (Fig 5). Assemble the Passenger Center Bar Bracket and Passenger Center Mounting Bracket using (2) M8X1.25-25mm Hex Bolts, (2) M8 Lock Washers, (4) M8 Large Flat Washers and (2) M8 Hex Nuts (Fig 6).
- **Note:** Center Mounting Brackets and Bar Brackets are universal.
- Remove the (2) factory hex flange nuts on the bottom of the mount. Attach the Passenger Center Mounting Bracket onto the body mounting location and reuse the factory hex nuts (Fig 7).





(Fig 6) Passenger Center Brackets Assembly




(Fig 7) Reuse Factory Hex Nuts To Attach Passenger Center Mounting Bracket To Underside Of Center Body Mounting Location


STEP 6

Once all (3) Passenger side mounting brackets are installed. , then proceed to the Step Bar installation. (Figs 8&9)

1. Select (1) Slider and (2) M8X1.25-35mm Carriage Bolts;
2. Install (2) M8X1.25-35mm Carriage Bolts in (1) Slider.
3. Slide the Slider (with carriage bolts) to the Step Bar.
4. Repeat to install the other (2) sliders to the step bar.
5. Attach the Step Bar (with the Sliders) to the installed mounting brackets. Position the Sliders to the installed brackets. Secure the Step Bar to the installed Brackets by using (6) M8 Large Flat Washers (6) M8 Nylon Lock Nuts and (3) Sliders, (Fig 9). Do not fully tighten the hardware at this time.



(Fig 8) Slider Installation



(Fig 9) Step Bar Installation


Note: The Sliders are packed with the Step Bars.
 Level and adjust the Step Bar and fully tighten all hardware.
 Repeat Steps 1-6 for the other side Step Bar installation. The installation is completed!!!

Attention

- Do periodic inspections to the installation to make sure that all hardware is secure and tight.
- In order to protect your bars/boards, please use mild soap/non-abrasive products for cleaning only.

Customer Support: info@iboardauto.com.





[iBoard IB-188C Running Boards Nerf Bars Side Steps](#) [pdf] Installation Guide
IB-188C Running Boards Nerf Bars Side Steps, IB-188C, Running Boards Nerf Bars Side Steps
, Nerf Bars Side Steps, Side Steps

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.