

Ibx instruments ORB-B2 Orbital Shaker Instruction Manual

Home » IbX instruments » Ibx instruments ORB-B2 Orbital Shaker Instruction Manual



Ibx instruments ORB-B2 Orbital Shaker Instruction Manual



ORB-B2 Orbital Shaker with Digital Screen and Timing Function

Preface

Users should read this Manual carefully, follow the instructions and procedures, and beware of all the cautions when using this instrument.

Service

In order to guarantee this equipment works safely and efficiently, it must receive regular maintenance. In case of any faults, do not try to repair it yourself. If help is needed, you can always contact your dealer or Labbox via www.labbox.com

Please provide the customer care representative with the following information:

- Serial number
- · Description of problem
- · Your contact information

Warranty

This instrument is warranted to be free from defects in materials and workmanship under normal use and service, for a period of 24 months from the date of invoice. The warranty is extended only to the original purchaser. It shall not apply to any product or parts which have been damaged on account of improper installation, improper connections, misuse, accident, or abnormal conditions of operation. For claim under the warranty please contact your supplier.

Contents

- 1 Installation Instructions
- 2 Operating Procedure
- 3 Troubleshooting and Error Code

Information

- 4 Documents / Resources
 - 4.1 References
- **5 Related Posts**

Installation Instructions

- 1. Carefully unpack the instrument and place it on a stable, clean, non-slip, and fireproof surface.
- 2. Ensure a good working environment free of any combustible media or flammable materials to avoid additional hazards.
- 3. Place the shaker at a distance of more than 10cm from the wall and other units if using multiple units together.
- 4. Ensure that there is no accidental spillage during speed setting.
- 5. Do not use any combustible media or flammable materials to avoid any additional hazards.
- 6. Ensure that the label indicates the correct voltage before connecting the unit to the power supply.
- 7. Do not operate the unit with a damaged power cord.
- 8. Disable the power supply while fitting the accessories.
- 9. Ensure that the unit and its accessories are in good working condition before each operation

Operating Procedure

- 1. Switch ON the power and the instrument will start self-checking.
- 2. Press the "Mode" key and the unit will enter the adjustment mode.
- 3. Press the "+/-" keys and confirm the set speed and time. Adjust the speed and time to the desired settings.
- 4. Press the "Start" key and the instrument will begin shaking.
- 5. Press the "Stop" key to stop the operation and return the unit to adjustment mode.

Troubleshooting and Error Code Information

Error C ode	Problem	Reason	Solution
E01	No operating response found (LED OFF)	Power switch is OFF	Check and conned the power supply before restarting. Check the adapter.
		Switch position is OF F	Turn on the instrument and check the speed set on the LED display.
		Internal cables disco nnected	Open the instrument and check allconnections before reconnecting them.
E02	The shaking bo ard operation failur e	Target speed is not s et	Set the target speed and make sure the indicator lamp is O N.
		Driver board damage	Replace the driver board.
		Motor damage	Replace the motor.
E03	Inaccurate sha king speed	Driver board damage	Replace the driver board.
		Photoelectric switch damage	Replace the photoelectric switch.
E04	Shaking speed is jammed	Driver board damage	Replace the driver board.
		Motor damage	Replace the motor.



Documents / Resources



<u>Ibx instruments ORB-B2 Orbital Shaker</u> [pdf] Instruction Manual ORB-B2 Orbital Shaker, ORB-B2, Orbital Shaker, Shaker

References

- O Lab supplies Labbox Export
- <u>Manual-Hub.com Free PDF manuals!</u>
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.