ICY BOX IB-MPS2220B-CH Double Socket Instruction Manual

Manual IB-MPS2220B-CH
Twin power outlet strip with 3x USB
(2x Type-A, 1x Type-C ®) charger
Handbuch IB-MPS2220B-CH
Doppelsteckdose mit 3x USB
(2x Type-A, 1x Type-C ®) Charger

Contents

Safety Information

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

Warning levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.

⚠ **DANGER** Warns of a directly hazardous situation causing death or serious injury.

⚠ **WARNING** Warns of a potentially hazardous situation that may cause death or serious injury.

⚠ **CAUTION** Warns of a potentially hazardous situation that may cause minor injury.

IMPORTANT Warns of a potential situation that may cause material or environmental damage and disrupt operative processes.

Risk of electrical shock

1. Risk of death by electrical shock

   Contact with parts conducting electricity

   ⚠ **WARNING**

   Read the operating instructions prior to use

   • Make sure the device has been de-energised prior to working on it

   • Do not remove contact p otection panels

   • Avoid contact with conducting parts

   • Do not bring plug contacts in contact with pointed and metal objects

   • Use in intended environments only

   • Operate the device using a power unit meeting the specifications of the type plate only!

   • Keep the device/power unit away from humidity, liquid, vapour and dust

   • Do not modify the device

   • Do not connect the device during thunderstorms

   • Approach specialist retailers if you require repairs

2. Hazards during assembly (if intended)

   Sharp components

   ⚠ **CAUTION** Potential injuries to fingers or hands during assembly (if intended)

   • Read the operating instructions prior to assembly

   • Avoid coming into contact with sharp edges or pointed components

   • Do not force components together

   • Use suitable tools

   • Use potentially enclosed accessories and tools only

3. Hazards caused by a development of heat

   IMPORTANT Insufficient device/power unit ventilation

   Overheating and failure of the device/power unit

   • Prevent externally heating up components and ensure an exchange of air

   • Do not cover the fan outlet and passive cooling elements

   • Avoid direct sunlight on the device/power unit

   • Guarantee sufficient ambient air for the device/power unit

   • Do not place objects on the device/power unit

4. Hazards caused by very small parts and packaging

   ⚠️ **WARNING**

   Risk of suffocation

   Risk of death by suffocation or swallowing

   • Keep small parts and accessories away from children

   • Store/dispose of plastic bags and packaging in an area that is inaccessible to children

   • Do not hand over small parts and packaging to children

5. Potential data loss

   IMPORTANT Data lost during commissioning

   Potentially irreversible data loss

   • Always comply with the information in the operating instructions/quick installation guide

   • Exclusively use the product once the specifications have been met

   • Back up data prior to commissioning

   • Back up data prior to connecting new hardware

   • Use accessories enclosed with the product

6. Cleaning the device

   IMPORTANT

   Harmful cleaning agents

   Scratches, discolouration, damage caused by moisture or short circuit in the device

   • Disconnect the device prior to cleaning

   • Aggressive or intense cleaning agents and solvents are unsuitable

   • Make sure there is no residual moisture after cleaning

   • We recommend cleaning devices using a dry, anti-static cloth

7. Disposing of the device

   IMPORTANT

   Environmental pollution, unsuitable for recycling

   Potential environmental pollution caused by components, recycling circle interrupted

   This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (WEEE) this electrical device and potentially included batteries must not be disposed of in conventional, domestic wasteor recycling waste. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.

   The included batteries must be completely discharged before return. Take precaution to protect the batteries from short circuits (e.g. by insulating the contact poles with adhesive tape).

If you have any questions, please do not hesitate to contact our support at **support@raidsonic.de** or visit our website at **www.icybox.de**.

Manual IB-MPS2220B-CH

Package content
IB-MPS2220B-CH
Manual
Description
IB-MPS2220B-CH is a power strip with integrated USB charging module and overcurrent protection. It disconnects the load if the load current permanently exceeds 16 amps. A tripped fuse is indicated by the main switch of the unit.
Resetting is done by switching the main switch off and on again.
The charging module offers two USB Type-A charging ports with 5 V and 2.4 A each as well as a USB Type-C ® charging port with 5 V and 3 A current delivery capacity. The combined total current must not exceed 3.4 Amperes.

Documents / **Resources**

ICY BOX IB-MPS2220B-CH Double Socket [pdf] Instruction Manual
IB-MPS2220B-CH Double Socket, IB-MPS2220B-CH, Double Socket, Socket

References

- 🧊 **ICY BOX - Create your workspace.**
- ⚠ **Que Faire de mes Déchets ? Découvrez les solutions pour tous vos déchets et nos conseils pour en produire moins.**