

[Skip to content](#)

[Manuals+](#)

User Manuals Simplified.

ifi NEO Stream Network Audio Streamer User Guide




[Home](#) » [ifi](#) » ifi NEO Stream Network Audio Streamer User Guide

- Contents [hide](#)
- [1 ifi NEO Stream Network Audio Streamer](#)
 - [2 Quick Start Guide](#)
 - [3 Wi-Fi Set-Up](#)

- [4 Ethernet Set-Up](#)
- [5 Music Streaming](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)




Quick Start Guide



1. Power



- ## 2. Input




3. Output




Wi-Fi Set-Up

- A power supply unit must be able to deliver minimum rated repetitive current.




2. Power on



3. Select Hotspot and set to ON




4. In your device's Wi-Fi setting, connect to 'ifi-Streamer'



5. Enter "http://ifi.local" or "192.168.211.1" Enter "192.168.211.1"


6. Connect the iFi-Streamer to your local Wi-Fi network



Enter network password
and press Connect



IP address will show once connected



Connection speed

- ☐ Fast (Internet)
- ☐ Slow (Internet)
- ☐ Fast (Local network)
- ☐ Slow (Local network)
- ☐ No connection


7. Network status LED

8. Connect device back to local Wi-Fi network (If not already connected)


9. Go to Music Streaming section

Ethernet Set-Up


1. Connect LAN and power supply DAC, Amplifier or Active Speakers via S/PDIF, RCA or USB



- A power supply unit must be able to deliver minimum rated repetitive current.



2. Power on



Connection speed

Fast (Internet)
Slow (Internet)
Fast (Local network)
Slow (Local network)
No connection

3. Ready to connect




4. IP address will show once connected

Music Streaming



Open Tidal app



- Other compatible apps are available

Documents / Resources



[ifi NEO Stream Network Audio Streamer](#) [pdf] User Guide

NEO Stream, Network Audio Streamer, NEO Stream Network Audio Streamer, Audio Streamer, Streamer

[Manuals+](#)

- [home](#)
- [privacy](#)