

iGPSPORT®

iGS800 Bike
Computer with
Color
Touchscreen



iGPSPORT iGS800 Bike Computer with Color Touchscreen User Guide

[Home](#) » [iGPSPORT](#) » iGPSPORT iGS800 Bike Computer with Color Touchscreen User Guide 

Contents

- [1 iGPSPORT iGS800 Bike Computer with Color Touchscreen](#)
- [2 Quick Start Manual](#)
- [3 Device Buttons](#)
- [4 First Pairing](#)
- [5 Installation of standard bike mount](#)
- [6 Fcc Statement](#)
- [7 SPECIFICATIONS:](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

iGPSPORT®

iGPSPORT iGS800 Bike Computer with Color Touchscreen



Quick Start Manual

Charging







The device is powered by a built-in lithium-ion battery that you can charge using an AC adapter or a USB port on your computer. (Please ensure the original charging cable is used.)

1. Lift the weather cap from the USB port.
2. Plug the USB cable into an AC adapter or a computer USB port.
3. Charge the device completely.
4. After you charge the device, unplug the cable and close the weather cap.

Note

1. Please use DCSV standard power adapter. The fast charge adapter is not recommended because it may damage the battery.
2. When the battery level is low, a low battery icon will be displayed in the upper right corner of the device's home page, indicating low battery level and recommending to charge the device.
3. Do not overstretch the USB weather cap to keep its waterproof and dust-proof performance.

Device Buttons

Button	Features
	Power Button: Short press to power on / Long press to power off / Back to last page
	Confirm Button: Confirm / Go to ride menu
	Lap Button: Lap / Go to system menu / Quick settings
	Ride Button: Start / Pause activity
	Up Button: Switch up / left
	Down Button: Switch down / right

Pairing your smartphone

Pairing smartphone helps you use the bike computer more conveniently. You can experience richer features on the iGPSPORT APP.

First Pairing

1. Open the iGPSPORT APP in your smartphone and login with your iGPSPORT account
2. Place the cycling computer nearby your smartphone and enter the home page or device page in the APP. Click Add Device, select iGS Series and then your smartphone will automatically search for iGSS00. Select it and click Connect , and the pairing will start.
3. When Bluetooth Pairing Request prompts on your device, click Pair to accept the request.
4. After the pairing, the cycling computer will be displayed in the device list.
5. Then the prompt of device setting on your smartphone will show up in the iGPSPORT APP. Finish your settings and click Save and Sync , and then the settings will be synced to the device.

After successful pairing, the device and the smartphone will be automatically connected via Bluetooth; if it fails, you can try to restart the smartphone Bluetooth, the iGPSPORT APP or the cycling computer for pairing again.

Remove Pairing

If you want to pair your cycling computer with another smartphone, please remove the current pairing first:

1. Go to System Menu> Pair Phone to view the paired device list.
2. Select the device you want to delete, click Unpair Phone and press to confirm.
3. When the deletion is completed, the bike computer will restart automatically and Bluetooth Disconnected icon will be displayed on the device.

Note

1. Please pair the device based on the instructions in the iGPSPORT APP, rather than using the Bluetooth settings on your smartphone.
2. Ensure that your smartphone is connected to the internet and that Bluetooth is enabled.
3. Download the iGPSPORT APP from the AppStore or GooglePlay.
4. For Android users, make sure to enable location permissions for the iGPSPORT APP in your phone's app settings.

5. Do not pair and unpair the device frequently.

Firmware Update

To keep the device's best performance, please update its firmware timely when a new version is available.

1. The device will automatically check for firmware updates when connected to Bluetooth or Wi-Fi.
2. Alternatively, you can manually check for updates by going to the iGPSPORT APP > Device > Firmware Update.
3. Depending on the strength of the Bluetooth signal, it may take up to 20 minutes. Please be patient during the process.

Installation of standard bike mount

Use the included rubber bands to attach the standard bike mount to the bike stem.

1. Place the rubber disk on the back of the standard bike mount.
2. Select a suitable place on the bike stem to place the rubber disk and the standard bike mount.
3. Loop the two rubber bands around the bike stem respectively, hook the buckle of the bike mount and fix it on the bike stem.
4. Align the tabs on the back of the device with the standard bike mount notches.
5. Place the device on the bike mount and rotate it by 90 degrees.

Note

It is recommended to use iGPSPORT Standard Bike Mount or Out-Front Mount to avoid damaging the tab of the cycling computer.

For more information

Please visit the iGPSPORT official website for the user manual and software update information.

Fcc Statement

WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body:

Use only the supplied antenna.

FCC ID:2AU4M-IGS630

SPECIFICATIONS:


- Operating Temperature: -10°-50°C

1GPSPORT®

Official website: www.igpsport.com

- Execution standard number: Q/WQW 005-2024
- Manufacture: Wuhan Qiwu Technology Co.,Ltd
- (86)027-87835568 1111
- service@igpsport.com

Documents / Resources

	<p>iGPSport iGS800 Bike Computer with Color Touchscreen [pdf] User Guide 04.VXX.00242, iGS800 Bike Computer with Color Touchscreen, iGS800, Bike Computer with Color Touchscreen, with Color Touchscreen, Color Touchscreen</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.