


IMOU Bullet 2S Wi-Fi Camera User Guide

Home » imou » IMOU Bullet 2S Wi-Fi Camera User Guide 🖫







Quick Start Guide Bullet 2S Bullet 2S 4MP

Welcome

Thank you for choosing IMOU.

We are devoted to providing you with easy smart home products.

If you have problems using the product, please contact our service team before returning your product.

Our service mail: service.global@imoulife.com

Frequently asked questions can be found at imoulife.com/support/help



http://www.imoulife.com/web/support/help




Contents

- 1 Package content
- 2 Camera introduction
- 3 Troubleshooting
- 4 Documents /


Resources

- 4.1 References
- **5 Related Posts**

Package content




Camera introduction



The pattern of the LED indicator is included in the following table.


LED Status	Device Status
Off	Powered off/LED turned off Rebooting after reset
Red light on	Booting Device malfunction
Greenlight flashing	Waiting for network
Greenlight on	Operating properly
Red light flashing	Network connection failed
Green and red light flashing alternately	Firmware updating




http://mobile.easy4ipcloud.com/imou/detect.html




(i) Tips



To ensure the best possible wireless performance, please make sure there are no obstacles and electromagnetic interference between the camera and router.



3 Installing the Camera



Troubleshooting

Problem	Solution
The APP says "Failed to configure device network"	 Reset your Camera and connect it again. Some cameras only support 2.4GHz, while some routers have dual-band, 2.4G/5G. Make sure you are connecting 2.4GHz only.
No audio	 Ensure the audio function on the camera is turned on. Ensure audio is turned up on the viewing device.
Human detection not working	• Ensure you have enabled "Human Detection" in the Device Settings screen of the Imou LifeApp.
The device cannot work normally or start?	Check the LED indicator status. If the light is not in green, press and hold the res et button for 10 s to reset the camera.
How to connect the camera to a new Wi-Fi?	If the camera is offline, reset the camera, and configure the camera again.
Connection is time?	Check if the distance between the camera and the router, the camera, and the s martphone is within 5 m (16.4 ft) during the connection.
When the Micro SD card is full, how is the recorded video saved?	When the Micro SD card is full, the system will overwrite the previously recorded videos. Save the important information in time.
The device is offline?	Check the indicator status: • If the green light is on, check whether the router can connect to the Internet. If the Internet is working, restartthe camera. • If the red light flashes, reset the camera, and then configure the camera again. • If the red light is on, it means the camera is faulty.

www.imoulife.com

Documents / Resources



IMOU Bullet 2S Wi-Fi Camera [pdf] User Guide Bullet 2S Wi-Fi Camera, Bullet 2S, Wi-Fi Camera

References

• Imou | Enjoy Smart Life

- Imou Support
- O MouLife.com is for sale | HugeDomains
- Imou | Enjoy Smart Life

Manuals+,