

inateck BK2009 Bluetooth Keyboard Case Instruction Manual



inateck BK2009 Bluetooth Keyboard Case Instruction Manual



Contents

- [1 Product Diagram](#)
- [2 Bluetooth Pairing](#)
- [3 Shortcut Keys](#)
- [4 Restore Factory Defaults](#)
- [5 Check Battery Level](#)
- [6 Charging](#)
- [7 Sleep Mode](#)
- [8 Product Specification](#)
- [9 Packing List](#)
- [10 FCC Note](#)
- [11 Service Center](#)
- [12 Documents / Resources](#)

Product Diagram



Bluetooth Pairing





Step 1: Put the keyboard in the case, press the power switch on the right side and long press simultaneously. Then, Indicator 1 will blink in blue, indicating that the keyboard is in Bluetooth pairing mode.

Step 2: On your iPad, go to Settings > Bluetooth, turn on Bluetooth and then Inateck BK2009 will show up in "Other Devices"

Step 3: Tap "Inateck BK2009" to pair it with your iPad that Bluetooth pairing is completed.
















Step 1: Go to Settings > Bluetooth, find Inateck BK2009 in My Devices and tap the Info (i next to it), then tap Forget This Device. If there are multiple pairing records related to the keyboard, please clear all of them.


Step 2: Hold  +  for 3 seconds and then the factory reset is completed.

Step 3: Pair your iPad with BK2009 again.







Shortcut Keys

1. To use below shortcut keys please press  and the corresponding number key of the function simultaneously. For example, to make BK2009 mute, you need to press  +  simultaneously.


Key	Function	Key	Function	Key	Function
 esc	Output ‘	 1	Brightness –	 2	Brightness +
 3	Multitasking interface	 4	Take a screenshot	 5	Switch keyboard layout
 6	Last track	 7	Play/Pause	 8	Next track
 9	Mute	 0	Volume –	 –	Volume+
 =	Lock				



Common Keyboard Shortcuts

 + X	Cut	 + C	Copy	 + V	Paste
 + A	Select all	 + Space	Search	control+Space	Switch keyboard layout
 + Tab	Switch between Apps				





Tips: Hold the  row shortcuts. key to see a list of shortcuts that you can use with an app, excluding the top

Indicator	Status	Meaning
Indicator 1-Blue	Solid	Caps Lock on
	Off	Caps Lock off/ Bluetooth connected / Bluetooth unconnected
	Blinking	Bluetooth Pairing / Bluetooth Reconnecting
Indicator 2-Red	Off	Fully charged
	Blinking	Battery level<20%
	Solid	Charging



Restore Factory Defaults



Hold  +  simultaneously for 3 seconds and then the Indicator 1 will blink for 3 times once the factory reset is completed.

Check Battery Level



When the eboard s unchord r Buctoth s conected hold  +  simtanously check the atery level according to the blinking frequency of Indicator 1.

Blinking Frequency	Battery Level
Once	0-25%
Twice	25%-50%
Three Times	50%-75%
Four Times	75%-100%

Charging

When the battery level is under 20%, the Indicator 2 will blink in red. Please use the included USB cable to recharge the keyboard for 2 hours. The suggested charging voltage and current are 5V/200mA. The Indicator 2

will stay in red when the keyboard is charging. Once it fully charged, the indicator 2 will go off.

Sleep Mode

When BK2009 is left idle for 10 minutes, it will enter sleep mode and the Bluetooth connection will be disrupted. The connection can be rebuilt with a press of any key.

Product Specification

Effective Transmission Distance	10m
Charging Time	About 2h
Continuous Working Time	About 150h
Operating Temperature	-10° -55°
Bluetooth Frequency Range	2402-2480MHz
Actuation Force	60 ± 10g
Battery Capacity	300mAh

Packing List

- BK2009 1
- Charging Cable *1
- Instruction Manual *1

FCC Note

"This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Users, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Identify or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirements. "This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-

located or conjunction with any other antenna or transmitter.

Service Center

Europe

F&M Technology GmbH

Tel: +49 3415199 8410 (Working day 8 AM – 4 PM CET)

Fax: +49 3415199 8413

Address: Fraunhoferstrafie 7,04178 Leipzig, Deutschland

North America

Inateck Technology Inc.

Tel: +1(909) 698 7018 (Working day 9 AM – 5 PM PST)

Address: 2078 Francis St., Unit 14-02, Ontario, CA 91761, USA



F&M Technology GmbH

Fraunhoferstrafie 7, 04178 Leipzig, Deutschland

Tel: +49 341 5199 8410



Inateck Technology (UK) Ltd.

95 High Street, Office B, Great Missenden, United

Kingdom, HP16 0AL

Tel: +44 20 3239 9869

Manufacturer

Shenzhen Inateck Technology Co., Ltd.

Address: Suite 2507, Block 11 in Tian An Cloud Park, Bantian Street, Longgang District, Shenzhen, Guangdong, China

Documents / Resources



[inateck BK2009 Bluetooth Keyboard Case](#) [pdf] Instruction Manual
2A2T9-BK2009, 2A2T9BK2009, BK2009, BK2009 Bluetooth Keyboard Case, Bluetooth Keyboard Case, Keyboard Case, Case