



inateck KB01103 Bluetooth Keyboard Case Instruction Manual

[Home](#) » [inateck](#) » inateck KB01103 Bluetooth Keyboard Case Instruction Manual 

Contents


- [1 inateck KB01103 Bluetooth Keyboard Case](#)
- [2 Product Diagram](#)
- [3 Bluetooth Pairing](#)
- [4 Shortcut Keys](#)
- [5 LED Indicator](#)
- [6 Charging](#)
- [7 Product Specification](#)
- [8 Packing List](#)
- [9 FCC](#)
- [10 Documents / Resources](#)

inateck®

inateck KB01103 Bluetooth Keyboard Case



Product Diagram





Bluetooth Pairing















- **Step 1:** For the first use, slide the power switch to the On position and then KB01103 will automatically enter Bluetooth Channel 1 pairing mode with a blinking blue indicator. To enter the Bluetooth pairing mode, you can also hold **fn** + **Bluetooth icon**. When the Bluetooth indicator flashes blue, it means KB01103 is in Bluetooth Channel 1 pairing mode.
- **Step 2:** On your iPad or Windows devices, turn on Bluetooth and then "Inateck KB01103" will show up in available devices list.
- **Step 3:** Tap "Inateck KB01103" to pair it with your device and then the Bluetooth indicator will stay solid in blue.

which means that Bluetooth pairing is completed.

Fix Bluetooth Pairing Problems

- **Step 1:** Go to Bluetooth page, find “Inateck KB01103” in paired devices list and delete the previous pairing record. If there are multiple pairing records, please delete them all.
- **Step 2:** Hold  +  simultaneously for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.
- **Step 3:** Turn off Bluetooth on your device and turn it back on. Then, pair it with your Inateck KB01103.

Shortcut Keys



	Undo		Brightness-		Brightness+
	Lock		Task View		Take a screenshot
	Switch keyboard layout		Last Track		Play/Pause
	Next Track		Mute		Volume-
	Volume+		Delete		

Note: The following operations are only applicable to Windows.

• How to Use F1-F12



You may press  +  to lock the Fn key. (The keyboard disables the Fn key lock by default.)

• When the Fn Lock is enabled
















Press F1 can trigger the functionality owned by F1 key; Press the combination of  +  simultaneously will dim the brightness of the screen.

This method applies to all F Keys (F1-F12).

• When the Fn Lock is disabled (Default Status)

Press F1 can dim the brightness of the screen. Press the combination of  +  simultaneously will trigger the functionality owned by F1 key.



The Combination of Fn and Other Keys

	Enable/Disable Fn Lock
	Check the Battery Level
	Turn on/off Trackpad
	Switch to iOS Device
	Switch to Windows Device
	Switch to Android Device
	Short press to enter 
	Long press to enter  pairing mode
	Short press to enter 
	Long press to enter  pairing mode
	Short press to enter 
	Long press to enter  pairing mode

LED Indicator

Indicator	Status	Meaning
Caps Lock Indicator	Solid	Caps Lock On
	Off	Caps Lock Off
Bluetooth Indicator	Fast Blinking	Bluetooth Pairing
	Off	Bluetooth Unconnected
	Solid	Bluetooth Connected
	Slow Blinking	Bluetooth Reconnecting
Battery Indicator	Blinking	Battery level<20%
	Solid in Red	Charging
	Solid in Green	Fully charged
Bluetooth Indicator Color		Meaning
Blue		Bluetooth Channel 1
Orange		Bluetooth Channel 2
Green		Bluetooth Channel 3

Restore Factory Defaults

Hold  +  for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.

Check Battery Level

Hold  +  simultaneously to check the battery level according to the blinking frequency of the red battery

indicator.

Blinkina Frequency	Battery Level
Once	0-25%
Twice	25%-50%
Three Times	50%-75%
Four Times	75%-100%

Charging

When the battery level is under 20%, the red battery indicator will blink. You can connect the included USB cable to the charger of your cellphone or the USB port of a computer to recharge the keyboard for 2~3 hours. The red battery indicator will stay solid when the keyboard is charging. Once it's fully charged, the green battery indicator will stay solid.

Sleep Mode

When KB01103 is left idle for 10 minutes, it will enter sleep mode and the Bluetooth connection will be disrupted. The connection can be rebuilt with a press of any key.

Product Specification

Bluetooth Version	Bluetooth 5.3
Bluetooth Range	10 m
Charging Time	2~3 h
Continuous Working Time	About 25 h
Operating Temperature	-10°C ~ +55°C
Bluetooth Frequency Range	2402-2480MHZ
Actuation Force	60 ± 10g
Battery Capacity	280mAh

Packing List

- KB01103 *1
- Charging Cable *1
- Instruction Manual *1

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Users, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

EU Declaration of Conformity

Inateck Co., Ltd. hereby declares that this device complies with the Directive 2014/53/EU. A copy of the Declaration of Conformity can be accessed from <https://www.inateck.de/pages/euro-compliance>.

Service Center

Europe

F&M Technology GmbH

Tel: +49 341 5199 8410 (Working day 8 AM – 4 PM CET)

Fax: +49 341 5199 8413

Address: Fraunhoferstraße 7, 04178 Leipzig, Deutschland

North America

Inateck Technology Inc.

Tel: +1 (909) 698 7018 (Working day 9 AM – 5 PM PST)


Address: 2078 Francis St., Unit 14-02, Ontario, CA 91761, USA

Manufacturer

Shenzhen Inateck Technology Co., Ltd.

Address: Suite 2507, Block 11 in Tian An Cloud Park, Bantian Street, Longgang District, Shenzhen, Guangdong, China

Documents / Resources

	<p>inateck KB01103 Bluetooth Keyboard Case [pdf] Instruction Manual 2A2T9-KB01103, 2A2T9KB01103, KB01103, KB01103 Bluetooth Keyboard Case, Bluetooth Keyboard Case, Keyboard Case, Case</p>
---	---