




inateck KB04122-11 Keyboard Instruction Manual

[Home](#) » [inateck](#) » inateck KB04122-11 Keyboard Instruction Manual 

Contents

- [1 inateck KB04122-11 Keyboard](#)
- [2 Product Specifications](#)
- [3 FAQ](#)
- [4 Product Diagram](#)
- [5 Bluetooth Pairing](#)
- [6 Multi-Touch Gestures](#)
- [7 Shortcut Keys](#)
- [8 LED Indicator](#)
- [9 Restore Factory And Check Battery](#)
- [10 Product Specification](#)
- [11 Packing List](#)
- [12 FCC STATEMENT](#)
- [13 Service Center](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)

inateck®

inateck KB04122-11 Keyboard




Product Specifications

- **Model:** KB04122-11 Keyboard
- **Manufacturer:** Shenzhen Inateck Technology Co., Ltd.
- **Address:** Suite 2507, Block 11 in Tian An Cloud Park, Bantian Street, Longgang District, Shenzhen, Guangdong, China
- **Email:** product@licheng-tech.com
- **Postal code:** 518129



FAQ

- **Q:** How do I clean my keyboard?
 - **A:** To clean the keyboard, first, make sure it is unplugged. Use a soft, slightly damp cloth to wipe down the keys. Avoid using harsh chemicals or excessive water to prevent damage.
- **Q:** What should I do if some keys are not working?
 - **A:** If certain keys are not functioning properly, try gently removing debris or dust that may be stuck under the problematic keys. If the issue persists, contact customer support for further assistance.

Product Diagram



Bluetooth Pairing

- **Step 1:** Put the iPad case on and slide the keyboard switch to the On position. Hold down  +  simultaneously and then the keyboard will enter pairing mode with a blinking blue indicator light.
- **Step 2:** On your iPad, go to Settings > Bluetooth, turn on Bluetooth and then “Inateck KB04122-11” will show up in “Other Devices”
- **Step 3:** Tap “Inateck KB04122-11” to pair it with your iPad. The Bluetooth indicator will go off in seconds, which means that Bluetooth pairing is completed.

Note:

Set Up Your iPad:


- For better user experience, please follow steps below to set up your iPad at first use once Bluetooth pairing is completed (using iPadOS 17 as an example). For any queries, feel free to contact us.
- Go to Settings > General > Trackpad and drag the slider to the middle of the tracking speed.
- Go to Settings > General > Trackpad and turn on “Tap to Click” and “Two Finger Secondary Click”
- Go to Settings > Accessibility > Touch and turn off “Assistive Touch” .



- Go to Settings > Multitasking & Gestures and turn on “Four & Five Finger Gestures”
- Go to Settings > Accessibility >Keyboards and turn off “Full Keyboard Access”

Optional Settings








- Steps to stop Caps Lock changing your keyboard language:
 - Go to Settings > General > Keyboard > Hardware Keyboard and turn off Switch Languages using Caps Lock.
- Steps to disable the double tap period shortcut:
 - Go to Settings > General > Keyboard > Hardware Keyboard and click the switch to turn on “” Shortcut.

Fix Bluetooth Pairing Problems:













- **Step 1:** Go to Settings > Bluetooth, find “Inateck KB04122-11” in My Devices and tap the info button  next to it, then tap “Forget This Device”. If there are multiple pairing records related to the keyboard, please clear all of them.

- **Step 2:** Hold  +  simultaneously for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.
- **Step 3:** Pair your Inateck KB04122-11 with your iPad.

Multi-Touch Gestures

	Drag: Click and hold the item until it lifts up and drag it to another location with another finger.		Scroll: Slide two fingers up or down to scroll.
	Swipe: Swipe left or right with two fingers.		Zoom in or out: Pinch with two fingers to zoom in or out.
	Secondary click: Click or tap with two fingers.		Show desktop: Swipe up with three fingers.
	App Exposé: Swipe up with three fingers and pause.		Swipe between full-screen apps: Swipe left or right with three fingers.

Shortcut Keys

esc	Undo		Brightness-		Brightness+
	Search		Take a screenshot		Switch keyboard layout
	Last track		Play/Pause		Next track
	Mute		Volume-		Volume+
	Lock				

Common Keyboard Shortcuts



⌘ + X	Cut	⌘ + C	Copy	⌘ + V	Paste
⌘ + A	Select all	⌘ + Space	Search	control+Space	Switch keyboard layout
⌘ + Tab	Switch between Apps				

LED Indicator



Indicator	Status	Meaning
Caps Lock Indicator	Solid	Caps Lock on
	Off	Caps Lock off
Bluetooth Indicator	Blinking	Bluetooth Pairing
	Off	Bluetooth connected or unconnected
Battery Indicator- Red	Blinking	Low battery
	Solid	Charging
Battery Indicator- Green	Solid	Fully charged

Restore Factory And Check Battery

Restore Factory Defaults

- Hold  +  simultaneously for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.

Check Battery Level

- Hold  +  simultaneously to check the battery level according to the blinking frequency of the red battery indicator.

Blinking Frequency	Battery Level
Once	0-25%
Twice	25%-50%
Three Times	50%-75%
Four Times	75%-100%

Charging

When the battery level is under 20%, the battery indicator will blink in red. Please recharge the keyboard in time. The recommended charging voltage and current are 5V and 250mA respectively. To recharge the keyboard, you can connect the included USB cable to the charger of your cellphone or the USB port of a computer. The keyboard will be fully charged in 2~3 hours. The indicator will stay in red when the keyboard is charging and turn green when it's fully charged.

Sleep Mode

- When KB04122-11 is left idle for 10 minutes, it will enter sleep mode and the Bluetooth connection will be disrupted. The connection can be rebuilt with a press of any key.

Note: Tapping the trackpad cannot wake up the keyboard.

Product Specification

Bluetooth Version	Bluetooth 5.3
Bluetooth Range	10m
Charging Time	2-3h
Operating Time	About 55h
Operating Temperature	-10°C~ +55°C
Bluetooth Frequency Range	2402-2480MHZ
Actuation Force	60 ± 10g
Battery Capacity	500mAh

Packing List

- KB04122-11 *1
- Charging Cable *1
- Instruction Manual *1

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Users, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

Battery Safety Warning:

This product contains a built-in rechargeable lithium battery. Please observe the following safety precautions: do not dismantle, hit, crush, or expose the battery to fire. If the battery experiences severe swelling, discontinue use immediately. Avoid placing the battery in high-temperature environments, and do not use it if it has been immersed in water. During transportation, do not mix the battery with metallic objects.

EU Declaration of Conformity

Inateck Co., Ltd. hereby declares that this device complies with the Directive 2014/53/EU . A copy of the Declaration of Conformity can be accessed from <https://www.inateck.de/pages/inateck-eurocompliance>.

Service Center

Europe

- F&M Technology GmbH
- **Tel:** +49 341 5199 8410 (Working day 8 AM – 4 PM CET)
- **Fax:** +49 341 5199 8413
- **Address:** Fraunhoferstraße 7, 04178 Leipzig, Deutschland

North America

- Inateck Technology Inc.

- **Tel:** +1 (909) 698 7018 (Working day 9 AM – 5 PM PST)
- **Address:** 2078 Francis St., Unit 14-02, Ontario, CA 91761, USA

For Product and Battery



F&M Technology GmbH

- Fraunhoferstraße 7, 04178 Leipzig, Deutschland
- **Tel:** +49 341 5199 8410
- **Email:** service@inateck.com
- **Postal code:** 04178




Inateck Technology (UK) Ltd.

- 95 High Street, Office B, Great Missenden, United Kingdom, HP16 0AL
- **Tel:** +44 20 3239 9869

Manufacturer

- Shenzhen Inateck Technology Co., Ltd.
- **Address:** Suite 2507, Block 11 in Tian An Cloud Park, Bantian Street, Longgang District, Shenzhen, Guangdong, China
- **Email:** product@licheng-tech.com
- **Postal code:** 518129

Documents / Resources

	<p>inateck KB04122-11 Keyboard [pdf] Instruction Manual KB04122-11, KB04122-11 Keyboard, Keyboard</p>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.