



INTELLINET 561839 5-Port Gigabit Ethernet PoE Plus Switch Instructions

[Home](#) » [INTELLINET](#) » INTELLINET 561839 5-Port Gigabit Ethernet PoE Plus Switch Instructions 



**5-Port Gigabit Ethernet PoE+ Switch
Instructions Model 561839
Important:**



For additional benefits:



Scan to register your product warranty or go to: register.intellinet-network.com/r/561839

Contents

- [1 Instructions](#)
- [2 Installation](#)
- [3 WARRANTY INFORMATION](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Instructions



Connections & Indicators



LEDs

The LED indicators make it easier to monitor the switch and its connections.

NOTE: Ports 1 – 4 can provide power to a connected powered device, and all powered devices should comply with IEEE 802.3at/af.

PWR	Color Green	Status Off	Status Description
			Power Off
		On	Power On
Link/ACT	Yellow	Off	No link established.
		On	Valid port connection.
		Flashing	Sending or receiving data.
Speed	Green	On	A device is connected to the port at 1000 Mbps speeds.
		Off	A device is connected to the port at 10/100 Mbps speeds.
PoE	Green	Off	No PD is connected to the port.
		On	The connected device is receiving power.

Ports

All RJ45 ports on the switch support Auto-MDI/MDI-X functionality, so you can use straight or crossover UTP/STP cables to connect the RJ45 ports to PCs, routers, hubs, other switches, etc. Cat5e/6 UTP/STP cables provide optimal performance; if a status LED doesn't indicate a link or activity, check the corresponding device for proper setup and operation.

Power

Use the included power cord and adapter to connect the device (on the rear panel) to an AC outlet. Confirm that the PWR LED on the front panel is lit.



Installation

Prior to use, it is recommended that the switch be placed/positioned:

- on a level surface that can support the weight of the switch
- with at least 25 mm (approx. 1") of clearance for ventilation;
- away from sources of electrical noise: radios, transmitters, broadband amplifiers, etc.;
- within 100 m (approx. 328') of network devices it's to be connected to.

Chassis Ground Column (Rear Panel)

Wire the grounding terminal to an earth grounding object to protect equipment from external electrical surges.

For specifications, visit intellinetnetwork.com. Register your product at register.
intellinet-network.com/r/561839 or scan the QR code on the cover.

WASTE ELECTRICAL & ELECTRONIC EQUIPMENT

DISPOSAL OF ELECTRIC AND ELECTRONIC EQUIPMENT

(Applicable In The European Union And Other European Countries With Separate Collection Systems)



This symbol on the product or its packaging means that this product must not be treated as unsorted household waste. In accordance with EU Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), this electrical product must be disposed of in accordance with the user's local regulations for electrical or

electronic waste. Please dispose of this product by returning it to your local point of sale or recycling pickup point in your municipality.

WARRANTY INFORMATION

REGULATORY STATEMENTS

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense. Any changes or modifications made to this equipment without the approval of the manufacturer could result in the product not meeting the Class A limits, in which case the FCC could void the user's authority to operate the equipment.

CE : This device complies with the requirements of CE 2014/30/EU and / or 2014/35/EU. The Declaration of Conformity for is available at:

support.intellinet-network.com/barcode/561839



North America

IC Intracom America
550 Commerce Blvd.
Oldsmar, FL 34677
USA

All trademarks and trade names are the property of their respective owners. © IC Intracom. All rights reserved. Intellinet Network Solutions is a trademark of IC Intracom, registered in the U.S. and other countries.

intellinetnetwork.com



Printed on recycled paper.






Documents / Resources



[INTELLINET 561839 5-Port Gigabit Ethernet PoE Plus Switch](#) [pdf] Instructions
561839 5-Port Gigabit Ethernet PoE Plus Switch, 561839, 5-Port Gigabit Ethernet PoE Plus Switch, Gigabit Ethernet PoE Plus Switch, Ethernet PoE Plus Switch, Plus Switch, Switch

References

-  [Intellinet Network Solutions - Provider of PoE and Data Center Product – Intellinet Solutions](#)
-  [DropCatch.com](#)
-  [Intellinet Network Solutions Account and Product Registration](#)

Manuals+.