



IOSiX OBDv5 Vehicle Data Logger User Manual

[Home](#) » [IOSiX](#) » IOSiX OBDv5 Vehicle Data Logger User Manual 



IOSiX OBDv5 User Manual

Contents

- [1 Hardware and Installation](#)
- [2 Regulatory Information FCC Statement](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Hardware and Installation

1. Locate the Diagnostic port on your vehicle. If the Vehicle uses J1939 use the optional 16 pins to 9 pin adapter
2. Plug in the ELD device into the port – the LED should light up indicating the device is powered up
3. Turn on vehicle ignition
4. A Blue or Green blinking LED will indicate that the device is powered up and communicating with the vehicle

Regulatory Information FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Radiation Exposure Statement: This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment in accordance with FCC rule part 2.1093 and KDB 447498 D01. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

ID Statement


This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada’s license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Radiation Exposure Statement: This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment in accordance with FCC rule part §2.1093 and KDB 447498 D01 and RSS 102. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

Documents / Resources

	<p>IOSIX OBDv5 Vehicle Data Logger [pdf] User Manual 2050, 2AICQ-2050, 2AICQ2050, OBDv5 Vehicle Data Logger, Vehicle Data Logger, Data Logger, Logger</p>
---	---