

# **IQUNIX OG80 Wireless Mechanical Keyboard Instruction Manual**

Home » IQUNIX » IQUNIX OG80 Wireless Mechanical Keyboard Instruction Manual





#### **Contents**

- 1 OG80 Wireless Mechanical Keyboard
- **2 LED Indicator Status Description**
- **3 Three Ways of Connecting Devices**
- **4 Special Keys Combinations**
- 5 Backlight Keys Combinations (Short

Press)

- **6 Keyboard Layout**
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**

### **OG80 Wireless Mechanical Keyboard**

We recommend that you read this manual thoroughly before using the product. Start Reading→



LED Indicator Status Description



Red Light Blinking	Blue Light Blinking / Flashing	Turquoise Light Blinking / Flashi ng	Yellow Light Blinking / Flashin g	Pink Light Blinking / Flashi ng	White Light On / Blinking
Low Battery Level	Bluetooth Device #1 Re-Connecting / Pairing On	Bluetooth Devic e #2 Re-Connecting / Pairing On	Bluetooth Device #3 Re-Connecting / Pairing On	2.4GHz Device Re-Connecting / Pairing On	Caps Lock On & O ff / Special Keys Combination Enabl ed

first then corresponding keys to enable special keys combination.

Short Press: Hold FN first, then the corresponding key, and release both keys.


Long Press: Hold FN first, then the corresponding key. Hold for 5 seconds until the indicator starts blinking.



## Three Ways of Connecting Devices

#### **Bluetooth Mode**


- to make the indicator blink in blue, then Long Press 2. Short Press flash in blue.
- 3. Select the pairing device [IQUNIX OG80 BT 1]. The indicator turns off when the keyboard is paired successfully.



In order to complete the pairing of the keyboard with a second or third new Bluetooth device, repeat the instructions from Step 2 and replace the "FN+1" with "FN+2" or "FN+3". The devices will be shown as [IQUNIX OG80 BT 2] and [IQUNIX OG80 BT 3].

#### 2.4GHz Mode


- 1. Toggle the keyboard Mode Switch to the wireless side. (4)
- 2. Plug the 2.4GHz receiver into your computer.



3. Press to enter 2.4GHz pairing mode. The indicator turns off when the keyboard is paired successfully.

#### **Wired Mode**

- 1. Toggle the keyboard Mode Switch to the wired side. ((7))
- 2. Plug the USB cable into your device.




\*Please find the 2.4GHz receiver under the magnetic cover of OBSC (On-Board Storage Compartment).

## **Special Keys Combinations**




<sup>\*</sup>Caution: The rated power for the charger must not exceed 5V===1A. Connection to a higher power output will damage the keyboard.



## **Backlight Keys Combinations (Short Press)**






FN+ ↑: Backlight Speed + FN+ ↓: Backlight Speed -

\*Available for Backlit version only.

## **Keyboard Layout**



Follow us: IQUNIX









To learn more details, please reach out to us on official website or social media. Official website: www.IQUNIX.store

Series: OG80

Number of Keys: 83 Input: 5V === 1A

Battery Specifications: 3.7V 4000mAh Precautions: See Warranty Card

Manufacturer: Shenzhen Silver Storm Technology Co., Ltd.

A905, Rongchaobinhai Bldg., Haixiu Rd., Bao'an District, Shenzhen, China

Packing List: Keyboard, Dust Cover, USB Cable, 2.4GHz Receiver, Keycap & Switch Puller, Bluetooth Dongle,

Manual, Warranty Card

https://manual-hub.com/

#### **Documents / Resources**



IQUNIX OG80 Wireless Mechanical Keyboard [pdf] Instruction Manual OG80 Wireless Mechanical Keyboard, OG80, Wireless Mechanical Keyboard, Mechanical Keyb oard, Keyboard

### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.