Home » JimiloT » JimiloT PB704 Micro Smart Chip User Guide Ta

JimiloT PB704 Micro Smart Chip User Guide

Contents

- 1 JimiloT PB704 Micro Smart Chip
- **2 Product Specifications**
- **3 Product Appearance**
- **4 Product specifications**
- 5 Instructions for use
- **6 Battery Replacement**
- **Instructions**
- 7 Important reminders
- 8 FAQ
- 9 FCC
- **10 Frequently Asked Questions**
- 11 Documents / Resources
 - 11.1 References



JimiloT PB704 Micro Smart Chip




• Battery: 210mAh CR2032 disposable button cell battery

Device Size: 9.2*38mmWorking Voltage: 3V

Operating Temperature: 0 to 60°C
 Indicator Light: Red and green

Please read the Quick Use Guide carefully before use. Appearance, color and accessory are all subject to change without notice.

Product Appearance



Product specifications

• Battery: 210mAh CR2032 disposable button cell battery


Device size: 9.2 *Φ38mm
Working Voltage: 3V

• Operating temperature: 0°C to 60°C

• Indicator light: Red and green

Instructions for use

1. Pull out the battery insulator, and then the device will be turned on immediately.




2. Contact the selling company to download the device management APP and bind the device to manage the device. When you bind the device, you need to turn on the Bluetooth of the cell phone and bring the device close to the cell phone to make it convenient to bind it quickly and successfully.

Battery Replacement Instructions

- 1. The unit uses a CR2032 battery.
- 2. Please use a pry bar or other tools to separate the upper and lower cover through the grooves on the top.



3. Choose the battery purchased from a regular supplier and insert it in the direction indicated by the arrow on the main board.



4. After replacing the new battery, you need to open the bound cell phone application and approach the device to synchronize the battery status.

Note: Please do not immerse the battery in water or put it into fire, please do not destroy or force open the battery, the battery is disposable and does not allow charging! To protect the environment, please recycle the used battery.



WARNING: KEEP BATTERIES AWAY FROM CHILDREN

Swallowing may lead to serious injury or death in 2 hours, due to chemical burns and potential perforation of the oesophagus.

If you suspect your child has swallowed or inserted a button battery, immediately call the 24-hour Poison Information Centre for emergency specialist advice.

Important reminders

- 1. Battery lifetime varies depending on individual usage habits. Frequent audible searching will accelerate the consumption of the battery.
- 2. To ensure better dustproof and waterproofing, after installation, please be sure to press the upper and lower covers to ensure that the equipment is sealed.
- 3. Because the device adopts a crowdsourcing network, there may be a delay in positioning, such as the management platform and APP having no data, you can wait for half an hour to refresh the location information. And try to open the device in a place where there are more cell phones.
- 4. Please do not disassemble the device, improper handling by non-professionals may cause damage to the device.

· How to confirm that the device has been turned

• There will be a buzzer reminder after powering on, accompanied by flashing LEDs.

· How to turn off the device?

 The device has low power consumption and can not be shut down, if you need to shut down the device, you need to pull out the battery.

FCC

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference,
- 2. this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Frequently Asked Questions

• How can I confirm if the device is turned on?

• A buzzer reminder and flashing LEDs indicate that the device is powered on.

· Can I turn off the device?

 The device has low power consumption and does not have a power-off function. To shut it down, remove the battery.

Documents / Resources



<u>JimiloT PB704 Micro Smart Chip</u> [pdf] User Guide PB704 Micro Smart Chip, PB704, Micro Smart Chip, Smart Chip, Chip

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.