JJC BTR-S1 Wireless Remote Control Instruction Manual

BTR-S1
WIRELESS REMOTE CONTROL

Instruction Manual

http://www.jjc.cc

Thank you for purchasing the JJC BTR-S1 Wireless Remote Control. For the best performance, please read this instruction carefully before using. You must read it thoroughly and fully understand this manual to avoid improper operation which may result in damage to the product.

The JJC BTR-S1 Wireless Remote Control is compatible with Bluetooth low energy technology, which is specially designed for select Sony cameras. It allows you to remote your camera wirelessly with an operating distance of approx. 10m / 32.8′ in any direction. The BTR-S1 can be used for shooting still image, recording video, adjusting camera focus, zooming the camera and activating the camera's C1 or AF-ON function. You can disable all the buttons on the remote control in order to prevent unintentional operations while you carry it around by sliding the LOCK switch to the "LOCK" position. The remote is portable and you can put it in your pocket or hang it on your key ring. It is powered by a CR2032 battery (included). JJC BTR-S1 replaces Sony RMT-P1BT remote commander.

Contents

WARNING

- Do not use any batteries not specified in the instruction manual.

- Do not insert the battery's plus and minus ends incorrectly.

- Do not disassemble or attempt to repair it.

- Keep the battery and battery cover, etc. out of the reach of children and infants. If a child or infant swallows the battery or battery cover, etc. consult a physician immediately.

- Before using the product inside an airplane or hospital, check if it is allowed. Electromagnetic waves emitted by the product may interfere with the plane's instruments or the hospital's medical equipment.

- A thorough explanation of how to use the product by an adult is required when the product is used by children. Supervise children while they are using the product.

- Do not expose the product to high temperature over 45°C (e.g. left in a car trunk).

- The product is not waterproof. Please keep it away from rain, snow and high humidity conditions.

- Do not clean the product with organic solvent or alcohol-based liquid.

PACKAGE INCLUDES

Wireless Remote Control	X1
CR2032 Battery	X1
Drahtlose Fernbedienung	X1
CR2032 Batterie	X1
CR20321	X1

SPECIFICATIONS

Transmission method: Bluetooth, GFSK modulation
Operating distance: Approx. 10m / 32.8′
Power: CR2032 battery
Dimension: Approx. 110 x 31.6 x 12.7mm (4.3 x 1.2 x 0.5″)
Weight: Approx. 18g

PARTS

1. Indicator Lamp
2. FOCUS/ZOOM Button
3. Shutter Release/Video Recording Button
4. AF-ON Button
5. C1 Button
6. LOCK Switch
7. ZOOM/FOCUS Switch
8. MOVIE/STILL Switch
9. Battery Compartment

INSERTING THE BATTERY

1. Place a coin, or similar object, into the groove of the battery cover on the back of the remote, and then turn the battery cover to I position.

2. Remove the battery cover and insert the supplied CR2032 battery with "+" mark side upward.

3. Turn the battery cover until you reach • position.

CONNECTING THE REMOTE CONTROL AND CAMERA

Before you start, please check that the remote control's LOCK switch is in the position to opposite of "LOCK".

1. On the camera, select MENU > [Bluetooth Function] —> [On]
2. On the camera, select MENU —> [On]
3. On the camera, select MENU —. [Pairing]
4. On the remote control, press and hold the Shutter ReleaseNideo Recording Button and the FOCUS/ZOOM Button (T button) at the same time for at least 7 seconds.
5. When a confirmation message appears on the camera's screen, select [OK]. When pairing is complete, [Paired.] appears.
   In the following situations, pair the remote control and the camera again. ()When using the remote control to operate a different camera (After having connected the remote control with a different camera, you also must pair the remote control and the original camera again when connecting to the original camera) ®When the camera's network settings have been reset

PREVENTING UNINTENTIONAL OPERATIONS

You can mama all me outtons on me remote 0011V01 in oraer to prevent unintentional operations while you carry it around.

1. Slide the LOCK switch to the 'LOCK' position.

2. To enable the buttons. slide the LOCK switch to the position to the opposite of "LOCK".

FCC Warning:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is
encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirements. Th e device can be used in portable exposure conditions without restriction.

Documents / Resources

JJC BTR-S1 Wireless Remote Control [pdf] Instruction Manual
BTR, 2APWR-BTR, 2APWRBTR, BTR-S1 Wireless Remote Control, BTR-S1, Wireless Remote Control