

JOOM
DB-01 Smart
Video
Doorbell



JOOM DB-01 Smart Video Doorbell User Guide

[Home](#) » [JOOM](#) » JOOM DB-01 Smart Video Doorbell User Guide 

Contents

- 1 JOOM DB-01 Smart Video Doorbell
- 2 Product Information
- 3 Product Usage Instructions
- 4 FAQ
- 5 Appearance
- 6 APP INSTALLATION AND USE
- 7 FCC Statement
- 8 INSTALLATION AND FIXATION OF DOORBELL
- 9 USE AND DESCRIPTION OF DING DONG MACHINE
- 10 MATCHING OF DINGDONG MACHINE AND DOORBELL
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts



JOOM DB-01 Smart Video Doorbell



Product Information

Specifications:

- **Model:** DB-01
- **Compliance:** FCC Radiation Exposure Limits
- **Minimum Distance:** 20cm between the radiator and the body

Product Usage Instructions

1. **Installation:** Ensure the equipment is installed in a well-ventilated area.
2. **Operation:** Power on the equipment and maintain a minimum distance of 20cm between the radiator and your body during operation.
3. **Maintenance:** Regularly clean the equipment to prevent dust build-up that may impact performance.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. It is important to follow the guidelines to ensure safe usage.

Safety Precautions:

Do not operate the equipment closer than 20cm to your body to minimize radiation exposure.

FAQ

- **Can I use the equipment closer than 20cm to my body?**


No, it is recommended to maintain a minimum distance of 20cm between the radiator and your body to comply with FCC regulations and ensure safety.

- **How often should I clean the equipment?**

It is advisable to clean the equipment regularly to prevent dust accumulation. Depending on usage, cleaning

once a month is recommended.

Appearance



• Doorbell:

- 1) Shipping mark
- 2) camera lens
- 3) photosensitive
- 4) Doorbell key
- 5) pilot lamp
- 6) Reset hole
- 7) Doorbell horn
- 8) Charging port

• Dingdong:

- 9) pilot lamp
- 10) Dingdong horn
- 11) Pairing key
- 12) Volume level
- 13) Music switching
- 14) USB connector

APP INSTALLATION AND USE

APP download and installation

- **Method 1:** Use WeChat/browser, scan QR code, download and install applications;



- **Method 2:** Search “Linklemo” in Apple Store/Google Play/Mobile App Store and Install it.



APP icon : “Linklemo”

APP connection

1. Open the APP and register to log in.
2. Press the doorbell for 10s for voice prompt: The device has been reset, Please turn on the Bluetooth to connect to the network! (Enter distribution network mode).
3. Click the Add Device(+) and automatically scan devices (Picture 1) until the device is scanned, and click “Add” to bind immediately (Picture 2). Select 2.4GHz WiFi, select your WiFi, and enter the WiFi password (Picture 3).
(**Note:** 5G WiFi and Figure 3 are not supported).



(Picture 1)




(Picture 2)



(Picture 3)

4. There will be a voice prompt after successful binding: The device bound successfully!
5. Enter the device naming interface (Figure 4), After editing, you can view it on the APP homepage.



(Picture 4)



(Picture 5)

If the equipment cannot be added for a long time, the device voice prompts: The network connection failed. Please reset the device! (Long press the doorbell key for 10 seconds to re-enter the distribution network mode)

APP Instruction

1. **Video call:** when a visitor presses the doorbell, the APP will receive a message sent from the device, then can talk to the visitor via video;
2. **Doorbell sharing:** the added device can be shared with others on the APP; The one to be shared needs to download the “Linklemo” APP and register to log in.
3. **Low battery and charging:** When the battery is low, the bound client-side will receive a low battery reminder (After receiving the low battery warning notice, please replace the battery in time to avoid affecting the use).

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


1. This device may not cause harmful interference
2. this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

INSTALLATION AND FIXATION OF DOORBELL

- **Method 1:** stick the double-sided adhesive tape on the back of the machine, and choose an appropriate height on the wall to stick tightly and fix it (Figure 1) –



(Figure 1)

- **Method 2:** Drill holes at appropriate places on the wall, insert anchors(wood is unnecessary to drill holes, directly screw in), fix the back cover with large screws, then fix the doorbell on the back cover and lock the bottom screws (Figure 2).




(Figure 2)

USE AND DESCRIPTION OF DING DONG MACHINE



MATCHING OF DINGDONG MACHINE AND DOORBELL

- **Step 1:** Plug the Ding dong machine into the 5V USB interface and get power (Diagram);



- **Step 2:** Press the Match button on the Ding Dong machine for 2 seconds to enter matching mode, and turn the red indicator light on;
- **Step** the doorbell's ring buttoning button again and wait match succeed. There light on the Ding dong machine will then be off.

ATTENTION

1. Ensure the WiFi network is in good condition, and set permissions through the APP to use the product normally;
2. Try not to install it on a metal door;
3. In the process of ding-dong matching, the doorbell should be as close to the Ding dong machine as possible;
4. Ensure the doorbell battery is sufficient;
5. If the doorbell button is not pressed within 10 seconds after the thing-doing machine enters matching mode, the changing mode will be finished and the light will be off. If the matching fails, please try again;
*After the Ding dong machine is successfully connected to the doorbell, when the visitor represses the doorbell, The dong machine will ring and immediately respond to the APP on your phone.

Documents / Resources

	<p>JOOM DB-01 Smart Video Doorbell [pdf] User Guide DB-01, DB-01 Smart Video Doorbell, Smart Video Doorbell, Video Doorbell, Doorbell</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.