

Keychron K10 Pro Wireless Custom Mechanical Keyboard Instruction Manual

Home » Keychron » Keychron K10 Pro Wireless Custom Mechanical Keyboard Instruction Manual



Contents

- 1 Keychron K10 Pro Wireless Custom Mechanical Keyboard
- **2 INSTRUCTION**
- 3 IN THE BOX
- **4 QUICK START GUIDE**
- **5 The Layers**
- **6 Factory Reset**
- 7 K10 PRO BLUETOOTH MECHANICAL KEYBOARD
- **SPECIFICATIONS**
- **8 K10 PRO BLUETOOTH MECHANICAL KEYBOARD OVERVIEW**
- 9 DEFAULT KEY LAYOUT
- **10 KEY DESCRIPTION**
- 11 FUNCTION DESCRIPTION
- 12 BLUETOOTH / WIRED MODE (MODE TOGGLE SWITCH)
- 13 TROUBLESHOOTING
- 14 Safety Precaution
- 15 Documents / Resources
 - 15.1 References
- **16 Related Posts**



Keychron K10 Pro Wireless Custom Mechanical Keyboard



INSTRUCTION

- Search "white backlight" here to download the JSON file if VIA does not automatically recognize keymap of the K10 Pro: https://www.keychron.com/blogs/archived/k10-pro-factory-reset-and-firmware-flash
- VIA Software for macOS, Windows, Linux: https://usevia.app/#/
- How to Use VIA on Your Keychron K Pro Series Keyboard: https://www.keychron.com/blogs/archived/how-to-use-via-to-program-your-keyboard


K10 Pro Source Code, please search "source code" on the product page on our official website.

IN THE BOX


- Keychron K10 Pro Bluetooth Mechanical Keyboard × 1
- Type-C Cable × 1
- Manual × 1
- Quick Start Guide × 1
- Extra Keycaps Set × 1

QUICK START GUIDE

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.



1 Connect Bluetooth



Switch toggle to Cable

The VIA Key Remapping Software

Please visit caniusevia.com to download the latest VIA software to remap the keys. If the VIA software cannot recognize your keyboard, please reach out to our support to get the instruction. (VIA only works when the keyboard is connected by wire to the computer.)


The Layers

- There are four layers of key settings on the keyboard. The layer O and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.
- If your system toggle is switched to Mac, then the layer O will be activated.
- If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a


common mistake people are making.




5 The Backlight



6 Adjust The Backlight Brightness



Press fn + S to decrease the backlight brightness




Activate Siri / Cortana

For Siri on Mac: Go to System preferences> Siri > select "Hold Command Space" option.

*Siri key only works on macOS and does not work on iOS.



For Cortana on Windows: Select Start > Settings > Cortana and select the shortcut by pressing Windows key+ C key.



Warranty


The keyboard is highly customizable and easy to be rebuilt.

If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.

Watch The Building Tutorial On Our Website

If you are building the keyboard for the first time, we highly recommend you watch the building tutorial video on our website first, then start building the keyboard yourself.

Factory Reset



Troubleshooting? Don't know what's going on with the keyboard?

- 1. Plug in the power cable and switch the keyboard to Cable mode.
- 2. Factory reset the keyboard by pressing fn + J + Z (for 4 seconds).
- 3. Download the right firmware and QMK Toolbox from our website.
- 4. Switch the keyboard to OFF mode and remove the space bar keycap to find the reset button on the PCB.
- Hold the reset key first, then switch the keyboard to Cable mode.Release the reset key, and the keyboard will now enter DFU mode.
- 6. Flash the firmware with the QMK Toolbox.

- 7. Factory reset the keyboard again by pressing fn + J + Z (for 4 seconds).
 - * Step by step guide can be found on our website.

K10 PRO BLUETOOTH MECHANICAL KEYBOARD SPECIFICATIONS

• Number of keys: 108

· Switch type: Mechanical

· Battery: 4000mAh

• Bluetooth working time (RGB): Up to 100 hours (Lowest brightness)

· Charging time: Around 3 hours

· Charging port: USB Type-C

· Mode: Bluetooth / Wired


• Bluetooth operating distance: Within 10 meters (open space)


• Name of Bluetooth device: Keychron K10 Pro


Operating Environment: -10 to 50°c

 Technical specifications can be subjected to change without notice we apologize for any inconvenience caused.

K10 PRO BLUETOOTH MECHANICAL KEYBOARD OVERVIEW









- 1. Charging indicator
- 2. Bluetooth indicator
- 3. Caps Lock indicator
- 4. Charging port
- 5. Win/Android Mac/JOS (OS Toggle Switch)
- 6. BT OFF Cable (Mode Toggle Switch)

DEFAULT KEY LAYOUT


LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.



LAYER 1: This layer will be activated when your keyboard's system toggle is switched to Mac and press the fn/M0(1) key.




LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Windows.



LWin = Left Windows LAlt = Left Alt RAlt = Right Alt RWin = Right Windows RCtl = Right Ctrl

LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn/M0(3) key.



KEY DESCRIPTION

Key Description		Key Description	
Scr-	Screen Brightness Decrease	RGBMd-	RGB Mode Previous
Scr+	Screen Brightness Increase	Hue+	Hue Increase
Bright-	Backlight Decrease	Hue-	Hue Decrease
Bright+	Backlight Increase	RGB SPI	RGB Speed Increase
Prvs	Previous	RGB SPD	RGB Speed Decrease
Play	Play/Pause	MO(1)	Layer 1 will be activated when holding this key
Next	Next	MO(2)	Layer 2 will be activated when holding this key
Mute	Mute	MO(3)	Layer 3 will be activated when holding this key
Vol-	Volume Decrease	MO(4)	Layer 4 will be activated when holding this key
Vol+	Volume Increase	BTH1	Bluetooth Host 1
RGB Toggle	Turn Backlight on/off	BTH2	Bluetooth Host 2
RGBMd+	RGB Mode Next	втнз	Bluetooth Host 3

LED STATUS OVERVIEW

LED Location	Function	Status
Battery indicator	Charging	Low battery – Blinking Red Charging – Static Red Fully charged – Static Green
Bluetooth indicator	Bluetooth	Pairing – Slow Blinking Paired – Light Off Swit ching – Fast Blinking

FUNCTION DESCRIPTION

CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Charging Indicator: When battery is below 15%, a red battery blinking indicator will be triggered. A red light will stay on while charging; Fully charged in around 3 hours, a green battery indicator will appear.

- *The Keychron keyboard is compatible with all USB ports. Please use a SV 2A adapter or USB 3.0 for the best performance. The Keychron KIO Pro can be charged in Bluetooth/on/off mode.
- **This product supports up to SV charging voltage and 2A charging current. We are not responsible for any problems caused by improper charging.

BLUETOOTH / WIRED MODE (MODE TOGGLE SWITCH)

WIRED MODE

- 1. Switch the toggle switch to the Cable option (it only works when a USB cable is plugged in).
- 2. Connect our cable with your PC and keyboard.
- 3. Backlighting will be turned on. *Under Wired Mode, keyboard will not enter into Battery Saver Mode.

BLUETOOTH MODE

- 1. Switch the toggle switch to the Bluetooth option.
- 2. Backlighting will be turned on.
- 3. Hold "fn+ 1" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
- 4. Search for the Bluetooth device "Keychron K10 Pro" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

Note: This keyboard supports pairing up to 3 devices simultaneously via key combination "fn" + "1" / "In" + "2" / "fn" + "3". *The Bluetooth indicator will continue to flash for 3 minutes. **Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.

SWITCH BLUETOOTH DEVICES

Short press key combination "n" + "l" / "fn" + "2" / "fn" + "3" to switch to other device.

RECONNECT:

- 1. Switch the keyboard to the Bluetooth option to activate the keyboard.
- 2. The Bluetooth indicator flashes for 4 seconds and automatically pairs with the last paired device.
- 3. If the Bluetooth indicator is off, press any button to enter the connection again.

TURN OFF THE KEYBOARD

Switch the keyboard to the OFF option.

BACKLIGHT SETTING

- Short press[:] to switch between different types of lighting effects.
- When backlighting is on, press[:] button to switch among them.

OS TOGGLE SWITCH

1. MAC/iOS

Switch the toggle to Mac/iOS when the keyboard is connected to a Mac or iOS operating system.

2. WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system.

*When using the Windows/ Android mode, 0[[] keys are used for "Windows" and "Alt" functions.

3. INPUT METHOD SWITCH

- 1. For iOS: Input method switch: Ctrl + Space Caps Lock: Caps (Enable General> Keyboards> Hardware Keyboard>Caps Lock Language Switch)
- 2. For Android: Input method switch: Shift + Space
- 3. NOTE: Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS. We also recommend not to switch OS frequently as it may impact keyboard operations.

TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again. Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates-a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

- Go to Bluetooth Devices > Open Settings and select the following:
- · Allow Bluetooth devices to find this computer
- Allow Bluetooth devices to connect to this computer
- Alert me when a Bluetooth device wants to connect

My keyboard isn't working.

For the computer/smartphone: Go to your device Bluetooth settings>Select the keyboard and

^{*} The keyboard must have been paired with the device to perform this function.

remove/delete/unpair it. Then restart your device.

For the keyboard:

Turn the keyboard off and back on. Then reconnect it to your device.

Third-party input tools may be affected while using the keyboard.

Please make sure your operating system and drivers are up to date. Certain multimedia keys or function keys do not work. Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

*Multimedia keys:

☆/☆/20/88/ヘニン//01/▷▷/ロ/切/切)

Function keys:

F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

Safety Precaution

Keep the product, accessories and packaging parts out of the reach of children to prevent any accidents and choking hazards. Always keep the product dry to avoid corrosion. Do not expose the product to extreme temperatures below -10°C(5°F) or above 50°C(131°F) to preserve the lifespan of the keyboard.

Keychron, Inc. Dover, DE 19901, United States

Find us at: https://www.keychron.com

Support@keychron.com

Documents / Resources

(S) Keychron K10 Pro Bluetoeth Mechanical Kryboard	Keychron K10 Pro Wireless Custom Mechanical Keyboard [pdf] Instruction Manual K10 Pro Wireless Custom Mechanical Keyboard, K10 Pro, Wireless Custom Mechanical Keyboard, Custom Mechanical Keyboard, Keyboard, Keyboard	
Quida Sourt Galde	Keychron K10 Pro Wireless Custom Mechanical Keyboard [pdf] User Guide K10 Pro Wireless Custom Mechanical Keyboard, K10 Pro, Wireless Custom Mechanical Keyboard, Custom Mechanical Keyboard, Keyboard, Keyboard	
Köyyühron K10 Pro Bluetosth Michanical Koyleand	Keychron K10 Pro Wireless Custom Mechanical Keyboard [pdf] Instruction Manual K10 Pro Wireless Custom Mechanical Keyboard, K10 Pro, Wireless Custom Mechanical Keyboard, Custom Mechanical Keyboard, Mechanical Keyboard, Keyboard	

References

- 🐸 VIA
- Mow to use VIA to program your keyboard Keychron | Wireless Mechanical Keyboards for Mac, Windows and Android
- ® K10 Pro Factory Reset and Firmware Flash Keychron | Wireless Mechanical Keyboards for Mac, Windows and Android
- User Manual

Manuals+,