

Klipsch REMOTE 100 Flexus Soundbar System User Manual

Home » Klipsch » Klipsch REMOTE 100 Flexus Soundbar System User Manual



Contents

- 1 IMPORTANT SAFETY INSTRUCTIONS
- **2 FCC AND CANADA EMC COMPLIANCE INFORMATION**
- **3 REMOTE**
- 4 Advanced Functionality
- **5 CONNECTIONS HDMI**
- **6 CONNECTIONS DIGITAL OPTICAL**
- 7 CONNECTIONS EXTERNAL HDMI SOURCE THROUGH

TV

8 CONNECTIONS – EXTERNAL AUDIO VIA DIGITAL

OPTICAL

- 9 ADJUSTING BASS LEVEL
- 10 Documents / Resources
 - 10.1 References

IMPORTANT SAFETY INSTRUCTIONS

- 1. Read these instructions
- 2. Keep these instructions
- 3. Heed all warnings
- 4. Follow all instructions
- 5. Do not use this apparatus near water
- 6. Clean only with dry cloth.
- 7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
- 8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- 12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tipover.



13. Unplug the apparatus during lightning storms or when unused for long periods of time. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been

exposed to rain or moisture, does not operate normally, or has been dropped.

FCC AND CANADA EMC COMPLIANCE INFORMATION

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Any Changes or modify cations not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit diff erent from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- 1. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:


- 1. This device may not cause interference; and
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

REMOTE

CONTROL REMOTO



- On/Of
- LEDs High/Low
- Source Select Selects HDMI eARC Input
- Play/Pause
- Source Select Selects Optical Input
- Bluetooth® Source Select Long press to enter Bluetooth pairing mode

• ((SURR)) Surround Level

Adjusts channel levels.

FH - Front Height

If surrounds present:


SL - Side Left Surround

SR - Side Right Surround


BASS Bass Level

Adjusts Bass equalizer value.

Use [Vol +] and [Vol -] to adjust.



Mute Decrease Volume



1. Sound Mode

Cycles through available Sound Modes. Movie (default) is highly

2. Dialog Boost

Toggles through Off, Low, Medium, High

3. Night Mode

Enables/disables Night Mode.

Advanced Functionality




Displays decoding mode.






Exits Surround adjust mode.




CONNECTIONS – HDMI


TV REAR PANE




CONNECTIONS – DIGITAL OPTICAL




CONNECTIONS – EXTERNAL HDMI SOURCE THROUGH TV



CONNECTIONS – EXTERNAL AUDIO VIA DIGITAL OPTICAL



ADJUSTING BASS LEVEL



Documents / Resources



Klipsch REMOTE 100 Flexus Soundbar System [pdf] User Manual

REMOTE 100 Flexus Soundbar System, REMOTE 100, Flexus Soundbar System, Soundbar System

References

- Speakers, Headphones, and Premium Home Audio | Klipsch
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.