

KOLINK Unity Code X ARGB Midi Tower Case User Manual

Home » KOLINK » KOLINK Unity Code X ARGB Midi Tower Case User Manual



Contents

- 1 KOLINK Unity Code X ARGB Midi Tower Case
- **2 ACCESSORY PACK CONTENTS**
- **3 PANEL REMOVAL**
- **4 MOTHERBOARD INSTALLATION**
- **5 POWER SUPPLY INSTALLATION**
- **6 GRAPHICS CARD/PCI-E CARD**

INSTALLATION


- 7 2.5" SDD INSTALLATION
- 8 2.5" SDD INSTALLATION
- 9 3.5" HDD INSTALLATION
- **10 TOP FAN INSTALLATION**
- 11 FRONT/REAR FAN INSTALLATION
- 12 WATERCOOLING RADIATOR INSTALLATION
- 13 I/O PANEL INSTALLATION
- 14 Documents / Resources
- 15 Related Posts



KOLINK Unity Code X ARGB Midi Tower Case




ACCESSORY PACK CONTENTS




PANEL REMOVAL

- Remove the left side panel by removing the four thumbscrews and lifting the glass panel away.
- Remove the right-side panel by removing the two rear thumbscrews and sliding the panel backward.
- To remove the front panel, remove the right-hand side plastic panel first (being careful with the I/O wiring) and unscrew the two screws on the glass panel, before lifting away from the chassis




MOTHERBOARD INSTALLATION

- Align your motherboard with the chassis to locate where the stand-offs should be installed. Once done, remove the motherboard and fasten stand-offs accordingly.
- Insert your motherboard I/O plate into the cutout at the rear of the case.
- Place your motherboard into the chassis, making sure the rear ports fit into the I/O plate.
- Use the provided motherboard screws to attach your motherboard to the chassis.




POWER SUPPLY INSTALLATION

- Place PSU in the bottom rear right side of the case, within the rear chamber.
- Align the holes and secure them with screws.




GRAPHICS CARD/PCI-E CARD INSTALLATION

- Remove the rear PCI-E slot covers as necessary (depending on the slot size of your card)
- Carefully position and slide your PCI-E card into place, then secure it with the add-on card screws supplied.
- If mounting vertically, attach the provided vertical GPU bracket to the PSU shroud, secure your Kolink PCI-E riser cable to it (sold separately), and attach the cable to the motherboard. Remove the rear PCI-E slot covers as necessary, then carefully position your PCI-E card, slot into the PCI-E riser mount, and secure with the add-on screws supplied.




2.5" SDD INSTALLATION

Mount your SSDs onto the bottom of the HDD/SSD bracket and secure using screws.




2.5" SDD INSTALLATION

Align the 2.5" HDD/SSD with the screw holes on the top right-hand side of the rear of the chassis and mount using screws (please note, only 2 screws can be used to mount the SSDs in this position).



3.5" HDD INSTALLATION

Mount your HDD to the bracket using the supplied screws and rubber grommet




TOP FAN INSTALLATION

- Remove the dust filter from the top of the case.
- Align your fan(s) to the screw holes on the top of the chassis and secure it with screws.
- Replace your dust filter once secured.




FRONT/REAR FAN INSTALLATION

Align your fan to the screw holes on the chassis and secure it with screws



WATERCOOLING RADIATOR INSTALLATION

Secure the fans to the radiator, then fasten the radiator inside the chassis by securing it with screws from the outside.



I/O PANEL INSTALLATION

- Carefully check the labeling of each connector from the I/O panel to identify their function.
- Cross-reference with the motherboard manual to locate where each wire should be installed, then secure one at a time. Please ensure they are installed in the correct polarity to avoid non-function or damage.

Documents / Resources



KOLINK Unity Code X ARGB Midi Tower Case [pdf] User Manual Unity Code X ARGB Midi Tower Case, Unity Code X, ARGB Midi Tower Case