

# KRAMER RC-10TB 1 Button Contact Closure Switch User Manual

[Home](#) » [Kramer](#) » KRAMER RC-10TB 1 Button Contact Closure Switch User Manual 

## Contents

- [1 KRAMER RC-10TB 1 Button Contact Closure Switch](#)
- [2 important information](#)
- [3 Instructions for use](#)
- [4 Customer support](#)
- [5 SAFETY WARNING](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

**KRAMER RC-10TB 1 Button Contact Closure Switch**




### important information

Congratulations on purchasing your Kramer **RC-10TB** single slot wall plate insert 1-Button Contact Closure Switch which is ideal for using as a means of remote control in boardrooms and conference rooms. It can be used with the **SID-X1** step-in commander or any other Kramer product with contact closure control.

### Instructions for use

The **RC-10TB** front panel has one momentary switching button. On the rear are remote momentary contact closure terminal block connectors that connect to a remote switch terminal block connector.

**Figure 1** shows the **RC-10TB** front panel and the pinout on the rear:



**Figure 1:** RC-10TB Front Panel and Rear

The RC-10TB can remotely take control of the input of a machine via its remote contact closure terminal blocks. For example, you can connect the RC-10TB to the REMOTE STEP-IN contact closure terminal block connectors of the Kramer SID-X1 Step-In Commander (download the up-to-date Kramer user manual at: [www.kramerelectronics.com](http://www.kramerelectronics.com)), to remotely take control of the input of the attached switcher, as well as a remote step-in LED to the REMOTE STEP-IN terminal block on the rear panel of the SID-X1.

**Figure 2** shows the pinout of the SID-X1 REMOTE STEP IN terminal block connector connected to the rear panel of RC-10TB terminal block connector.

# SID-X1




Figure 2: RC-10TB connected to an SID-X1 Unit

To connect the **RC-10TB**, as illustrated in the example in **Figure 2**:

1. Connect the first REMOTE STEP-IN pin (from the left side) to the anode pin of the **RC-10TB**.
2. Connect the second REMOTE STEP-IN pin to the switch pin on the **RC-10TB**.
3. Connect the GND REMOTE STEP-IN pin to the GND pin on the **RC-10TB**.

Momentarily pressing the button on the RC-10TB activates the STEP-IN process.

Button Contact Closure Switch

## Customer support



For the latest information on our products and a list of Kramer distributors, visit our Web site where updates to this user manual may be found.

We welcome your questions, comments, and feedback.

Web site: [www.kramerelectronics.com](http://www.kramerelectronics.com)

E-mail: [info@kramerel.com](mailto:info@kramerel.com)

SAFETY WARNING



- Disconnect the unit from the power supply before opening and servicing.



Documents / Resources

	<p><a href="#">KRAMER RC-10TB 1 Button Contact Closure Switch</a> [pdf] User Manual RC-10TB 1 Button Contact Closure Switch, RC-10TB, 1 Button Contact Closure Switch, Contact Closure Switch, Closure Switch</p>
--	---

References

- [Kramer | Audio Visual Solutions - Kramer](#)
- [User Manual](#)