

Laxihub W2 Wireless Battery Wi-Fi Security Camera



Laxihub W2 Wireless Battery Wi-Fi Security Camera User Guide

[Home](#) » [Laxihub](#) » **Laxihub W2 Wireless Battery Wi-Fi Security Camera User Guide** 

Contents

- [1 Laxihub W2 Wireless Battery Wi-Fi Security Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 Packing list](#)
- [6 Product Description](#)
- [7 Installation](#)
- [8 Product Configuration](#)
- [9 Specifications](#)
- [10 Legal notice](#)
- [11 FCC Statement](#)
- [12 Power Adapter Safety](#)
- [13 BATTERY SAFETY](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)
- [15 Related Posts](#)

Laxihub

Laxihub W2 Wireless Battery Wi-Fi Security Camera



Product Information

Specifications

- **Model:** W2
- **Type:** Wireless battery Wi-Fi security camera
- **Email:** support@arenti.com
- **Phone:** 1-[866-999-7868](tel:866-999-7868), Mon-Fri 9 AM-5PM (PT)
- **Toll-free** for USA & Canada, charges may apply for other regions

Product Usage Instructions

Packing List

- Camera X1
- Screw package X1
- Power adapter X1
- Power cable X1
- Bracket X1
- Quick guide X1

Product Description

The product features a lens, microphone, status light, IR light, PIR sensor, speaker, power port, power button, TF card slot, and a reset button. Different status light colors indicate different camera states.

Installation

1. Find a position with the desired field of view.
2. Use screws and bracket to install the camera:
 - Fix the screw bracket on the wall with screws.
 - Install the device in the bracket and lock it with the bottom screw.

Product Configuration

1. Scan the QR code to download and install the Arenti App from the App Store or Google Play.
2. Register and create a new account in the app.
3. Power on the camera and follow the pairing methods:
 - Pairing via QR code on the device.
 - Pairing via Bluetooth.
 - Pairing via QR code on the App.

Frequently Asked Questions

Q: How do I reset the camera?

A: To reset the device, press and hold the reset button for 5 seconds. The camera will beep when the operation is complete.

Q: What do the different status light colors indicate?

A: Flashing red light (slow) – Wait for network configuration
Flashing red light (fast) – Connecting the network
Fixed red light – Network malfunctions
Fixed blue light – Camera is working correctly

Q: How can I pair the camera with the app if it's not in pairing mode?

A: If the camera is not in pairing mode (red slow blinking) after powering on, press and hold the reset button for 5 seconds to reset. Then restart to pair the camera with the app.

Packing list



Camera X1




Screw package X1



Power adapter X1



Power cable X1




Bracket X1



Quick guide X1

Product Description



Status light Description


- **Flashing red light (slow)** Wait for network configuration
- **Flashing red light (fast)** Connecting the network
- **Fixed red light** Network is malfunction
- **Fixed blue light** Camera is working correctly
- **Note:** To reset the device, press and hold the reset button for 5 seconds. The camera beeps when the operation is complete.

Installation


- Find a position where you can get the desired field of view.

Consider the below factors:


- Avoid direct sunlight.
- Keep it in range of your router's Wi-Fi.
- Avoid the front of the lens facing the plant or porch light; Avoid facing a busy road.
- Install it 2-3 meters (7-10 ft) above the ground – close enough to see someone's face and talk to them through the camera. Make sure that the camera can see what you want to see.



- Use screws and brackets to install the camera.
 - **a.** Fix the screw bracket on the wall with screws.



- **b.** Install the device in the bracket and lock it with the bottom screw.



Product Configuration

Scan the QR code to download and install the Arenti App. Or you can search “Arenti” on App Store (iOS) or Google Play (Android).



Registration

- Open the App. If you are a new user, tap to create a new account and follow the prompts to complete the account setup.
- **Note:** Before creating a new account, please read the Privacy Policy and Terms of Use carefully.




Powering on the device

- Power on the camera. The status light flashing red indicates that the camera is ready for pairing.

Pairing method 1: pairing via QR code on a device


- Open the App home page, click “+” >> “Scan Code”, then scan the QR code pasted on the device casing with the App of your phone, and add the camera to the App.

- **Note:** When pairing, please put the camera and phone close to the router. If a camera is not in the red slow blinking after 30 seconds of powering on, press and hold the reset button for 5 seconds to reset, and then restart to pair the camera with the App.




Pairing method 2: pairing via bluetooth

- Turn on your phone's bluetooth.
- Open the App home page, and click "+" >> "Add Device" or "Add" the device will be searched for by bluetooth and appear on the page. Click the device and follow the notes to pair the camera with the App.



Pairing method 3: pairing via QR code on the App


- Open the App home page, click "+" >> "Add Device" or "Add" and select the icon according to the actual camera.



- Select a fluent and steady Wi-Fi and input the password. Then, scan the QR code in the App on your camera.



- Click “Next” and use the camera to scan the QR code in the App on your mobile phone.



- If no device is found and the pairing process is not successful, please check the below instructions.

Make sure the camera is in pairing mode


- Ensure that the Wi-Fi network is set to 2.4GHz.
- Verify that the entered Wi-Fi password is correct and that the mobile device is connected to the same Wi-Fi network.
- Check for network activity on your Wi-Fi.
- If none of the solutions works or you have any other problems, please call 1- [866-999-7868](tel:866-999-7868) (Mon-Fri 9 AM-5 PM (PT), toll-free for USA&Canada, subject to charges for other regions, Phone Service Language only available in English) or contact support@arenti.com to get help.
- **Note:** If you have multiple cameras, please follow the steps again to add devices one by one. To change the Wi-Fi network, please restore the camera to factory settings and follow the steps to add the camera.

Specifications

- **Product name** W2
- **Resolution** 2304 x 1296
- **The angle of view** is 135°
- **IR Distance** Up to 10m

- **Working temp** -10°C to 50°C
- **Local storage** TF card (up to 256GB)
- **Power input** DC 5V/1A
- **Consumption** Up to 3W
- **Supported phone OS** iOS 9/Android 5.0 or later
- **2.4GHz Wi-Fi** 2412-2462MHz (Max. power<30dBm)
- **Bluetooth** 2400-2483.5MHz (Max. power<20dBm)

Legal notice

- Support www.arenti.com
- Symbols  Direct current (DC)
- Don't throw batteries or out-of-order products with the household waste (garbage). The dangerous substances that they are likely to include may harm health or the environment.
- Make your retailer take back the products or use the selective collection of garbage proposed by your city.
- Hereby, we declare that the radio equipment type 'W2' complies with the Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following Internet address: www.arenti.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

FCC Radiation Exposure Statement: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated per provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference,
2. this device must accept any interference received, including interference that may cause undesired operation.

Caution! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada (ISED) Compliance Statement

This device complies with Industry Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference
2. This device must accept any interference, including interference that may cause undesired operation of the device.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Power Adapter Safety

- The power plug is intended to serve as a disconnect device. Do not drop or cause an impact on the power adapter.
- If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using it at once. Continued use may lead to electric shocks, short circuits, or fire.
- Do not touch the device or the power adapter with wet hands. Doing so may lead to short circuits, malfunctions, or electric shocks.

Child's Safety

- Comply with all precautions for the child's safety. Letting children play with the device or its accessories may be dangerous.
- The device and its accessories are not intended for use by children. Children should only use the device with adult supervision.

Operation Requirements

- Use the device under allowed humidity and temperature conditions.
- Do not aim the device at strong light sources (such as lamplight, and sunlight) when focusing it, to avoid reducing the lifespan of the CMOS sensor, and causing overbrightness and flickering.
- Observe local laws and regulations, and respect the privacy and legal rights of others.


BATTERY SAFETY

- Your device contains a rechargeable lithium-ion battery and should be replaced only by a qualified service provider. Do not disassemble, open, crush, bend, deform, puncture, shred, or attempt to access the battery in your device.
- Do not modify or remanufacture the battery, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids, exposed to fire, explosion, or other hazards.
- DO NOT use a battery if its case appears damaged, swollen, or compromised. Examples include, but are not

limited to, leaking, odors, dents, corrosion, rust, cracks, swelling, melting, and scratches.

- Do not put the battery in the trash that is disposed of in landfills. When disposing of the battery, comply with local ordinances or regulations.
- © 2024. All rights reserved. All trade names are registered trademarks of respective companies Apple, the Apple logo, and iPhone are trademarks of Apple Inc. registered in the U.S. and other countries.
- Google, the Google logo, and Android are trademarks of Google Inc. The App Store is a service mark of Apple Inc. Google Play is a service mark of Google Inc.
- **Email:** support@arenti.com
- **Phone:** 1-[866-999-7868](tel:866-999-7868), Mon-Fri 9AM-5PM (PT)
- **Toll free for USA&Canada, subject to charges for other regions**
- **Phone Service Language only available in English**

Documents / Resources

	<p>Laxihub W2 Wireless Battery Wi-Fi Security Camera [pdf] User Guide</p> <p>W2, W2 Wireless Battery Wi-Fi Security Camera, Wireless Battery Wi-Fi Security Camera, Battery Wi-Fi Security Camera, Wi-Fi Security Camera, Security Camera, Camera</p>
---	---

References

- [Arenti: Best Baby Monitor & Indoor/Outdoor Security Camera](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.