

LED SOLUTION 191049 LED Light with Motion Sensor and Battery Backup Instruction Manual

Home » LED Solution » LED SOLUTION 191049 LED Light with Motion Sensor and Battery Backup Instruction Manual [™]

Contents

- 1 LED SOLUTION 191049 LED Light with Motion Sensor and Battery Backup
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Specification**
- **5 Function**
- 6 Installation
- 7 Test
- 8 Troubleshooting
- 9 Documents / Resources
 - 9.1 References



LED SOLUTION 191049 LED Light with Motion Sensor and Battery Backup



Product Information

Specifications:

• Voltage: 110 – 240 V / AC

• Operating frequency: 50 / 60 Hz

• Light sensitivity setting: 0.5

• Lighting time: Up to 5 hours (if fully charged)

• **Power:** 16W

• Luminous flux: Standard light power

• Backup light power: Luminous flux of the backup light

• Power factor: Not specified

• IP rating: IP20

Detection angle: Not specified
Detection distance: Max. 6m

• Operating temperature: Not specified

• Operating humidity: < 93% RH

• Installation height: 2.2 – 4m

• **Battery:** 3.7V / 1500mAh Li-ion

• Detectable speed: 0.6 - 1.5 m/s

Backup period: Up to 5 hours (if fully charged)
Dimensions: Diameter – 290mm, Height – 60mm

Product Usage Instructions

- 1. Turn off the power supply.
- 2. Unscrew the plastic ring around the sensor and remove the diffuser.
- 3. Thread the supply wire through the cable gland in the luminaire.
- 4. Screw the luminaire using three screws into pre-drilled holes with anchors.

- 5. Make the wire connections according to the wiring diagram.
- 6. Connect the wires from the battery to the connector.
- 7. Attach the diffuser and screw on the plastic ring.
- 8. You can now turn on the power supply.

FAQs

The light is not turning on:

- a. Check if the light is properly connected.
- b. Verify if the power supply is functional.
- c. Ensure that the LUX control is correctly set.

The PIR sensor sensitivity is poor:

- a. Check if there are any obstacles in the sensor's detection field.
- b. Verify if the ambient air temperature is not too high.
- c. Make sure you are moving within the PIR sensor's detection field.

The sensor does not automatically turn off:

- a. Check if there is continuous motion in the detection field.
- b. Verify if the TIME control is not set to a too-long duration.

Made in P.R.C

Contact: obchod@ledsolution.cz
Website: www.ledsolution.cz

The fixture is fully automatic, switched on by a motion sensor, and equipped with a backup power module, allowing continuous lighting in case of a power outage. The fixture is equipped with an LED source, enabling energy-efficient operation.

Specification


Voltage	110 – 240 V / AC	Detection angle	Ceiling 360°
Operating frequency	50 / 60 Hz	Detection distance	Max. 6 m
Light sensitivity setting	<3-2000 LUX (adjustable)	Operating temperature	-20 ~ +40 °C
Lighting time	Min. 10 s ± 3 s/Max. 3 mi n ± 30 s	Operating humidity	< 93% RH
Power	16 W	Installation height	2,2 – 4 m
Luminous flux	1100 lm	Battery	3,7 V / 1500 mAh Li-ion
Backup light power	1,2 W	Detectable speed	0,6 - 1,5 m/s
Luminous flux of the back up light	65 lm	Backup period	Up to 5 hours (if fully char ged)
Power factor	>0,5	Dimensions	Diameter – 290mm / Heig ht – 60mm
IP rating	IP20		

Function


- This light fixture is equipped with a backup power source. In the event of a power outage, the backup light will be illuminated from the battery. It provides uninterrupted lighting for up to 5 hours.
- The light can be switched on during both day and night.
- The user can set the desired light level for activation.
- The light will turn on when motion is detected during the day if the "SUN" (max) position is set. Conversely, the light can turn on only in complete darkness at a light level of 3 LUX, if the "MOON" (min) position is set.
- The lighting duration can be set using the second controller: If the set duration elapses and no further motion is detected by the sensor, the light will turn off. It will turn on again with a new motion.
- Setting the lighting duration: The user can adjust the duration of lighting activation.
- The minimum duration is 10 seconds ± 3 seconds, and the maximum duration is 3 minutes ± 30 seconds.

Installation

- 1. Turn off the power supply.
- 2. Unscrew the plastic ring around the sensor and remove the diffuser (Pic. 1).
- 3. Thread the supply wire through the cable gland in the luminaire. Then, screw the luminaire using three screws into pre-drilled holes with anchors (Pic. 2). Make the wire connections according to the wiring diagram (Pic. 3).
- 4. Connect the wires from the battery to the connector (Pic. 4)
- 5. Attach the diffuser and screw on the plastic ring.
- 6. You can now turn on the power supply.




PIR:



360°

Test



- 1. Turn the TIME knob to the minimum (-) position. Turn the LUX knob to the maximum (SUN) position.
- 2. Turn on the power supply. The light will not function immediately, it will respond to motion only after approximately 30 seconds of warming up. When the motion sensor detects movement, the light will turn on. Once the motion stops, the light will turn off after the set time.
- 3. Turn the LUX knob to the minimum (MOON) position. If the ambient light level is higher than 3 LUX, the light will not turn on. If the ambient light drops to 3 LUX (DARK), the sensor will activate and the light will illuminate. If there is no motion within the sensor range, the light will turn off after the set time.
- 4. In the event of a power outage, the emergency module will activate automatically, and the light will continuously illuminate in emergency mode for up to 5 hours.

Note

If you perform the test during the day, set the controller to the "SUN" position; otherwise, the light fixture will not

function. Installation should only be carried out by a person with electrical qualifications. Obstacles within the sensor's detection range can negatively affect detection functions. Do not install the light fixture near sources of heat or airflow, such as heaters, air conditioners, etc.

Troubleshooting

- The light is not turning on:
 - a. Check if the light is properly connected.
 - **b.** Verify if the power supply is functional.
 - c. Ensure that the LUX control is correctly set.
- The PIR sensor sensitivity is poor:
 - a. Check if there are any obstacles in the sensor's detection field.
 - **b.** Verify if the ambient air temperature is not too high.
 - c. Make sure you are moving within the PIR sensor's detection field.
- · The sensor does not automatically turn off:
 - a. Check if there is continuous motion in the detection field.
 - **b.** Verify if the TIME control is not set to a too long duration.

Producer LED Solution s.r.o., Výrobce M. Horákové185/66, Liberec 460 07 Made in P.R.C <u>obchod@ledsolution.cz</u> https://www.ledsolution.cz/

Documents / Resources



LED SOLUTION 191049 LED Light with Motion Sensor and Battery Backup [pdf] Instruction Manual

191049 LED Light with Motion Sensor and Battery Backup, 191049, LED Light with Motion Sensor and Battery Backup, Motion Sensor and Battery Backup, Battery Backup, Backup

References

- O Český výrobce kvalitního LED osvětlení | LED Solution
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.