

LEDYi Lighting PR RGB2 3x10A 3v1 RGB/CCT/Dimming 3 Channel LED RF Controller Owner's Manual

Home » LEDYI Lighting » LEDYi Lighting PR RGB2 3x10A 3v1 RGB/CCT/Dimming 3 Channel LED RF Controller Owner's Manual ™

Contents

- 1 LEDYi Lighting PR RGB2 3x10A 3v1 RGB/CCT/Dimming 3 Channel LED RF Controller
- 2 Features
- 3 Technical Parameters
- **4 Mechanical Structures and Installations**
- **5 Wiring Diagram**
- 6 Match Remote Control (two match ways)
- 7 RGB Dynamic mode list
- 8 Dual color control
- 9 Malfunctions analysis & troubleshooting
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



LEDYi Lighting PR RGB2 3x10A 3v1 RGB/CCT/Dimming 3 Channel LED RF Controller



Model No: PR RGB2 3x10A 3v1

3 Channels/10A per channel/Step-less dimming/Wireless remote control/Auto-transmitting/Synchronize

Features

- Match with RF 2.4G single zone or multiple zone single color, dual color, and RGB/RGBW remote control.
- One RF controller accepts up to 10 remote control.
- 4096 levels 0-100% dimming smoothly without any flash.
- When using RGB light, built-in 10 dynamic modes, include jump or gradual change style.
- Auto-transmitting function: The Controller automatically transmits a signal to another controller with a 15m control distance.
- Synchronize on multiple controllers.

Technical Parameters

Input and Output	
Input voltage	12-36VDC
Input current	30.5A
Output voltage	3 x (12-36)VDC
Output current	3CH,10A/CH
Output power	360-1080W(12-36V)
Output type	Constant voltage

Environment	
Operation temperature Ta: -30 OC ~ +55 OC	
Case temperature (Max.)	T c: +85OC
IP rating	IP20

Warranty and Protection	
Warranty	2 years
Protection	Reverse Polarity


Dimming data


Input signal	RF 2.4GHz
Control distance	15m(Barrier-free space)
Dimming gray scale	4096 (2^12) levels
Dimming range	0 -100%
Dimming curve	Logarithmic
PWM Frequency	750Hz (default)

Safety and EMC	
EMC standard (EMC) EN301 489, EN 62479	
Safety standard(LVD)	EN60950
Radio Equipment(RED)	EN300 328
Certification	CE,EMC, LVD,RED


Weight	
Net weight	0.240kg
Gross weight	0.259kg

Mechanical Structures and Installations





Wiring Diagram



Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:

Short press the match key, and immediately press the on/off key (single zone remote) or zone key (multiple zone remote) of the remote. The LED indicator fast flash a few times means match is successful.

Delete:

Press and hold the match key for 5s to delete all matches, The LED indicator fast flash a few times means all matched remotes were deleted.

Use Power Restart

Match:


Switch off the power, then switch on power again, and immediately short press the on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The light blinks 3 times means match is successful.

Delete:

Switch off the power, then switch on power again, and immediately short press the on/off key (single zone remote)

or zone key (multiple zone remote) 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

RGB Dynamic mode list



Dual color control

- CH1=Warm white LED
- CH2=Cool white LED


Each channel can supply up to 240W(@24V) and the white balance can be controlled as such:


Color temperature	Cool white	Neutral white	Warm white
Power distribution	CH1=0W,CH2=240W	CH1=120W,CH2=120W	CH1=240W,CH2=0W




Dimming curve for CCT

Dimming curve for RGB/DIM







Malfunctions analysis & troubleshooting

Malfunctions	Causes Troubleshooting	
	1. No power.	Check the power.
No light	2. Wrong connection or insecure.	2. Check the connection.
Wrong color	1. Wrong connection of R/G/B wires.	1. Reconnect R/G/B wires.
	1. Output cable is too long.	Reduce cable or loop supply.
Uneven intensity	2. Wire diameter is too small.	2. Change wider wire.
between front and rea r,with voltage drop	3. Overload beyond power supply capability.	3. Replace higher power supply.
	4. Overload beyond controller capability.	4. Add power repeater.
	The battery has no power.	Replace battery.
No response from the remote	2. Beyond controllable distance.	2. Reduce remote distance.
	3. The controller did not match the remote.	3. Re-match the remote.

Documents / Resources



<u>LEDYi Lighting PR RGB2 3x10A 3v1 RGB/CCT/Dimming 3 Channel LED RF Controller</u> [pdf] Owner's Manual

PR RGB2 3x10A 3v1 RGB CCT Dimming 3 Channel LED RF Controller, PR RGB2 3x10A 3v1, RGB CCT Dimming 3 Channel LED RF Controller, CCT Dimming 3 Channel LED RF Controller, Dimming 3 Channel LED RF Controller, 3 Channel LED RF Controller, LED RF Controller, RF C ontroller, Controller

References

User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.